


# Capacitance Diaphragm Gauge

## CDG045D








**CE**

**Operating Manual**  
Incl. Declaration of Conformity

## Product Identification

In all communications with INFICON, please specify the information given on the product nameplate. For convenient reference copy that information into the space provided below.


INFICON AG, LI-9496 Balzers		 
Model:	-----	
PN:	-----	 
SN:	-----	
	V    W	



## Validity

This document applies to products of the CDG045D series.


Part numbers of standard products are indicated below. OEM products have other part numbers and different parameter settings (e.g. factory setting of setpoint) as defined in the corresponding ordering information.



The part number (PN) can be taken from the product nameplate. If not indicated otherwise in the legends, the illustrations in this document correspond to CDG045D gauges with the DN 16 ISO-KF vacuum connection. They apply to other vacuum connections by analogy.

We reserve the right to make technical changes without prior notice.

## Intended Use

The temperature compensated Capacitance Diaphragm Gauges of the CDG045 series are intended for absolute pressure measurement of gases in their respective pressure ranges (→  3).

The gauges belong to the SKY<sup>®</sup> Smart Sensors family and can be operated in connection with an INFICON Vacuum Gauge Controller (VGC series) or another appropriate controller.

## Functional Principle

A ceramic diaphragm is deflected by pressure. The deflection is measured capacitively and converted into an analog linear output signal by the digital electronics.

The output signal is independent of the gas type.

Very accurate pressure measurement is achieved by heating the sensor to a constant temperature of 45°C which results in a compensation of changes in the ambient conditions and a reduced deposition of process products and by-products in process applications.



## Trademarks

SKY<sup>®</sup>    INFICON GmbH  
VCR<sup>®</sup>    Swagelok Marketing Co.

## Contents

Product Identification	2
Validity	3
Intended Use	4
Function	4
Trademarks	4
<b>1 Safety</b>	<b>7</b>
1.1 Symbols Used	7
1.2 Personnel Qualifications	7
1.3 General Safety Instructions	8
1.4 Liability and Warranty	8
<b>2 Technical Data</b>	<b>9</b>
<b>3 Installation</b>	<b>14</b>
3.1 Vacuum Connection	14
3.2 Power Connection	17
<b>4 Operation</b>	<b>20</b>
4.1 Displays	20
4.2 Zeroing the Gauge	21
4.3 Switching Functions	26
4.4 Activating the Factory Setting (Factory Reset)	29
4.5 Diagnostic Port (RS232C Interface)	30
<b>5 Deinstallation</b>	<b>31</b>
<b>6 Maintenance, Repair</b>	<b>32</b>
<b>7 Returning the Product</b>	<b>33</b>
<b>8 Disposal</b>	<b>33</b>
<b>9 Accessories</b>	<b>34</b>

<b>Further Information</b>	<b>35</b>
<b>Declaration of Contamination</b>	<b>36</b>
<b>ETL Certification</b>	<b>37</b>
<b>EC Declaration of Conformity</b>	<b>38</b>

For cross-references within this document, the symbol (→  XY) is used, for cross-references to further documents, listed under "Further Information", the symbol (→  [Z]).

# 1 Safety

## 1.1 Symbols Used



**DANGER**

Information on preventing any kind of physical injury.



**WARNING**

Information on preventing extensive equipment and environmental damage.



**Caution**

Information on correct handling or use. Disregard can lead to malfunctions or minor equipment damage.



Notice

## 1.2 Personnel Qualifications



**Skilled personnel**

All work described in this document may only be carried out by persons who have suitable technical training and the necessary experience or who have been instructed by the end-user of the product.

### 1.3 General Safety Instructions

- Adhere to the applicable regulations and take the necessary precautions for the process media used.  
Consider possible reactions with the product materials.
- Adhere to the applicable regulations and take the necessary precautions for all work you are going to do and consider the safety instructions in this document.
- Before beginning to work, find out whether any vacuum components are contaminated. Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.

Communicate the safety instructions to all other users.

### 1.4 Liability and Warranty

INFICON assumes no liability and the warranty becomes null and void if the end-user or third parties


- disregard the information in this document
- use the product in a non-conforming manner
- make any kind of interventions (modifications, alterations etc.) on the product
- use the product with accessories not listed in the product documentation.

The end-user assumes the responsibility in conjunction with the process media used.

Gauge failures due to contamination are not covered by the warranty.

## 2 Technical Data



For further technical data for gauges with DeviceNet and Profibus interface →  [4] and [5].

Measurement range	→ "Validity"
Accuracy <sup>1)</sup>	0.15% of measured value
Temperature effect on zero	
0.1 / 0.25 / 0.5 F.S.	0.0050% F.S./ °C
1 ... 1100 F.S.	0.0025% F.S./ °C
Temperature effect on span	0.01% of reading / °C
Resolution	0.003% F.S.
Gas type dependence	none
<hr/>	
Output signal analog (measurement signal)	
Measurement range	0 ... +10 V
Voltage range	-5 ... +10.24 V (limited to +10.24 V)
Relationship voltage-pressure	linear
Output impedance	0 Ω (short-circuit proof)
Loaded impedance	>10 kΩ
Response time <sup>2)</sup>	30 ms
<hr/>	
Identification	
Resistance R <sub>Ident</sub>	13.2 kΩ referenced to
Voltage	supply common
	≤5 V
<hr/>	


<sup>1)</sup> Non-linearity, hysteresis, repeatability at 25 °C ambient operating temperature without temperature effects after operation of 2 h.

<sup>2)</sup> Increase 10 ... 90 % F.S.R.

Switching functions	SP1, SP2
Setting range	0 ... 99% F.S. (0 ... 9.9 V)
Hysteresis	1% F.S.
Relay contact	30 VDC/ $\leq 0.5$ ADC floating (n.o.)
closed	$p \leq p_{SP}$ (LED is lit)
open	$p \geq p_{SP}$ (LED is dark)
Switching time	$\leq 50$ ms

---

RS232C interface	
Transmission rate	9600 baud
Data format	binary 8 data bits one stop bit no parity bit no handshake → "Electrical Connection"


For further information on the RS232C interface →  [3].


---

Diagnostic port	Jack connector, 2.5 mm, 3-pin
-----------------	----------------------------------

---

### Supply




**DANGER**

The gauge may only be connected to power supplies, instruments or control devices that conform to the requirements of a grounded protective extra-low voltage (SELV-E according to EN 61010). The connection to the gauge has to be fused<sup>3)</sup>.

<sup>3)</sup> INFICON controllers fulfill this requirement.

Supply voltage at the gauge	+14 ... +30 VDC or ±15 V (±5%)
Ripple	≤1 V <sub>pp</sub>
Power consumption while being heated	≤12 W
at operating temperature	≤8 W

The gauge is protected against reverse polarity of the supply voltage and overload.

---

Electrical connection	15 poles D-Sub, male
Sensor cable	15 poles plus shielding
Cable length	
Supply voltage 15 V	≤ 8 m (0.14 mm <sup>2</sup> /conductor) ≤15 m (0.25 mm <sup>2</sup> /conductor)
Supply voltage 24 V	≤43 m (0.14 mm <sup>2</sup> /conductor) ≤75 m (0.25 mm <sup>2</sup> /conductor)
Supply voltage 30 V	≤88 m (0.14 mm <sup>2</sup> /conductor) ≤135 m (0.25 mm <sup>2</sup> /conductor)

For longer cables, larger conductor cross-sections are required ( $R_{\text{cable}} \leq 1.0 \Omega$ ).

---

Grounding concept	→ "Electrical Connection"
-------------------	---------------------------

---

Materials exposed to vacuum	ceramics (Al <sub>2</sub> O <sub>3</sub> ≥99.5%), stainless steel AISI 316L, nickel, glass solder
Internal volume	≤4.2 cm <sup>3</sup>
Admissible pressure (absolute)	
200 / 500 / 1000 / 1100 F.S.	3 bar
1 / 2 / 5 / 10 / 20 / 50 / 100 F.S.	2 bar
0.1 / 0.25 / 0.5 F.S.	1.3 bar
Bursting pressure (absolute)	6 bar

---

### Admissible temperatures

Storage	-40 °C ... +65 °C
Operation	+10 °C ... +40 °C
Bakeout	≤110 °C at the flange

### Relative humidity

≤80% at temperatures ≤+31 °C, decreasing to 50% at +40°C
--


### Use

indoors only, altitude up to  
2000 m NN

### Type of protection

IP 40

### Dimensions [mm]




Weight

837 ... 897 g

## Analog Measurement Signal vs. Pressure

Pressure p



$$p = (U_{out} / 10 \text{ V}) \times p (\text{F.S.})$$

Conversion Torr  $\leftrightarrow$  Pascal

	Torr	mbar <sup>4)</sup>	Pa <sup>4)</sup>
c	1.00	1013.25 / 760 = 1.3332...	101325 / 760 = 133.3224...

Example: Gauge with 10 Torr F.S.  
Measurement signal  $U_{out} = 6 \text{ V}$

$$\begin{aligned} p &= (6 \text{ V} / 10 \text{ V}) \times 10 \text{ Torr} \\ &= 0.6 \times 10 \text{ Torr} = \mathbf{6 \text{ Torr}} \end{aligned}$$

<sup>4)</sup> Source: NPL (National Physical Laboratory)  
Guide to the Measurement of Pressure and Vacuum, ISBN 0904457x / 1998

## 3 Installation



### WARNING



WARNING: fragile components

The ceramic sensor may be damaged by impacts.

Do not drop the product and prevent shocks and impacts.

### 3.1 Vacuum Connection



### DANGER



DANGER: overpressure in the vacuum system  
>1 bar

Injury caused by released parts and harm caused by escaping process gases can result if clamps are opened while the vacuum system is pressurized.

Do not open any clamps while the vacuum system is pressurized. Use the type clamps which are suited to overpressure.



### DANGER



DANGER: overpressure in the vacuum system  
>2.5 bar

KF flange connections with elastomer seals (e.g. O-rings) cannot withstand such pressures. Process media can thus leak and possibly damage your health.

Use O-rings provided with an outer centering ring.


**DANGER**


**DANGER:** protective ground

Products that are not correctly connected to ground can be extremely hazardous in the event of a fault.

Electrically connect the gauge to the grounded vacuum chamber. This connection must conform to the requirements of a protective connection according to EN 61010:

- CF and VCR flanges fulfill this requirement.
- For gauges with a KF flange, use a conductive metallic clamping ring.
- For gauges with a 1/2" tube, take appropriate measures to fulfill this requirement.


**Caution**


**Caution:** vacuum component

Dirt and damages impair the function of the vacuum component.

When handling vacuum components, take appropriate measures to ensure cleanliness and prevent damages.


**Caution**


**Caution:** dirt sensitive area


Touching the product or parts thereof with bare hands increases the desorption rate.

Always wear clean, lint-free gloves and use clean tools when working in this area.



Mount the gauge so that no vibrations occur. The gauge may be mounted in any orientation. To keep condensates and particles from getting into the measuring chamber preferably choose a horizontal to upright position. If adjustment should be possible after the gauge has been installed, be sure to install it so that the buttons can be accessed with a pin (→ 21).


Remove the protective lid and connect the product to the vacuum system.





Keep the protective lid.

## 3.2 Power Connection



Make sure the vacuum connection is properly made (→  14).


**DANGER**



The gauge may only be connected to power supplies, instruments or control devices that conform to the requirements of a grounded protective extra-low voltage (SELV-E according to EN 61010). The connection to the gauge has to be fused <sup>5)</sup>.




Ground loops, differences of potential, or EMC problems may affect the measurement signal. For optimum signal quality, please do observe the following notes:

- Connect the cable shield to ground on one side via the chassis ground. Do not connect the other side of the shield.
- Connect the supply common with protective ground directly at the power supply (SELV-E EN 61010).
- Use differential measurement input (signal common and supply common conducted separately).

---


<sup>5)</sup> INFICON controllers fulfill this requirement.

- 1** If no sensor cable is available, make one according to the following diagram (cable length and conductor cross-sections → 11).




#### Electrical connection

Pin 1, 4	Relay SP1, closing contact
Pin 2	Signal output (measurement signal) or thresholds SP1/2
Pin 3	Status
Pin 5	Supply common
Pin 6	Supply (-15 V)
Pin 7, 11	Supply (+14 ... +30 V or +15 V)
Pin 8, 9	Relay SP2, closing contact
Pin 10	Gauge identification or Remote Zero Adjust
Pin 12	Signal common
Pin 13	RS232, TxD
Pin 14	RS232, RxD
Pin 15	Housing (Chassis Ground)
case	Connector case




- 2** Connect the sensor cable to the gauge and secure it using the lock screws.




- 3** Connect the sensor cable to the controller.

## 4 Operation

Put the gauge into operation. If you are using an INFICON controller, define the measurement range (→  [1, 2]).

A warm-up time of at least ½ hour should be allowed; for precise pressure measurements a warm-up time of at least 2 hours is required.

### 4.1 Displays



LED	State	Meaning
<STATUS>	dark	No supply voltage
	lit green	Measurement mode
	flashing green	Warming up, warning
	lit red	Error
<SP1>	lit green	$p \leq$ setpoint 1
	flashing green	Waiting for setpoint 1 input
	dark	$p >$ setpoint 1
<SP2>	lit green	$p \leq$ setpoint 2
	flashing green	Waiting for setpoint 2 input
	dark	$p >$ setpoint 2

## 4.2 Zeroing the Gauge

The gauge is factory calibrated while "standing upright" (→ "Calibration Test Report").

When the gauge is operated for the first time, a zero adjustment should be performed.

Due to long time operation or contamination, a zero drift could occur and zero adjustment may become necessary.

For adjusting the zero, operate the gauge under the same ambient conditions and in the same mounting orientation as normally.

The signal difference between the vertical and horizontal mounting orientation is:

F.S.	$\Delta U / 90^\circ$
1000 Torr/mbar	2 mV
100 Torr/mbar	10 mV
10 Torr/mbar	50 mV
1 Torr/mbar	300 mV





If the gauge is operated via a controller, the zero of the whole measuring system has to be adjusted on the controller: first, adjust the zero of the gauge and then, the zero of the controller.

## 4.2.1 <ZERO> Adjustment



The zero can be adjusted via

- the <ZERO> button on the gauge,
- the diagnostic port (→  [6]),
- the digital input "Remote Zero" (briefly apply the supply voltage (+14 ... +30 V) to pin 10),
- the RS232C interface (→  [3]),
- an INFICON Vacuum Gauge Controller (VGC series).




While the gauge is being heated and/or under atmospheric pressure, the zeroing function is locked in order for operating errors to be prevented.




Evacuate the gauge to a pressure according to the table below:

F.S.		Recommended final pressure for zero adjustment		
1100	mbar	-	$<6.65 \times 10^0$ Pa	$<5 \times 10^{-2}$ mbar
1000	Torr/mbar	$<5 \times 10^{-2}$ Torr	$<6.65 \times 10^0$ Pa	$<5 \times 10^{-2}$ mbar
500	Torr/mbar	$<2.5 \times 10^{-2}$ Torr	$<3.33 \times 10^0$ Pa	$<2.5 \times 10^{-2}$ mbar
200	Torr/mbar	$<10^{-2}$ Torr	$<1.33 \times 10^0$ Pa	$<10^{-2}$ mbar
100	Torr/mbar	$<5 \times 10^{-3}$ Torr	$<6.65 \times 10^{-1}$ Pa	$<5 \times 10^{-3}$ mbar
50	Torr/mbar	$<2.5 \times 10^{-3}$ Torr	$<3.33 \times 10^{-1}$ Pa	$<2.5 \times 10^{-3}$ mbar
20	Torr/mbar	$<10^{-3}$ Torr	$<1.33 \times 10^{-1}$ Pa	$<10^{-3}$ mbar
10	Torr/mbar	$<5 \times 10^{-4}$ Torr	$<6.65 \times 10^{-2}$ Pa	$<5 \times 10^{-4}$ mbar
5	Torr/mbar	$<2.5 \times 10^{-4}$ Torr	$<3.33 \times 10^{-2}$ Pa	$<2.5 \times 10^{-4}$ mbar
2	Torr/mbar	$<10^{-4}$ Torr	$<1.33 \times 10^{-2}$ Pa	$<10^{-4}$ mbar
1	Torr/mbar	$<5 \times 10^{-5}$ Torr	$<6.65 \times 10^{-3}$ Pa	$<5 \times 10^{-5}$ mbar
0.5	Torr/mbar	$<2.5 \times 10^{-5}$ Torr	$<3.33 \times 10^{-3}$ Pa	$<2.5 \times 10^{-5}$ mbar
0.25	Torr/mbar	$<10^{-5}$ Torr	$<1.33 \times 10^{-3}$ Pa	$<10^{-5}$ mbar
0.1	Torr/mbar	$<5 \times 10^{-6}$ Torr	$<6.65 \times 10^{-4}$ Pa	$<5 \times 10^{-6}$ mbar

If the final pressure is too high for zero adjustment ( $>50\%$  of the F.S.), the zero cannot be reached and the <STATUS> LED flashes green. If this is the case, activate the factory setting and adjust the zero again (→  29).

- 2 Operate the gauge for at least ¼ hour (until the signal is stable).
- 3 Briefly press the <ZERO> button with a pin (max.  $\varnothing 1.1$  mm). The zero adjustment runs automatically. The <STATUS> LED flashes until the adjustment (duration  $\leq 8$  s) is completed.



After zero adjustment, the gauge automatically returns to the measurement mode.

The <STATUS> LED flashes green if

- the signal output is negative ( $>6.5$  mV) when the final pressure has been attained
- the zero adjustment has failed.

#### 4.2.2 <ZERO> Adjustment with Ramp Function

The ramp function allows to adjust the zero at a known reference pressure within the measurement range of the gauge.



It also permits to adjust an offset of the characteristic curve in order to

- compensate for the offset of the measuring system or
- obtain a slightly positive zero for a 0 ... 10 V AD converter.


The offset should not exceed 2% of the F.S. (+200 mV). At a higher positive offset, the upper limit of the measurement range (+10.24 V) is exceeded.



Zero adjustment using the ramp function can be performed via

- the <ZERO> button on the gauge,
- the diagnostic port (→  [6]),
- the RS232C interface (→  [3]).




Recommended procedure for adjusting the offset of a measuring system: → Notice  21.

**1**

Operate the gauge for at least 1 hour (until the signal is stable).

**2**

Push the <ZERO> button with a pin (max.  $\varnothing 1.1$  mm) and keep it depressed. The <STATUS> LED starts flashing. After 5 s, the zero adjustment value, starting at the current output value, keeps continually changing (ramp) until the button is released or until the setting limit (min. 50% F.S.) is reached.



**3** Push the <ZERO> button again:

Fine adjustment within 0...3 s:	the zero adjustment value changes by one unit
Change of direction within 3...5 s:	the zero adjustment changes its direction (the flashing frequency of the <STATUS> LED changes briefly)



If the <ZERO> button is released for more than 5 s, the gauge returns to the measurement mode.

The <STATUS> LED flashes green if the signal output is negative (>6.5 mV).


### 4.3 Switching Functions

The two switching functions can be set to any pressure within the measurement range of the gauge (→ [13](#)).

The current setpoint setting

- can be read/written via the diagnostic port,
- is output at the D-Sub connector instead of the measurement signal (→ [18](#)) and can be measured with a voltmeter after the <SP> button is pressed, or
- can be read/written via the RS232C interface.



If the pressure is lower than the setpoint, the corresponding LED is lit (<SP1> or <SP2>) and the corresponding relay (→ [18](#)) is energized.



### 4.3.1 Adjusting the Setpoints



The setpoints can be adjusted via

- the buttons on the gauge,
- the diagnostic port (→  [6]),
- the RS232C interface (→  [3]).



**DANGER**



**DANGER: malfunction**


If processes are controlled via the signal output, keep in mind that by pushing the <SP> button the measurement signal is suppressed and the corresponding threshold value is output instead. This can cause malfunctions.

Push the <SP> button only if you are sure that no damages can arise from a malfunction.


#### Adjusting Setpoint <1>



Push the <SP> button with a pin (max.  $\varnothing 1.1$  mm). The gauge changes to the switching function mode and outputs the current threshold value at the measurement value output for about 10 s (LED <1> flashes).



- 2** For changing the threshold value, push the <ZERO> button and keep it depressed. The threshold keeps changing from the current value (ramp) until the button is released or until the limit of the setting range is reached.



- 3** Push the <ZERO> button again:

Fine adjustment within 0...3 s:	the zero adjustment value changes by one unit
Change of direction within 3...5 s:	the zero adjustment changes its direction (the flashing frequency of the <STATUS> LED changes briefly)



If the <ZERO> button is released for more than 5 s, the gauge returns the measurement mode.



The upper threshold is automatically set 1% F.S. above the lower one (hysteresis).


### Adjusting Setpoint <2>


Push the <SP> button twice (LED <2> flashes). The adjustment procedure is the same as for setpoint <1>.

## 4.4 Activating the Factory Setting (Factory Reset)

The factory parameter setting is activated by keeping the <ZERO> button depressed for at least 5 s while the gauge is being put into operation (Power ON).

## 4.5 Diagnostic Port (RS232C Interface)

The diagnostic port <DIAG> permits to output the pressure reading and all status information and to enter all settings at the same time (→  [6]).



## 5 Deinstallation



### WARNING



WARNING: fragile components

The ceramic sensor may be damaged by impacts.

Do not drop the product and prevent shocks and impacts.



### DANGER



DANGER: contaminated parts

Contaminated parts can be detrimental to health and environment.

Before beginning to work, find out whether any parts are contaminated. Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.



### Caution



Caution: vacuum component

Dirt and damages impair the function of the vacuum component.

When handling vacuum components, take appropriate measures to ensure cleanliness and prevent damages.



### Caution



Caution: dirt sensitive area

Touching the product or parts thereof with bare hands increases the desorption rate.

Always wear clean, lint-free gloves and use clean tools when working in this area.

- 1 Vent the vacuum system.
- 2 Turn the gauge off.
- 3 Unfasten the lock screws and disconnect the sensor cable.
- 4 Remove the gauge from the vacuum system and install the protective lid.

## 6 Maintenance, Repair

Under clean operating conditions, the product requires no maintenance.



Gauge failures due to contamination are not covered by the warranty.

INFICON assumes no liability and the warranty becomes null and void if any repair work is carried out by the end-user or third parties.

## 7 Returning the Product



### WARNING



**WARNING:** forwarding contaminated products  
Contaminated products (e.g. radioactive, toxic, caustic or microbiological hazard) can be detrimental to health and environment.

Products returned to INFICON should preferably be free of harmful substances. Adhere to the forwarding regulations of all involved countries and forwarding companies and enclose a duly completed declaration of contamination.

Products that are not clearly declared as "free of harmful substances" are decontaminated at the expense of the customer. Products not accompanied by a duly completed declaration of contamination are returned to the sender at his own expense.

## 8 Disposal



### DANGER



**Caution:** contaminated parts

Contaminated parts can be detrimental to health and environment.

Before beginning to work, find out whether any parts are contaminated. Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.



## WARNING



Caution: substances detrimental to the environment

Products or parts thereof (mechanical and electric components, operating fluids etc.) can be detrimental to the environment.

Dispose of such substances in accordance with the relevant local regulations.

## Separating the components

After disassembling the product, separate its components according to the following criteria:







- Contaminated components  
Contaminated components (radioactive, toxic, caustic or biological hazard etc.) must be decontaminated in accordance with the relevant national regulations, separated according to their materials, and disposed of.
- Other components  
Such components must be separated according to their materials and recycled.

## 9 Accessories

	Ordering number
Communication adapter (2 m) <sup>6)</sup>	303-333

<sup>6)</sup> The diagnostic software (Windows NT, XP) can be downloaded from our website.

## Further Information

-  [1] [www.inficon.com](http://www.inficon.com)  
 Operating Manual  
 Vacuum Gauge Controller VGC032  
 tinb02e1  
 INFICON AG, LI-9496 Balzers, Liechtenstein
-  [2] [www.inficon.com](http://www.inficon.com)  
 Operating Manual  
 Single-Channel Controller VGC401  
 tinb01e1  
 INFICON AG, LI-9496 Balzers, Liechtenstein
-  [3] [www.inficon.com](http://www.inficon.com)  
 Communication Protocol  
 RS323C Interface  
 tira49e1  
 INFICON AG, LI-9496 Balzers, Liechtenstein
-  [4] [www.inficon.com](http://www.inficon.com)  
 Communication Protocol  
 DeviceNet™ CDG045D  
 tira51e1  
 INFICON AG, LI-9496 Balzers, Liechtenstein
-  [5] [www.inficon.com](http://www.inficon.com)  
 Communication Protocol  
 Profibus CDG045D  
 tira54e1  
 INFICON AG, LI-9496 Balzers, Liechtenstein
-  [6] [www.inficon.com](http://www.inficon.com)  
 Operating Manual  
 Diagnostic Software  
 tina55e1  
 INFICON AG, LI-9496 Balzers, Liechtenstein



## ETL Certification



ETL LISTED  
CONFORMS TO UL STD 61010-1  
CERTIFIED TO CAN/CSA STD C22.2  
NO 61010-1

## EC Declaration of Conformity



We, INFICON, hereby declare that the equipment mentioned below complies with the provisions of the Directive relating to electrical equipment designed for use within certain voltage limits 2006/95/EC and the Directive relating to electromagnetic compatibility 2004/108/EC.

# Capacitance Diaphragm Gauge CDG045D

### Standards

Harmonized and international/national standards and specifications:

- EN 61000-6-2 (EMC: generic immunity standard)
- EN 61000-6-3 (EMC: generic emission standard)
- EN 61010-1 (Safety requirements for electrical equipment for measurement, control and laboratory use)

### Signatures

INFICON AG, Balzers

4 March 2008



Dr. Urs Wälchli  
Managing Director

4 March 2008



Alex Nef  
Product Manager

## Notes

Original: German tina51d1 (2008-03)



tina51e1



LI-9496 Balzers  
Liechtenstein  
Tel +423 / 388 3111  
Fax +423 / 388 3700  
[reachus@inficon.com](mailto:reachus@inficon.com)

[www.inficon.com](http://www.inficon.com)