

GAS-Mate®

Combustible Gas Leak Detector



TWICE THE SENSITIVITY OF THE NEAREST COMPETITOR AND THREE TIMES THE WARRANTY

INFICON raises the bar on combustible gas detectors with the next-generation GAS-Mate, the ideal tool for locating leaks in combustion appliances, such as natural gas or propane-fired heating systems, or gas valves, regulators and pipelines.

GAS-Mate outperforms other models with twice the sensitivity of the closest competitor - down to 5 ppm methane, the main component of natural gas. GAS-Mate also detects many other combustible gases, such as ammonia, propane, ethanol and hydrogen sulfide.

No calibration is required for GAS-Mate or its field-replaceable sensor. Simply turn the unit on, allow it to warm up for a few seconds and it is ready to quickly pinpoint any gas leaks present.

To prove that GAS-Mate has the performance and durability for your job, it carries an industry-leading, three year over-the-counter replacement warranty – three times what most other manufacturers offer.

FEATURES AT A GLANCE

- Sensitive to 5 ppm methane (twice as sensitive as the nearest competitor)
- Also detects natural gas, propane, butane, cyclopentane, ethane, ethanol, isobutane and ammonia
- Multiple LEDs, variable intensity audio alarm indicate leak strength
- Adjustable sensitivity helps pinpoint leaks fast
- Auto-zeroing for ignoring background gas levels in leak test area
- Small sensor and probe tip permit leak checking in tighter places
- Certified intrinsically safe by MET Laboratories for use in combustible/explosive environments
- 3-year replacement warranty
- Made in the USA



SPECIFICATIONS

Base unit includes	Sensor, two D-size alkaline batteries, and a hard plastic carrying case.
Sensitivity	5 ppm methane
Controls	Power button, sensitivity touch pad
Power source	2 D-size (1.5V) alkaline batteries, included (use Duracell® MN1300 to maintain intrinsically safe approval)
Battery life	40 hours
Probe	Chrome-plated flexible metal, approx. 17" (43 cm) long
Alarm indicators	Multiple LEDs, variable intensity audio alarm
Weight with batteries	1.54 lb (700 g)
Certifications	Intrinsic Safety Testing Pending
Warranty	3-year replacement

ORDERING INFORMATION

GAS-Mate	718-202-G1
Replacement Parts	
Sensor	706-700-G1



www.inficonservicetools.com service.tools@inficon.com

GAS-Mate is a registered trademark of INFICON.

Due to our continuing program of product improvements, specifications are subject to change without notice.

eibb79a1-b ©2011 INFICON