

# TEK-Mate<sup>®</sup>

## Refrigerant Leak Detector



### THE AFFORDABLE, PORTABLE LEAK DETECTOR

If you're looking for a moderately priced, hand-held leak detector with proven D-TEK™ heated diode sensor technology — TEK-Mate is the tool for you.

- ◆ 0.4 oz./yr. sensitivity to CFCs, HCFCs, and HFCs
- ◆ Automatically compensates for changing background contamination
- ◆ Variable intensity audible signal and single flashing LED help locate leaks fast
- ◆ Uses 2 "D" batteries

### TECHNICAL NOTES

The INFICON TEK-Mate Refrigerant Leak Detector incorporates an electrochemical sensor consisting of a ceramic substrate, doped with a reactive element, and maintained at high temperature by a built-in heating element. When a halogen-bearing gas contacts with the hot surface, the chlorine, fluorine, or bromine atoms are separated from the molecule and ionized. This causes an electrical current to flow within the ceramic to a collection electrode at the center.

Careful selection and application of the ceramic permits the INFICON sensor to provide similar responses to CFCs (such as R11 and R12), HCFCs (such as R22 and R123), HFCs (such as R134a) as well as replacement blends (such as R404A and R410A) so that the operator need not determine the refrigerant in use, nor remember to set a selector switch. Furthermore, when searching for HFCs, the instrument does not have an exaggerated response to traces of chlorine-bearing vapors which are frequently present.

## SPECIFICATIONS

Base unit includes	Sensor, 2 D-size alkaline batteries, spare filters, and a hard plastic carrying case.
Sensitivity to CFCs, HCFCs, HFCs	0.4 oz/yr. (11 g/yr.)
Controls	3-position slide switch— off, low sensitivity, high sensitivity
Power	2 D-size (1.5-volt) alkaline batteries
Contamination adjustment	Automatic
Weight with batteries	1.54 lb (700 g)
Operating temperature range	-20°F to +122°F -27°C to +50°C
Probe	Chrome-plated flexible metal. Approximate length: 17" (43 cm)
Sampling system	Positive displacement pump
Certifications	CE marking per Safety and EMC. SAE J1627
Warranty	2 years

## ACCESSORIES

TEK-Mate	705-202-G1
Sensor	703-020-G1
Filter kit	705-600-G1
Storage case	705-401-P2



### GLOBAL HEADQUARTERS:

Two Technology Place, East Syracuse, NY 13057 USA  
Tel: +315.434.1100 Fax: +315.437.3803 E-mail: reachus@inficon.com

D-TEK and GAS-Mate are trademarks of INFICON Inc. TEK-Mate is a registered trademark of INFICON Inc.  
Due to INFICON's continuing program of product improvements, specifications are subject to change without notice.  
Visit our website for contact information and other sales offices worldwide. [www.inficon.com](http://www.inficon.com)

ELBA66A1 (0007)STL ©2000 INFICON Inc.