

# Wey-TEK® Pro

## REFRIGERANT CHARGING SCALE

### For all jobs, big and small

Wey-TEK Pro is truly a do-it-all scale. A large, 275 lb. (125 kg) capacity platform allows you to easily weigh large tanks, while its 0.1 oz (3 g) display resolution and optional small charge adapter kit allows you to accurately weigh small, critical charges. Wey-TEK Pro features an intuitive wired handpiece with a bright, backlit display for ease of operation. For cordless use, simply download the free Wey-TEK Pro app and connect your mobile device via Bluetooth®.



#### ADVANTAGES

- 275 lb. (125 kg) capacity platform designed to fit all tank sizes
- Wired handpiece with bright, backlit LCD display
- Bluetooth connectivity with free mobile app
- 0.1 oz (3 g) resolution for critical charging of all refrigerants including A3 flammables
- Compatible with small charge adapter kit (PN 501-601-G1) for mounting A3 refrigerant bottles



## SPECIFICATIONS

|                                        |                                                                                      |
|----------------------------------------|--------------------------------------------------------------------------------------|
| <b>Includes</b>                        | Wey-TEK Pro<br>Magnetic handpiece strap<br>3 AA batteries installed<br>Carrying case |
| <b>Weighing capacity</b>               | 275 lb. (125 kg)                                                                     |
| <b>Accuracy</b>                        | ±0.06% of reading or ± 3 g (whichever is greater)                                    |
| <b>Display resolution</b>              | 0.1 oz (3 g)                                                                         |
| <b>Display type</b>                    | Backlit full color LCD                                                               |
| <b>Display units</b>                   | lb, oz, lb/oz, kg, g                                                                 |
| <b>Power source</b>                    | 3 AA batteries                                                                       |
| <b>Battery life</b>                    | Up to 150 hours (depending on dimming settings)                                      |
| <b>Weight (including batteries)</b>    | 6.35 lb. (2880 g)                                                                    |
| <b>Platform dimensions (W x L x H)</b> | 11.0 x 11.0 x 1.5 in. (28.0 x 28.0 x 3.7 cm)<br>13.25 in. (33.5 cm) diagonal         |
| <b>Certifications</b>                  | A2L Certified, CE, UKCA                                                              |
| <b>Warranty</b>                        | Two-year, over-the-counter                                                           |

## ORDERING INFORMATION

|             |            |
|-------------|------------|
| Wey-TEK Pro | 501-202-G1 |
|-------------|------------|

**Accessories and Replacement Parts**

|                          |            |
|--------------------------|------------|
| Small charge adapter kit | 501-601-G1 |
| Magnetic handpiece strap | 501-311-P1 |
| Replacement battery door | 501-308-P1 |
| Carrying case            | 501-700-G1 |



Shown with small charge adapter kit for mounting A3 refrigerant bottles (PN 501-601-G1, SOLD SEPARATELY)