

Inspection Documents Service

Vacuum Control

INFICON offers a inspection documents service for Vacuum Control products.

All issued inspection documents are in compliance with the European Standard EN 10204

ADVANTAGES

- Choice of three different inspection documents for customers individual needs
- Inspection documents according to European Standard EN 10204

ORDERING INFORMATION

Designation of Inspection Document	Type	Ordering Number
Declaration of compliance with the order (Werksbescheinigung 2.1)	EN 10204-2.1	211-801
Test report (Werkszeugnis 2.2)	EN 10204-2.2	211-802
Inspection certificate (Abnahmeprüfzeugnis 3.1)	EN 10204-3.1	211-800

Please check with the given information in the following chart the right inspection document for your specific needs and order your choice of inspection document together with the corresponding Vacuum Control product you need it for.

The inspection document will be issued and delivered together with your goods and / or can be sent as pdf file for your attention. For pricing or specific questions concerning inspection documents please call our customer service center.

INSPECTION DOCUMENTS

	EN 10204-2.1	EN 10204-2.2	EN 10204-3.1
Inspection document	Declaration of compliance with the order	Test report	Inspection certificate
Kind of inspection	Non-specific inspection The products inspected are not necessarily the products actually supplied	Non-specific inspection The products inspected are not necessarily the products actually supplied	Specific inspection The products inspected are the products, or part of the products, actually supplied
Contents of inspection document	Manufacturer's declaration that the products supplied are in compliance with the requirements of the order, without inclusion of test results	Manufacturer's declaration that the products supplied are in compliance with the requirements of the order, with test results based on non-specific inspection	Manufacturer's declaration that the products supplied are in compliance with the requirements of the order, with test results based on specific inspection
Conditions of delivery	In accordance with conditions of order	In accordance with conditions of order	According to regulations of authorities and the corresponding technical rules
Inspection document confirmed by	The manufacturer	The manufacturer	The manufacturer's authorized inspection representative, independent of the manufacturing department
Example for ordering at INFICON	Add ordering number 211-801 to your order in a separate order position directly after the order position of the corresponding parts you like to have the declaration of compliance for	Add ordering number 211-802 to your order in a separate order position directly after the order position of the corresponding parts you like to have the test report for	Add ordering number 211-800 to your order in a separate order position directly after the order position of the corresponding parts you like to have the certificate for
Notes by INFICON	If this declaration is needed for all of your purchase order items you simply can add the ordering number 211-801 at the end of your order in the last position and state that it should be valid for the whole order	The test report just can be issued to a specific part number you have ordered. It can't be valid for multiple part numbers. It should be ordered along with the corresponding product it belongs to (add ordering number 211-802 directly after the product it belongs to)	This certificate just can be issued to a specific part number you have ordered. It can't be valid for multiple part numbers. It strictly has to be ordered along with the corresponding product it belongs to (add ordering number 211-800 directly after the product it belongs to) The original certificate always comes along with the corresponding product it belongs to. On customer request we can send it in addition to our shipment as pdf file by email or by post (copies)
Inspection document available for	All INFICON Vacuum Control products	All INFICON Vacuum Control products	Majority of our vacuum fittings (usually this certificate is asked for fittings made of stainless steel and aluminium and their specific chemical composition) Other Vacuum Control products on request and according feasibility. Please define in your request values you like to have tested and confirmed Standard prices apply for this type of certificate, however we reserve the right to apply further charges for any additional work that maybe required