

Leak Detection Pro Kit

Get even more out of your leak detector.

A kit built to maximize capability and performance.

Designed to help you leak check like a pro, this kit comes with a needle probe, rubber I-Tip, brush I-Tip XL, spare filters and extra rubber refills. Use the needle probe to diagnose problems in unique applications like VRF and other systems that have hard-to-access refrigerant lines, and even check for leaks on insulated lines without removing insulation. For windy or drafty conditions, attach I-Tip or I-Tip XL to the end of the probe to contain the refrigerant sample and find leaks in any environment.



Leak Detection Pro Kit 724-712-G1

SPECIFICATIONS

Includes	Needle probe extension I-Tip I-Tip XL Rubber refills Filter cartridges
Compatible Leak Detectors	D-TEK 3, D-TEK Stratus, D-TEK Pro, D-TEK Select

ORDERING INFORMATION

Leak Detection Pro Kit	724-712-G1
Needle Probe Extension	721-612-G1
Rubber Refills	724-713-G1
Filter Cartridges	712-707-G1



I-Tip XL



I-Tip



Needle Probe Extension 721-612-G1