

# Compass<sup>®</sup>

## REFRIGERANT LEAK DETECTOR

### Locate the leak with proven sensor technology.

Compass takes the proven heated diode sensor of TEK-Mate and adds premium features like a rubber hand grip and rechargeable battery. Get improved sensitivity from the probe tip-mounted sensor. Compass can even be operated while charging with the included car and wall chargers.



### ADVANTAGES

- Sensitivity of 0.15 oz./year (4 g/year)
- Detects all CFCs, HCFCs, HFCs, and HFOs
- Proven heated diode sensor for reliable leak checking
- No false alarms from soap solutions
- Runs on rechargeable battery or AC adapter
- Advanced filter keeps out water, dirt, and oil
- Rugged carrying case included

### SPECIFICATIONS

Includes	Compass Heated diode sensor NiMH rechargeable battery Spare filters AC wall charger DC car charger Carrying case
Compatible refrigerants	R22, R32, R134a, R404a, R407c, R410a, R422b, R448a, R449a, R452a, R452b, R507 (AZ50), R1234yf/ze and more
Minimum sensitivity	0.15 oz./yr. (4 g/a)
Power source	NiMH battery (rechargeable) Wall/car charger (can operate while charging)
Battery life	5.5 hours
Weight	1.15 lb. (522 g)
Certifications	A2L certified CE
Probe length	15 in. (38 cm)
Warranty	Two-year over-the-counter

### ORDERING INFORMATION

Compass (115 V)	717-202-G1
-----------------	------------

#### Accessories and Replacement Parts

Headphones	032-0430
Premium headphones	032-0427
TEK-Check R134a reference leak	703-080-G10
115 V (ac) wall charger	033-0019-G1
12 V (dc) car charger	703-055-P1
NiMH battery	712-700-G1
Sensor	703-020-G1
Filters	717-701-G1
Carrying case	717-700-G1