## Compass®

## REFRIGERANT LEAK DETECTOR

## Locate the leak with proven sensor technology.

Compass takes the proven heated diode sensor of TEK-Mate and adds premium features like a rubber hand grip and rechargeable battery. Get improved sensitivity from the probe tip-mounted sensor. Compass can even be operated while charging with the included car and wall chargers.



## **ADVANTAGES**

- Sensitivity of 0.15 oz./year (4 g/year)
- Detects all CFCs, HCFCs, HFCs, and HFOs
- Proven heated diode sensor for reliable leak checking
- No false alarms from soap solutions
- Runs on rechargeable battery or AC adapter
- Advanced filter keeps out water, dirt, and oil
- Rugged carrying case included

SPECIFICATIONS	
Includes	Compass Heated diode sensor NiMH rechargeable battery Spare filters AC wall charger DC car charger Carrying case
Comp <mark>atible refrigerants</mark>	R22, R32, R134a, R404a, R407c, R410a, R422b, R448a, R449a, R452a, R452b, R507 (AZ50), R1234yf/ze and more
Minimum sensitivity	0.15 oz./yr. (4 g/a)
Power source	NiMH battery (rechargeable) Wall/car charger (can operate while charging)
Battery life	5.5 hours
Weight	1.15 lb. (522 g)
Certifications	A2L certified CE
Probe length	15 in. (38 cm)
Warranty	Two-year over-the-counter

Compass (115 V)	717-202-G1
Accessories and Replace	ement Parts
Headphones	032-0430
Premium headphones	032-0427
TEK-Check R134a reference leak	703-080-G10
115 V (ac) wall charger	033-0019-G1
12 V (dc) car charger	703-055-P1
NiMH battery	712-700-G1
Sensor	703-020-G1
Filters	717-701-G1
Carrying case	717-700-G1