

# Cygnus<sup>®</sup>2

Thin Film Deposition Controller

PN 074-545-P1H



#### **Trademarks**

The trademarks of the products mentioned in this Operating Manual are held by the companies that produce them.

CAJON® is a registered trademark of Swagelok, Co.

INFICON®, RateWatcher™, and Cygnus® are trademarks of INFICON GmbH.

Kingston® is a registered trademark of Kingston Technology Corporation.

Lexar® is a registered trademark of Lexar Media, Inc.

Memorex® is a U.S. registered trademark of Memtek Corporation.

SanDisk® is a registered trademark of SanDisk Corporation.

Windows<sup>®</sup>, Windows 95<sup>®</sup> and Microsoft<sup>®</sup> are registered trademarks of Microsoft Corporation.

All other brand and product names are trademarks or registered trademarks of their respective companies.

#### **Disclaimer**

The information contained in this Operating Manual is believed to be accurate and reliable. However, INFICON assumes no responsibility for its use and shall not be liable for any special, incidental, or consequential damages related to the use of this product.

Due to our continuing program of product improvements, specifications are subject to change without notice.

#### Copyright

©2017 All rights reserved.

Reproduction or adaptation of any part of this document without permission is unlawful.



# DECLARATION OF CONFORMITY

This is to certify that this equipment, designed and manufactured by:

# INFICON Inc. Two Technology Place East Syracuse, NY 13057 USA

Meets the essential safety requirements of the European Union and is placed on the market accordingly. It has been constructed in accordance with good engineering practice in safety matters in force in the Community and does not endanger the safety of persons, domestic animals or property when properly installed and maintained and used in applications for which it was made.

**Equipment Description:** IC6/Cygnus 2 Deposition Controller (including all options).

**Applicable Directives:** 2014/35/EU (LVD)

2014/30/EU (General EMC)

2011/65/EU (RoHS)

**Applicable Standards:** 

Safety: EN 61010-1: 2010 Safety Requirements for Electrical Equipment For

Measurement, Control, And Laboratory Use.

PART 1: General Requirements

Emissions: EN 61326-1: 2013 (Radiated & Conducted Emissions)

(EMC - Measurement, Control & Laboratory Equipment)

CISPR 11/EN 55011 Edition 2009-12 Emission standard for industrial.

scientific, and medical (ISM) radio RF equipment

FCC Part 18 Class A emissions requirement (USA)

Immunity: EN 61326-1: 2013 (Industrial EMC Environments)

(EMC – Measurement, Control & Laboratory Equipment)

RoHS2: Fully Compliant

CE Implementation Date: June 2010 (Revised August, 2015)

Authorized Representative: Steven Schil

Thin Film Business Line Manager

NEICON Inc

INFICON, Inc.

# Warranty

WARRANTY AND LIABILITY - LIMITATION: Seller warrants the products manufactured by it, or by an affiliated company and sold by it, and described on the reverse hereof, to be, for the period of warranty coverage specified below, free from defects of materials or workmanship under normal proper use and service. The period of warranty coverage is specified for the respective products in the respective Seller instruction manuals for those products but shall not be less than two (2) years from the date of shipment thereof by Seller. Seller's liability under this warranty is limited to such of the above products or parts thereof as are returned, transportation prepaid, to Seller's plant, not later than thirty (30) days after the expiration of the period of warranty coverage in respect thereof and are found by Seller's examination to have failed to function properly because of defective workmanship or materials and not because of improper installation or misuse and is limited to, at Seller's election, either (a) repairing and returning the product or part thereof, or (b) furnishing a replacement product or part thereof, transportation prepaid by Seller in either case. In the event Buyer discovers or learns that a product does not conform to warranty, Buyer shall immediately notify Seller in writing of such non-conformity, specifying in reasonable detail the nature of such non-conformity. If Seller is not provided with such written notification, Seller shall not be liable for any further damages which could have been avoided if Seller had been provided with immediate written notification.

THIS WARRANTY IS MADE AND ACCEPTED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, WHETHER OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, AS BUYER'S EXCLUSIVE REMEDY FOR ANY DEFECTS IN THE PRODUCTS TO BE SOLD HEREUNDER. All other obligations and liabilities of Seller, whether in contract or tort (including negligence) or otherwise, are expressly EXCLUDED. In no event shall Seller be liable for any costs, expenses or damages, whether direct or indirect, special, incidental, consequential, or other, on any claim of any defective product, in excess of the price paid by Buyer for the product plus return transportation charges prepaid.

No warranty is made by Seller of any Seller product which has been installed, used or operated contrary to Seller's written instruction manual or which has been subjected to misuse, negligence or accident or has been repaired or altered by anyone other than Seller or which has been used in a manner or for a purpose for which the Seller product was not designed nor against any defects due to plans or instructions supplied to Seller by or for Buyer.

This manual is intended for private use by INFICON® Inc. and its customers. Contact INFICON before reproducing its contents.

NOTE: These instructions do not provide for every contingency that may arise in connection with the installation, operation or maintenance of this equipment. Should you require further assistance, please contact INFICON.





**Cover Page** 

#### Table Of Contents

**Trademarks** Disclaimer Copyright **Declaration Of Conformity** Warranty Chapter 1 **Introduction and Specifications** 1.1 1.2 1.2.1 Definition of Notes, Cautions and Warnings.....1-2 1.2.2 1.2.3 1.2.4 1.3 1.3.1 Returning Your Cygnus 2......1-5 1.4 1.4.1 Screens and Hierarchy......1-6 1.4.2 1.4.3 1.4.3.1 1.4.3.2 Source Parameters......1-7 1.4.3.3 1.4.3.4 1.4.3.5 1.4.4 1.4.5 1.4.6 1.4.7 1.4.8 1.4.9 1.4.10 1.4.11 Operating Environment......1-15 1.4.12 1.4.13 



1.4.14	Size	1-15
1.4.15	Installation Clearance Requirements	1-15
1.4.15.1	Connector Clearances:	1-15
1.4.15.2	Cooling Clearances:	1-15
1.4.16	Weight	1-16
1.4.17	Cleaning	1-16
1.5	Unpacking and Inspection	1-16
1.6	Parts and Options Overview	1-16
1.6.1	Base Configurations	1-16
1.6.2	Pre-installed Options or Spares	1-17
1.6.3	Optional Accessories	1-17
1.6.4	Oscillator Packages	1-17
1.6.5	Sensors	
1.6.6	Replacement Cables	1-18
1.7	Initial Power-On Verification	1-19
Chapter 2		
	Installation and Interfaces	
2.1	Location Guidelines	. 2-1
2.1.1	Sensor Types	. 2-1
2.1.2	Sensor Installation	. 2-1
2.1.3	Cygnus 2 Installation	. 2-4
2.2	Avoiding Electrical Interference	. 2-4
2.2.1	Verifying/Establishing Earth Ground	. 2-4
2.2.2	Connections to Earth Ground	. 2-5
2.2.3	Minimizing Noise Pickup from External Cabling	. 2-6
2.3	Connecting the Controller	. 2-7
2.3.1	Routing XIU Cables	. 2-7
2.3.2	Interface Cable Fabrication and Pin-Out	. 2-7
2.3.2.1	Source Control Connection	. 2-8
2.3.2.2	Crucible Indexer Connections	. 2-8
2.3.2.3	DAC Option Kit	. 2-8
2.3.2.4	I/O Expansion Options	. 2-9
2.3.2.5	RS-232C Communications	2-11
2.3.2.6	Isolated +24 V (dc) Supply	2-12
Chapter 3		
Shapter 3	Operation	
3.1	Front Panel Controls	. 3-1
3.2	Rear Panel Interfaces.	
0.2		



3.3	Displays	3-5
3.3.1	Main Menu Display	3-5
3.3.2	Operate	3-6
3.3.3	Sensor Information	3-8
3.3.3.1	Sensor Information Rate/Xtal Display Description	3-8
3.3.3.2	Crystal Life and Starting Frequency	3-10
3.3.3.3	Function Key Selection Choices	3-10
3.3.3.4	Sensor Information Type/Freq Display Description	3-11
3.3.3.4.1	TEST XIU	3-12
3.3.4	Sensor Screen	3-13
3.3.5	Source	3-14
3.3.6	Material	3-15
3.3.6.1	Overview Page	3-15
3.3.6.2	Source Page	3-15
3.3.6.3	Sensor Page	3-16
3.3.6.4	Pre/Post Page	3-16
3.3.6.5	Deposit Page	3-16
3.3.6.6	Lib A-Hf, Lib Hf-Sc, Lib Sc-Z Sub-Displays	3-17
3.3.7	General	3-17
3.3.7.1	Process Page	3-17
3.3.7.2	DACs Page	3-17
3.3.7.3	Comm Page	3-18
3.3.7.4	Message Page	3-18
3.3.7.5	Date/Time Page	3-18
3.3.7.6	Test Page	3-18
3.3.7.7	Lock Page	3-18
3.3.7.8	Audio/Visual Page	3-18
3.3.8	Digital I/O	3-19
3.3.9	Logic	3-20
3.3.10	Maintenance	3-20
3.3.11	Counter / Timer	3-20
3.3.12	USB Storage	3-20
3.3.13	Programming Guidelines	3-20
3.4	State Descriptions	3-23
3.5	Special Features	3-25
3.5.1	Crystal Switching	
3.5.1.1	XtalTwo (CrystalTwo)	
3.5.1.2	XtalSix (CrystalSix)	3-27
3.5.1.3	Xtal12 (Crystal12)	3-27



3.5.1.4	Generic Sensor Crystal Switching	3-28
3.5.2	Source/Crucible Selection	3-28
3.5.2.1	Example: Programming Turret Source Crucible Selection	3-28
3.5.3	Auto-Z	3-29
3.5.4	Rate Watcher	3-31
3.5.5	Handheld Controller	3-31
3.5.5.1	Determining Soak Power with the Handheld Controller	3-32
3.5.6	Test Mode	3-32
3.5.6.1	Standard or Time Compressed	3-32
3.5.6.2	Advanced Test	3-32
3.5.7	USB Storage Device	3-33
3.5.8	Lock and Access Codes	3-34
3.5.9	Datalog	3-35
3.5.9.1	Datalog contents:	3-36
3.5.9.2	Page Format ASCII Example:	3-38
3.5.9.3	Comma Format ASCII Example to USB Storage Device:	3-39
3.5.10	DAC Monitoring	
3.5.11	Trend Analysis	3-40
3.5.11.1	Cygnus 2 Parameters Associated with the Trend Analysis Feature .	3-40
01 4 4		
Chapter 4	Songer and Source Set Un	
•	Sensor and Source Set-Up	4 1
4.1	Sensor Set-Up Introduction	
4.1 4.1.1	Sensor Set-Up Introduction	4-1
4.1 4.1.1 4.1.2	Sensor Set-Up Introduction	4-1
4.1 4.1.1 4.1.2 4.2	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction	4-1
4.1 4.1.1 4.1.2 4.2 4.2.1	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation	4-1 4-2 4-4
4.1 4.1.1 4.1.2 4.2	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters	4-1 4-2 4-4 4-5
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation	4-1 4-2 4-4 4-5
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules	4-1 4-2 4-4 4-5
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3 <b>Chapter 5</b>	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules  Material Set-Up	4-14-24-44-5
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3 <b>Chapter 5</b>	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules  Material Set-Up Introduction.	4-14-24-44-54-7
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3 <b>Chapter 5</b> 5.1 5.1.1	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules  Material Set-Up Introduction. Material Overview Page	4-14-44-54-7
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3 Chapter 5  5.1 5.1.1 5.1.2	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules  Material Set-Up Introduction. Material Overview Page Material Definition.	4-14-24-44-54-7
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3 <b>Chapter 5</b> 5.1 5.1.1 5.1.2 5.1.3	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules  Material Set-Up Introduction. Material Overview Page Material Definition. Material Source Page Parameters	4-14-24-44-55-15-25-3
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3 <b>Chapter 5</b> 5.1 5.1.1 5.1.2 5.1.3 5.1.4	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules  Material Set-Up Introduction. Material Overview Page Material Definition. Material Source Page Parameters Material Sensor Parameters Page	4-14-24-44-55-15-25-7
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3 <b>Chapter 5</b> 5.1 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules  Material Set-Up Introduction. Material Overview Page Material Definition. Material Source Page Parameters Material Sensor Parameters Page Pre/Post Screen Deposit Page Parameters	4-14-24-44-55-15-15-35-10
4.1 4.1.1 4.1.2 4.2 4.2.1 4.2.2 4.3 <b>Chapter 5</b> 5.1 5.1.1 5.1.2 5.1.3 5.1.4	Sensor Set-Up Introduction Sensor Display Navigation Sensor Parameters Source Set-Up Introduction Source Navigation Source Parameters DAC Output Selection Rules  Material Set-Up Introduction. Material Overview Page Material Definition. Material Source Page Parameters Material Sensor Parameters Page	4-14-24-44-55-15-75-75-10



5.2	Special Material Parameter Features5-17
5.2.1	Skip Deposit
5.2.2	RateWatcher™ Sample and Hold Feature
Chapter 6	
	General Parameters
6.1	General Set-Up Overview
6.2	General Process Page
6.3	DACs Page Parameters
6.4	COMM Page Parameters
6.5	MESSAGE Page Set-up6-5
6.6	DATE / TIME Set Up6-6
6.7	TEST Page Set Up6-7
6.8	LOCK Page Code Set-up
6.9	AUDIO / VISUAL Page Set Up6-9
Chapter 7	
	Digital I/O
7.1	Digital I/O Screen
7.2	All Input Page
7.3	All Output Page
7.4	I/O Board Page
7.4.1	Output Type
Chapter 8	
	Logic Statement Set-Up
8.1	Logic Statement Overview
8.2	Editing the Logic Statements
8.2.1	Logic Statement Groups
8.2.2	Logic Statement Editing
8.2.3	AND/OR and ON Logic Connectors
8.2.3.1	ON Operator
8.3	IF Event Definitions
8.4	THEN Action Definitions
8.5	Logic Statement Example
Chapter 9	Damata Oammuulaatiara
<u> </u>	Remote Communications
9.1	Remote Communication Configuration Overview9-1
9.2	Physical Connections
9.2.1	RS-232C Serial Port9-1



9.2.2	TCP/IP Ethernet Port	9-2
9.2.2.1	Network Connection	9-2
9.2.2.2	How to Set Up the Network Protocol on the PC	9-2
9.3	Message Format	
9.3.1	Protocol	9-5
9.3.1.1	Command Packet (Host to Cygnus 2 Message)	9-5
9.3.1.2	Data Type Codes	9-7
9.3.1.3	Response Packet (Cygnus 2 to Host Message)	
9.3.1.4	Timeouts	
9.4	Communication Commands	9-10
9.4.1	Query and Update Commands	
9.4.2	Status Commands	9-11
9.4.3	HELLO Command	9-11
9.4.4	Query General Parameter	9-11
9.4.5	Update General Parameter	9-12
9.4.6	Query Material Parameter	9-17
9.4.7	Update Material Parameter	9-17
9.4.8	Query Sensor Parameter	9-22
9.4.9	Update Sensor Parameter	9-22
9.4.10	Query Source Parameter	9-23
9.4.11	Update Source Parameter	9-23
9.4.12	Query Process Material Parameter	9-25
9.4.13	Update Process Material Parameter	9-25
9.4.14	Query Material Name	9-26
9.4.15	Update Material Name	9-26
9.4.16	Query Input Name	9-26
9.4.17	Update Input Name	9-26
9.4.18	Query Output Name	9-26
9.4.19	Update Output Name	
9.4.20	Query Output Type	
9.4.21	Update Output Type	
9.4.22	Query User Message	
9.4.23	Update User Message	
9.4.24	Query Logic Statement	
9.4.25	Update Logic Statement	
9.4.26	Cygnus 2 Event List	
9.4.27	Cygnus 2 Action List	
9.4.28	Status General	
9.4.29	Status Material	9-39



9.4.30	Status Sensor	9-41
9.4.31	Remote General Action	9-43
9.4.32	Remote Material Action	9-46
9.4.33	Cygnus 2 Communications Examples	9-48
9.4.33.1	General Command Packet Format	9-48
9.4.33.2	General Response Packet Format	9-48
9.4.33.3	HELLO Command, ASCII name and version	9-48
9.4.33.4	Query Material Parameter, Z-Ratio (2), Material 1	9-49
9.4.33.5	Update Material Parameter, Control Loop (4), Material 1, PID (2)	9-49
9.4.33.6	Query Sensor Parameter, Shutter Output (1), Sensor 1	9-49
9.4.33.7	Update Sensor Parameter, Sensor Type (2), Sensor 1, CrystalTwo (1)	9-49
9.4.33.8	Query Source Parameter, Shutter Output (2), Source 1	9-49
9.4.33.9	Update Source Parameter, Number of crucibles (3), Source 1, 4 crucible 9-49	es (1)
9.4.33.10	Query Material Name, Material 1	9-50
9.4.33.11	Update Material Name, Material 1, "SILVER"	9-50
9.4.33.12	Query Input Name, Input 1	9-50
9.4.33.13	Update Input Name, Input 1, "P1"	9-50
9.4.33.14	Query Output Name, Output 1	9-50
9.4.33.15	Update Output Name, Output 1, "SHUTTER"	9-50
9.4.33.16	Query Output Type, Output 1	9-51
9.4.33.17	Update Output Type, Output 1, Normally Closed (1)	9-51
9.4.33.18	Query User Message, Message 1	9-51
9.4.33.19	Update User Message, Message 1, "HELLO!"	9-51
9.4.33.20	Query Logic Statement, Statement 1	
9.4.33.21	Update Logic statement, Statement 1, "IF External Input 1 THEN Start	1" 9-52
9.4.33.22	Status Material, Thickness (4), Material 1	9-53
9.4.33.23	Status Sensor, Crystal Life (0), Sensor 1	9-53
9.4.33.24	Remote General Action, Stop All	9-53
9.4.33.25	Remote Material Action, Open Source Shutter (8)	9-53
9.4.33.26	Example for Interpreting Float Responses	
Chapter 10		
	Maintenance and Calibration Procedures	
10.1	Importance of Density, Tooling and Z-Ratio	
10.2	Determining Density	
10.3	Determining Tooling	
10.4	Laboratory Determination of Z-Ratio	
10.5	Source Maintenance	10-5



10.5.1	Source Maintenance Parameters	
10.5.1.1	Crucible Rotation	
10.5.1.2	Toggle Sensor and Source Shutter	
10.5.1.3	Start/Stop Manual Power	10-6
10.6	System Status	10-7
Chapter 11		
	Counters and Timers	
11.1	Introduction	11-1
Chapter 12		
	USB Storage	
12.1	File Handling (USB)	
12.1.1	USB Storage Devices	
12.2	Directory Structure	
12.3	Configuration Files	
12.4	Data Logs	
12.5	Screen Captures	12-4
Chapter 13		
	Troubleshooting, Status and Error Messages	
13.1	Status Messages	
13.2	User Messages	
13.3	STOP messages	
13.4	Transient Messages	
13.5	Input Error Messages	
13.6	Troubleshooting Guide	
13.6.1	Troubleshooting Cygnus 2	. 13-12
13.6.2	Troubleshooting Transducers/Sensors	
13.6.3	Troubleshooting Computer Communications	
13.7	Replacing the Crystal	. 13-20
13.7.1	Front Load	. 13-20
13.7.2	Cool Drawer	. 13-21
13.7.3	Shuttered and Dual Sensors	. 13-23
13.7.4	Bakeable Sensor	. 13-23
13.7.5	Sputtering Sensor	. 13-24
13.7.6	Crystal Snatcher	. 13-25
13.7.7	CrystalSix (XtalSix)	. 13-25
13.8	Crystal Sensor Emulator IPN 760-601-G1 or 760-601-G2	13 26
13.8.1	Diagnostic Procedures	
13.0.1	Diagnosiic Flocedules	. 10-21



13.8.1.1	Measurement System Diagnostic Procedure
13.8.1.2	Feedthrough Or In-Vacuum Cable
	Diagnostic Procedure
13.8.1.3	Sensor Head Or Monitor Crystal
	Diagnostic Procedure
13.8.1.4	System Diagnostics Pass But
	Crystal Fail Message Remains13-30
13.8.2	% XTAL Life
13.8.3	Sensor Cover Connection
13.8.3.1	Compatible Sensor Heads
13.8.3.2	Incompatible Sensor Heads
13.8.4	Specifications
Chapter 14	
	Measurement and Control Theory
14.1	Basics14-1
14.1.1	Monitor Crystals
14.1.2	Period Measurement Technique14-4
14.1.3	Z-match Technique14-5
14.1.4	Active Oscillator
14.1.5	ModeLock Oscillator14-7
14.1.6	Auto-Z Theory14-9
14.1.7	Control Loop Theory14-11
Appendix A	
	Material Table
A.1	Introduction
Index	



# Chapter 1 Introduction and Specifications

#### 1.1 Introduction

Cygnus 2 is a closed loop process controller designed for use primarily in physical vapor deposition. Cygnus 2 monitors and/or controls the rate and thickness of the deposition of thin films. Deposition rate and thickness are inferred from the frequency change induced by mass added to a quartz crystal. This technique positions sensors in the path between or to the side of the source of the vaporized material and the target substrate. The sensor incorporates an exposed oscillating quartz crystal whose frequency decreases as material accumulates. The change in frequency provides information to determine rate and thickness and to continually control the evaporation power source. With user programmed time, thickness and power limits and with desired rates and material characteristics, Cygnus 2 is capable of automatically controlling the process in a precise and repeatable manner. User interaction is accomplished via Cygnus 2 front panel or remote communication and consists of selection or entry of parameters to define the process.

A complete system consists of a main electronics unit also called Cygnus 2, sensor heads and a crystal interface unit (XIU) for each attached sensor. These items are generally bundled at the factory and are also sold separately.

This Cygnus 2 Operating Manual provides user information for installing, programming and operating the main electronics unit.

When reading Cygnus 2 Operating Manual, please pay particular attention to the Notes, Cautions, and Warnings found throughout the text. The Notes, Cautions, and Warnings are defined in section 1.2.1 on page 1-2.

You are invited to comment on the usefulness and accuracy of this manual by visiting our website at www.inficon.com.



### 1.2 Cygnus 2 Safety

#### 1.2.1 Definition of Notes, Cautions and Warnings

When using this manual, please pay attention to the Notes, Cautions, and Warnings found throughout. For the purposes of this manual they are defined as follows:

**NOTE:** Pertinent information that is useful in achieving maximum Cygnus 2 efficiency when followed.



#### **CAUTION**

Failure to heed these messages could result in damage to Cygnus 2.



#### WARNING

Failure to heed these messages could result in personal injury.



#### **WARNING - Risk Of Electric Shock**

Dangerous voltages are present which could result in personal injury.



#### 1.2.2 General Safety Information



#### WARNING - Risk Of Electric Shock

Do not open the Cygnus 2 case! There are no user-serviceable components within the Cygnus 2 case. Dangerous voltages may be present whenever the power cord or external input/relay connectors are present. Refer all maintenance to qualified personnel.



#### CAUTION

Cygnus 2 contains delicate circuitry which is susceptible to transient power line voltages. Disconnect the line cord whenever making any interface connections. Refer all maintenance to qualified personnel.

#### 1.2.3 Earth Ground

Cygnus 2 is connected to earth ground through a sealed three-core (three-conductor) power cable, which must be plugged into a socket outlet with a protective earth terminal. Extension cables must always have three conductors including a protective earth terminal.



#### **WARNING - Risk Of Electric Shock**

Never interrupt the protective earth circuit.

Any interruption of the protective earth circuit inside or outside Cygnus 2, or disconnection of the protective earth terminal is likely to make Cygnus 2 dangerous.



This symbol indicates where the protective earth ground is connected inside Cygnus 2. Never unscrew or loosen this connection.



#### 1.2.4 Main Power Connection



#### **WARNING - Risk Of Electric Shock**

This Cygnus 2 has line voltage present on the primary circuits whenever it is plugged into a main power source.

Never remove the covers from Cygnus 2 during normal operation.

There are no operator-serviceable items within Cygnus 2.

Removal of the top or bottom covers must be done only by a technically qualified person.

In order to comply with accepted safety standards, Cygnus 2 must be installed into a rack system which contains a mains switch. This switch must break both sides of the line when it is open and it must not disconnect the safety ground.



#### 1.3 How To Contact INFICON

Worldwide customer support information is available under Support at www.inficon.com where you can contact:

- a Technical Support Engineer with questions regarding applications for and programming Cygnus 2.
- a Service Engineer with questions regarding troubleshooting, diagnosing or repairing a defective Cygnus 2.
- Sales and Customer Service, to find the INFICON Sales office nearest to you.
- Repair Service, to find the INFICON Service Center nearest to you.

If you are experiencing a problem with your Cygnus 2, please have the following information readily available:

- the serial number and firmware version for your Cygnus 2,
- a description of your problem,
- an explanation of any corrective action that you may have already attempted,
- and the exact wording of any error messages that you may have received.

#### 1.3.1 Returning Your Cygnus 2

Do not return any component of your Cygnus 2 to INFICON without first speaking with a Customer Support Representative. You must obtain a Return Material Authorization (RMA) number from the Customer Support Representative.

If you deliver a package to INFICON without an RMA number, your package will be held and you will be contacted. This will result in delays in servicing your Cygnus 2.

Prior to being given an RMA number, you may be required to complete a Declaration Of Contamination (DOC) form if your sensor has been exposed to process materials. DOC forms must be approved by INFICON before an RMA number is issued. INFICON may require that the sensor be sent to a designated decontamination facility, not to the factory.



# 1.4 Cygnus 2 Specifications

#### 1.4.1 Measurement

Crystal Frequency . . . . . . . . . . . . . 6.0 MHz (new crystal) to 4.5 MHz

Internal Precision . . . . . . . . . . . . . . . . . . ±0.0035 Hz over 100 ms sample for

fundamental and anharmonic

frequencies

Thickness & Rate Resolution . . . . . . . . 0.0042 Å (new crystal);

0.0076 Å (crystal @ 4.5 MHz) over 100 ms sample for material density =

1.0,

Z-Ratio = 1.0

Thickness Accuracy . . . . . . . . . . . . . 0.5% typical, (dependent on process

conditions, especially sensor

location, material stress, temperature

and density)

Frequency Accuracy.....±2 ppm 0-50°C

Measurement Frequency . . . . . . . . . . . . . . . . . 10 Hz

Measurement Technique . . . . . . . . . . ModeLock with Auto-Z

User Interface......LCD and limited membrane keypad.

All parameters accessible through computer communications. Multiple message areas for indication of states and detailed indication of abnormal and stop conditions.

### 1.4.2 Screens and Hierarchy

a) Navigation . . . . . . . . . . . . . . . . Menu driven, four soft keys

b) Structure..... Separate screens dedicated to

1) Operate

2) Sensor Information

3) Sensor Parameters

4) Source Parameters

5) Material Parameters

6) General Parameters

7) Digital I/O Display

8) Logic

9) Maintenance

10) Counter/Timer

11) USB Storage



#### 1.4.3 Cygnus 2 Features

#### 1.4.3.1 Recipe Storage and Datalogging

**USB Memory Device** 

#### 1.4.3.2 Sensor Parameters

#### 1.4.3.3 Source Parameters

Turret Delay . . . . . . . . . . . . . . . . . . 2 to 180 s (Time-out period with feedback, delay time without

feedback)



#### 1.4.3.4 Material Parameters

6 Materials can be specified and given unique names (15 character max.). Control Loop types . . . . . . . . . . . . Non-PID, PI, PID Maximum Source Power . . . . . . . . . . . . 0.01 to 99.99% Minimum Source Power . . . . . . . . . . . . . 0.00 to 99.98% Maximum Power Option . . . . . . . . . . . Continue, Post-Dep(osition), Stop All, Stop Mat(erial)—can be selected for each Material individually Power Ramps......3 per Material Deposit After Pre-Deposit..... Yes / No Yes = go to Deposit No = go to Non-Deposit Rate Control (Control) Delay Option . . . . . . . . . . None, Shutter, Control, Both Shutter Delay Accur(acy) . . . . . . . . . . . . 1 to 99% Idle Ramp......1 per Source 



Time Limit (in Deposit) . . . . . . . . . . . . . . . . . . 00:00 to 99:59 min:s Time Power Averaging Time . . . . . . . . . 0 to 30 minutes Ion Assist Deposit. . . . . . . . . . . . . Yes/No On Final Thickness. . . . . . . . . . . . . . . . Continue, Post-Dep(osit), NonDep(osit)Cont(rol) New Rate while in Deposit . . . . . . . . . . . 2 Rate Ramps per Material New Rate 1 or 2 . . . . . . . . . . . . . 0.000 to 999.9 Å/s Start Ramp 1 or 2...................... 0.000 to 999.9 kÅ RateWatcher® ...... Sample and Hold Feature (RateWatcher) Option. . . . . . . . . . Yes/No (RateWatcher) Time . . . . . . . . . . . . . . . . 00:00 to 99:59 min:s (RateWatcher) Accuracy. . . . . . . . . . 1 to 99% TimeP(o)w(er) CrystalTwo Tooling . . . . . . . . . . . . . . . . . . 1.0 to 999.9% CrystalSix (XtalSix) and Crystal12 (Xtal12) sensor selections to specify a subset of available crystal positions: Xtal Position First . . . . . . . . . . . . 0 to 6 (XtalSix) or 12 (Xtal12) Xtal Position Last . . . . . . . . . . . . 0 to 6 (XtalSix) or 12 (Xtal12) (Crystal) Quality Percent . . . . . . . . . . 0 to 99% (Crystal) Quality Counts . . . . . . . . . . . . 0 to 99 (Crystal) Stability Single . . . . . . . . . . . 0 to 9999 Hz (Crystal) Stability Total . . . . . . . . . . . . 0 to 9999 Hz Recorder Output. . . . . . . . . . . . . . . . . . 0 to 12 Recorder Function . . . . . . . . . . . . . . Rate, Thick(ness), RateDev(iation), Power Final Thick(ness) . . . . . . . . . . . . . . . . 0.000 to 999.99 kÅ Thick(ness) Limit . . . . . . . . . . . . . . . . . . 0.000 to 999.99 kÅ 



#### 1.4.3.5 General Global Parameters

Date Format	. DDMMYYYY or MMDDYYYY
LCD Dimmer Time	. 0 for Always On or # of Minutes till Off 0 to 99 minutes
Graph Scale	. Power, ±0.1 Å/s, ±0.5 Å/s, ±1 Å/s, ±2 Å/s,±3 Å/s, ±5 Å/s, ±10 Å/s, ±20 Å/s, ±50 Å/s
Graph Scan Rate	. Auto, Slow, Medium, Fast
Test	. On / Off
Advanced Test	. On / Off
Time Compressed	. Yes / No
Audio Feedback	. Yes / No
RS232 Baud Rate	. 9600, 19200, 38400, 57600, 115200
RS232 Protocol	. Standard, D(ata)log Page, D(ata)log Comma
DataLog XTAL History	. Yes / No
USB Datalog Format	. Log Off (No datalogging), Page, Comma
Thickness Eq(uation) 1	. Up to 6 Source numbers can be specified, each Source number can be used only once in the equation.
Thickness Eq(uation) 2	. Up to 6 Source numbers can be specified, each Source number can be used only once in the equation.
Thickness Eq(uation) 3	. Up to 6 Source numbers can be specified, each Source number can be used only once in the equation.
DAC 1 to 12 Scale	. 0.1 to 10.0
DAC 1 to 12 Polarity	. Positive / Negative



#### 1.4.4 Display

Type/Color/Size . . . . . . . . . . . . . . LCD/Color/TFT/7 inch diagonal Dimming Feature . . . . . . . . . . . . . . Always Full on or Full on when in use. Full off when no process running and no key interaction for dimming time Backlighting . . . . . LED Thickness Display Range................ 0.000 to ±9999 kÅ Thickness Display Resolution . . . . . . . . 1 Å for 0.000 to ±9.999 kÅ, 10 Å for ±10.00 to ±99.99 kÅ 100Å for ±100.0 to ±999.9 kÅ Rate Display Range . . . . . . . . . . . . . . . . 0.000 to ±999.9 Å/s ......0.01 Å/s for ±10.00 to ±99.99 Å/s  $0.1 \text{ Å/s for } \pm 100.0 \text{ to } \pm 999.9 \text{ Å/s}$ Power Display Range. . . . . . . . . . . . . . . 0.00 to 99.99% Graphic Display Functions . . . . . . . . . . Rate Deviation at ±0.1 Å/s, ±0.5 Å/s, ±1 Å/s, ±2 Å/s, ±3 Å/s, ±5 Å/s, ±10 Å/s, ±20 Å/s, or ±50 Å/s or Power at 0 to 100% Display Data Update Rate . . . . . . . . . 1 Hz



#### 1.4.5 DAC Outputs

Quantity and Type ...... 6 with BNC, 6 optional with 15 pin miniature D-sub providing analog outputs for Rate and Thickness. Configuration . . . . . . . . . . . . . . . . . User programmable for recorder or Source control. Function and Ranges . . . . . . . . . . . Power, Rate, Rate Deviation, Thickness Full scale voltage value fully selectable up to + or - 10 V relative to 0 V at 0 output Current rating . . . . . . . . . . . . . . . . . . 20 mA per channel source characteristics). Recorder Output Functions . . . . . . . . . Rate, Thickness, Rate Deviation, or Source Power. Recorder Output Ranges Rate ...... 0 to up to 99999 Å/s programmable Thickness . . . . . . . . . . . . . . . . . 0 to up to 99999 Å programmable, [Function modulo (Thickness Range, Thickness)output is "saw-tooth" like with increasing thickness.] Rate Deviation . . . . . . . . . . . . . . Desired rate ±50 Å/s Accuracy.....±1%



#### 1.4.6 Logic Processing

#### 1.4.7 Relays / Inputs

Relays ..... SPST 2.5 A relays rated @ 30 V (dc) 30 V (ac) RMS or 42 V (peak) maximum; (8 standard, up to 16 optional with 2 additional I/O cards); D sub connector; relays are normally open in the power off state, but may be programmed to normally open or normally closed during operation. # of TTL Compatible Outputs . . . . . . . . . . . . . . . . . 14 with optional I/O card. Internally pulled up to 5 V (dc). May be pulled up externally to 24 V (dc) through 2.4 k resistor. minimum high level 0.5 mA load @3.75 V maximum low level 10 mA load @1.1 Inputs (TTL Compatible). . . . . . . . . . . . . . . (14 standard, 14 additional optional)



Input Levels

maximum high ......24 V

minimum high . . . . . . . . . . . . . . . . . . 2.5 V

maximum low . . . . . . . . . . . . . . . . . . 1.1 V

Input/Output Name . . . . . . . . . . . . . . . Those that are Non-Hardware

reserved may be named. (15

character max.)

#### 1.4.8 Remote Communications

RS232C Serial Port . . . . . . . . . Standard; INFICON binary protocol

9,600

Ethernet . . . . . . Optional, Programmable IP Address

and Net Mask

USB port.....Print screen bitmap (.bmp) files,

Datalogging file, Configuration file

store/retrieve

#### 1.4.9 Accessories

Connector Kit . . . . . . . . . . . . . . . . Connectors for inputs and relays

Operating Manual......074-5000-G1 CD-ROM

#### 1.4.10 Power

50/60 Hz ±3 Hz

Maximum apparent power . . . . . . . . . . . . . 150 VA

Temporary Overvoltages . . . . . . . . . . . . Short Term: 1430 V, <5 s

Long Term: 480 V, >5 s



#### 1.4.11 Operating Environment

Usage..... Indoor only

Temperature . . . . . . . . . . . . . . . . . . 0 to 50°C (32-122°F)

Installation (Overvoltage) . . . . . . . . . Category II per IEC 60664

#### 1.4.12 Storage Temperature

Storage Temperature . . . . . . . . . . . . -10 to 60°C (14 to 140°F)

#### 1.4.13 Warm Up Period

Warm Up Period......None required;

For maximum stability allow 5

minutes.

#### 1.4.14 Size

Not including mounts or user connectors

5.25 in. H x 17.625 in. W x 13 in. D (133.4 mm H x 447.7 mm W x 330 mm D)

Including mounts, but no user connectors

5.25 in. H x 19 in. W x 13 in. D (133.4 mm H x 482.6 mm W x 330 mm D)

## 1.4.15 Installation Clearance Requirements

#### 1.4.15.1 Connector Clearances:

USB, 2.5 in (64 mm) minimum dependent on size of USB storage

device

#### 1.4.15.2 Cooling Clearances:



#### 1.4.16 Weight

## 1.4.17 Cleaning

Use a mild, nonabrasive cleaner or detergent taking care to prevent cleaner from entering Cygnus 2.

# 1.5 Unpacking and Inspection

- 1 If Cygnus 2 has not been removed from its shipping container, do so now.
- **2** Carefully examine Cygnus 2 for damage that may have occurred during shipping. This is especially important if you notice obvious rough handling on the outside of the container. *Immediately report any damage to the carrier and to INFICON*.
- **3** Do not discard the packing materials until you have taken inventory and have at least performed a power on verification.
- **4** Take an inventory of your order by referring to your order invoice and the information contained in section 1.6 on page 1-16.
- **5** To perform a power-on verification, see section 1.7 on page 1-19.
- **6** For additional information or technical assistance, contact INFICON, refer to section 1.3, How To Contact INFICON, on page 1-5.

## 1.6 Parts and Options Overview

# 1.6.1 Base Configurations

Cygnus 2 Control Unit	. 781-500-G11 North America, 781-500-G12 Europe
Ship Kit	. 781-020-G1 North America, 781-020-G2 Europe
Operating Manual on CD ROM	. 074-545 on 074-5000-G1 CD ROM included in Ship Kit
I/O Relay	. Contains Input/Relay Interface Connectors (8 relay outputs, 14 TTL inputs). Included in Ship Kit.



#### 1.6.2 Pre-installed Options or Spares

#### The following contain board and interface connector

(8 relay outputs, 14 TTL inputs)

781-503-G1

(8 relay outputs, 14 TTL outputs)

DAC Option Board and Kit . . . . . . . . . . . 781-504-G1

#### 1.6.3 Optional Accessories

Pneumatic Shutter

Handheld Controller ......755-262-G1

Function:Power Increase/Decrease/Stop/Switch Crystal

#### 1.6.4 Oscillator Packages

Cygnus 2 Oscillator, 15 ft. and 6 in. cable . . pkg. . . 781-611-G15

Cygnus 2 Oscillator, 30 ft. and 6 in. cable pkg. . . . . 781-611-G30

Cygnus 2 Oscillator, 50 ft. and 6 in. cable pkg. . . . . 781-611-G50

Cygnus 2 Oscillator, 100 ft. and 6 in. cable pkg. . . . 781-611-G100

4 Meter Oscillator, 15 ft. and 6 in. cable pkg. .....781-612-G15

4 Meter Oscillator, 30 ft. and 6 in. cable pkg. ..... 781-612-G30

4 Meter Oscillator, 50 ft. and 6 in. cable pkg. ..... 781-612-G50

4 Meter Oscillator, 100 ft. and 6 in. cable pkg. .... 781-612-G100

4 Meter Oscillator, 15 ft. and 20 in. cable pkg. .... 781-613-G15

4 Meter Oscillator, 20 ft. and 20 in. cable pkg. . . . . 781-613-G20

4 Meter Oscillator, 50 ft. and 20 in. cable pkg. .... 781-613-G50

4 Meter Oscillator, 100 ft. and 20 in. cable pkg. ... 781-613-G100

#### 1.6.5 Sensors

Contact INFICON for a complete listing of sensors.



# 1.6.6 Replacement Cables

Oscillator to vacuumfeedthrough cable, 6 in	.755-257-G6
Cygnus 2 Unit to Oscillator Cable 15 ft	. 600-1261-P15
Cygnus 2 Unit to Oscillator Cable, 30 ft	.600-1261-P30
Cygnus 2 Unit to Oscillator Cable, 50 ft	. 600-1261-P50
Cygnus 2 Unit to Oscillator Cable, 100 ft	.600-1261-P100



#### 1.7 Initial Power-On Verification

A preliminary functional check of Cygnus 2 can be made before formal installation. It is not necessary to have sensors, source controls, inputs or relays connected to do this. For more complete installation information, see Chapter 2, Installation and Interfaces and Chapter 10, Maintenance and Calibration Procedures.



#### **WARNING - Risk Of Electric Shock**

There are no user-serviceable components within the Cygnus 2 case.

Dangerous voltages may be present whenever the power cord or external input/relay connectors are present.

Refer all maintenance to qualified personnel.



#### **WARNING - Risk Of Electric Shock**

Never interrupt the protective earth circuit.

Any interruption of the protective earth circuit inside or outside Cygnus 2, or disconnection of the protective earth terminal is likely to make Cygnus 2 dangerous.



This symbol indicates where the protective earth ground is connected inside Cygnus 2. Never unscrew or loosen this connection.



- 1 Confirm that AC line voltage is supplied and proper for Cygnus 2.
- **2** Confirm that the back panel (main) AC switch is in the ON position.
- **3** Press the ON/STBY button on the front panel. A green pilot light should be illuminated next to the power switch.
- **4** The fan at the back of Cygnus 2 should be exhausting air.
- **5** After the initial temporary boot-up screen which can be viewed in Maintenance Sys Status, the LCD monitor will display an image similar to the one shown in Figure 1-1 or Figure 1-2.

Figure 1-1 Operate screen show graph





Figure 1-2 Operate screen show all materials





# Chapter 2 Installation and Interfaces

#### 2.1 Location Guidelines

Before permanently installing Cygnus 2, read this entire chapter on installation and interfaces and follow its recommendations as closely as possible. INFICON has taken numerous steps to ensure its equipment will operate in a variety of harsh situations. Failure to adhere to these simple practices may adversely affect the performance and longevity of Cygnus 2.

#### 2.1.1 Sensor Types

The choice of sensor type must be dictated by the process, the deposition material and the physical characteristics of the process chamber. General guidelines for each sensor type produced by INFICON are outlined in the Sensor Data Sheets on the www.inficon.com website. For specific recommendations, consult your INFICON representative.



#### CAUTION

The performance of this Cygnus 2 depends on the careful installation of the chosen transducer. Improper installation will cause problems with deposition repeatability, crystal life and rate stability.

#### 2.1.2 Sensor Installation

Figure 2-1 shows a typical installation of an INFICON water cooled crystal sensor in the vacuum process chamber. Use the illustration and the following guidelines to install your sensors for optimum performance and convenience.



Mounting Bracket Coax Cable (Routed with Water Tubes) Sensor Shutter Brazing Adapters Or, Customer Supplied Cajon Coupling Source to Sensor 10" Minimum Source Shutter Source Pneumatic Actuator To Source Controller Water In - Water Out IPN 750-420-G1 Shutter Solenoid XIU (Oscillator) Assembly Air, 80 PSI, 110 PSI Max. Instrument Chassis То


Figure 2-1 Typical installation

Sensor Shutter



Generally, install the sensor as far as possible from the evaporation source (a minimum of 10 in. (25.4 cm) is recommended) while still being in a position to accumulate thickness at a rate proportional to accumulation on the substrate. Figure 2-2 shows proper and improper methods of installing sensors.

Figure 2-2 Sensor installation guidelines



To guard against spattering, use a source shutter or crystal shutter to shield the crystal during the initial soak periods. If the crystal is hit with even a minute particle of molten material, it may be damaged and stop oscillating. Even in cases when it does not completely stop oscillating, it may become unstable. Follow these precautions:

- Mount the sensor to something rigid and fixed in the chamber. Do not rely on the water tubes to provide support.
- Plan the installation to insure there are no obstructions blocking the path between the sensor and the source. Be certain to consider rotating or moving fixtures.
- Install sensors so their central axis (an imaginary line drawn normal to the center of the crystal face) is aimed directly at the virtual source being monitored.
- Be sure there is easy access for the exchange of crystals.
- For systems employing simultaneous source evaporation (co-deposition), try to locate the sensors so the evaporant from each source is flowing to only one sensor. It is not generally possible to do this without special shielding or optional "material directors."



## 2.1.3 Cygnus 2 Installation

Cygnus 2 is designed to be rack mounted. It may be also used on a table. Cygnus 2 is forced-air cooled, with the air flow exiting the rear of Cygnus 2 for clean room convenience.

It is generally advisable to centrally locate Cygnus 2, minimizing the length of external cabling. The cable from the instrument to the XIU is typically fifteen feet. Thirty, fifty and one hundred foot cables are available.

# 2.2 Avoiding Electrical Interference

Careful consideration of simple electrical guidelines during installation will avoid many problems caused by electrical noise.

To maintain the required shielding and internal grounding and ensure safe and proper operation, Cygnus 2 must be operated with all enclosure covers, sub-panels and braces in place and fully secured with the screws and fasteners provided.



### **CAUTION**

When using Cygnus 2 with an RF sputtering system, the cable between Cygnus 2 and oscillator should be kept as far away from the RF transmission cable as possible. Interference from the RF transmission cable may cause an erroneous crystal fail.

# 2.2.1 Verifying/Establishing Earth Ground

If a ground must be established, the following procedure is recommended:

- Where soil conditions allow, drive two ten foot copper clad steel rods into the ground six feet apart. Pour a copper sulfate or a salt solution around each rod to improve the ground's conduction. A near zero resistance measurement indicates earth ground is achieved.
- Keep connections to this grounding network as short as possible.



#### 2.2.2 Connections to Earth Ground

There are two required earth ground connections:

- The earth ground connection on Cygnus 2 is a threaded stud with a hex nut. Connect a ring terminal to the ground strap, thus allowing a good connection and easy removal and installation. This connection must be made at installation. For best protection against high frequency noise, the length-to-width ratio of the earth conductor should not exceed 5:1. See Figure 2-3 for the suggested method of grounding.
- This Cygnus 2 is also connected to earth ground via a sealed three-core power cable, which must be plugged into a socket outlet with a protective earth ground terminal. Extension cables must always have three conductors including a protective earth ground conductor.



## **WARNING - Risk Of Electric Shock**

Never interrupt the protective earth ground intentionally. Any interruption of the protective earth ground connection inside or outside Cygnus 2 or disconnection of the protective earth ground terminal is likely to make Cygnus 2 dangerous.



This symbol indicates where the protective earth ground is connected inside Cygnus 2. Never unscrew or loosen this connection.



#### CAUTION


An external earth ground connection is required to ensure proper operation, especially in electrically noisy environments.

When used with RF powered sputtering systems, the grounding method may have to be modified to the specific situation. An informative article on the subject of Grounding and RFI Prevention was published by H.D. Alcaide, in "Solid State Technology", p.117, April, 1982.



In many cases, a braided ground strap is sufficient. However, there are cases when a solid copper strap (0.030 in. thick x 1 in. wide) is required because of its lower RF impedance.

Figure 2-3 System grounding diagram



## 2.2.3 Minimizing Noise Pickup from External Cabling

When a Cygnus 2 is fully integrated into a deposition system, there can be many wire connections, each a potential path for electrical noise to reach the inside of Cygnus 2. The likelihood of these wires causing a problem can be greatly diminished by adhering to the following guidelines.

- Use shielded coax cable or twisted pairs for all connections.
- Minimize cable lengths.
- Avoid routing cables near areas that have the potential to generate high levels of interference. For example, large power supplies such as those used for electron beam guns or sputtering sources can be a source of large, rapidly changing electromagnetic fields. Placing cables as little as one foot away from these problem areas can significantly reduce noise pickup.
- Be sure that a good ground system and straps are in place per the recommendations in section 2.2.2 on page 2-5.
- Ensure that all Cygnus 2 covers and option panels are in place and tightly secured with the provided fasteners.

**NOTE:** Always use shielded cables when making connections to Cygnus 2 rear panel to minimize electrical noise pickup.



# 2.3 Connecting the Controller

The operation of Cygnus 2 depends on the proper connection of power and signal interfaces to owner equipment and sources.



#### WARNING - Risk Of Electric Shock

This Cygnus 2 has line voltage present on the primary circuits whenever it is plugged into a mains power source.

Never remove the cover from Cygnus 2 during normal operation.

There are no operator serviceable items within Cygnus 2.

Removal of the cover must be done only by a technically qualified person.

In order to comply with accepted safety standards, Cygnus 2 must be installed into a rack or system which contains a mains switch. This switch must break both sides of the line when it is open and it must not interfere with the safety earth ground.

Cygnus 2 is initially powered by AC line current. The line voltage provided in your facility must be within the voltage range shown in section 1.4.10, Power, on page 1-14.

# 2.3.1 Routing XIU Cables

The signals traveling on this cable are both analog and digital. It is suggested that it not be routed near areas with high levels of electromagnetic interference, even if its length must be somewhat increased.

#### 2.3.2 Interface Cable Fabrication and Pin-Out

It is necessary to fabricate several cables in order to interface Cygnus 2 to the deposition system. Refer to section 2.2.3, Minimizing Noise Pickup from External Cabling, on page 2-6.



#### 2.3.2.1 Source Control Connection

Six Digital-to-Analog (DAC) outputs are provided as standard equipment with Cygnus 2. These standard 6 DAC channels with BNC connectors and six optional DAC outputs on a 15 pin sub-D connector may be programmed for Source control or chart recorder functions as desired.

#### 2.3.2.2 Crucible Indexer Connections

Example: 4 pocket crucible using outputs 6 and 7

Number of crucibles = 4

Crucible output = 6

For this example, wiring to the controller is based on Table 2-1. Only relays 6 and 7 are needed to encode the four possible positions.

Table 2-1 Wiring to the controller

Crucible Position	Contact Status	
	Relay #6	Relay #7
1	Open	Open
2	Closed	Open
3	Open	Closed
4	Closed	Closed

#### 2.3.2.3 DAC Option Kit

An optional Digital-to-Analog Converter (DAC) card can be installed into Cygnus 2. This card provides six additional DAC outputs, numbered 7 through 12, for Thickness and/or Rate as determined by the DAC Output Option parameters. The pin assignments for DAC outputs 7 through 12 are shown in Table 2-2.

Table 2-2 Optional DAC pin assignments

Output Number	Pin
7	1, 6 (GND)
8	2, 7 (GND)
9	3, 8 (GND)
10	4, 9 (GND)
11	5, 10 (GND)
12	11, 12 (GND)

A mating connector is included with the DAC option.



#### 2.3.2.4 I/O Expansion Options

One I/O Relay module is included as standard equipment with Cygnus 2 and is used to interface with other machinery of the vacuum system. It can control components such as heaters, rotators or shutters through its 8 relays. It can respond to external instructions through its 14 isolated input lines. Standard equipment provides 8 relays and 14 input lines. Optionally, this can be expanded to 24 relays, 28 TTL inputs, and 14 open collector type outputs with the addition of another Relay I/O module and a TTL Relay module having 8 relays and 14 TTL open collector outputs.

The modules provide separate connectors for outputs and input lines. A 25-pin D-sub, male connector is used for the eight relays. A 15-pin D-sub, male connector is used for the input lines. Mating connectors are provided. Refer to Figure 3-2 on page 3-3 for connector locations and Table 2-3 on page 2-10 for connector pin assignment. Relay connections are rated at 30 V (dc) or 30 V (ac) RMS or 42 V (peak) maximum; 2.5 A maximum.

Inputs are activated by pulling the specific input terminal to ground (<0.8 V) through a contact closure to common (GND) or with TTL/CMOS Logic having current sink capability of 2 mA (1 low power TTL load).



#### **WARNING - Risk Of Electric Shock**

The relay, relay circuit, and associated pins in the I/O connector(s) have a maximum voltage rating of 30 V (dc) or 30 V (ac) RMS or 42 V (peak). The maximum current rating per connector pin or relay contact is 2.5 Amps.



Table 2-3 Input/Relay pin connections

	I/O B	oa	rd #1	
Relay #	Pins		TTL Input #	Pin
1	7, 6		1	15
2	9, 8		2	14
3	11, 10		3	13
4	13, 12		4	12
5	5, 4		5	11
6	3, 2		6	10
7	1, 14		7	9
8	15, 16		8	8
			9	7
			10	6
			11	5
			12	4
			13	3
			14	2
			GND	1

	I/O B	oa	rd #2	
Relay #	Pins		TTL Input #	Pin
9	7, 6		15	15
10	9, 8		16	14
11	11, 10		17	13
12	13, 12		18	12
13	5, 4		19	11
14	3, 2		20	10
15	1, 14		21	9
16	15, 16		22	8
			23	7
			24	6
			25	5
			26	4
			27	3
			28	2
			GND	1

	I/O B	oard	#3	
Relay #	Pins		TTL itput #	Pin
17	7, 6		25	9
18	9, 8		26	10
19	11, 10		27	11
20	13, 12		28	12
21	5, 4		29	13
22	3, 2		30	14
23	1, 14		31	15
24	15, 16		32	1
			33	2
			34	3
			35	4
			36	5
			37	6
			38	7
	-	(	GND	8



#### 2.3.2.5 RS-232C Communications

RS-232C serial communications is included in Cygnus 2 as standard equipment. It can be used to remotely control or monitor Cygnus 2. An industry standard 9-pin D-Sub connector is required for the host computer side connection. Depending on the computer source, all connections may not be necessary. The length of the cable is limited to fifty feet according to published standards. Cygnus 2 interface operates as DCE (Data Communication Equipment). Pin assignments are for Cygnus 2 connector.

Table 2-4 RS-232C pin connections

Signal	Name	Pin	EIA Name
TX	Transmit Data	2	BA
RX	Receive Data	3	BB
SG	Signal Ground	5	AB
GND	Shield Ground	1	



## 2.3.2.6 Isolated +24 V (dc) Supply

An isolated +24 V (dc) power supply is available on a 9-pin D-Sub connector on the Cygnus 2 back panel. This supply is rated for 1.75 Amps maximum.

The pin assignments for this connector are shown in Table 2-5.

Table 2-5 +24 V (dc) pin connections

Pin	Function
1	Return
2	Return
3	Return
4	Not Connected
5	Not Connected
6	+24 Volts
7	+24 Volts
8	+24 Volts
9	Not Connected



## **CAUTION**

Both the isolated 24 V (dc) supply and the RS-232C remote communications port use a 9-pin D-sub connector. Care must be taken not to inadvertently connect the RS-232C remote communications cable to the 24 V (dc) supply connector. Also, care must be taken not to inadvertently connect the 24 V (dc) supply cable to the RS-232C remote communications connector.




# Chapter 3 Operation

## 3.1 Front Panel Controls

Operational controls for Cygnus 2 are located on the front panel, see Figure 3-1.

Figure 3-1 Cygnus 2 front panel



#### 1 LCD Screen

Provides graphical displays, set-up menus, status and error messages.

#### 2 STOP and PRINT Function Keys

The STOP key places an individual Material into the Stop state. The Material stopped is designated by the screen cursor position. The PRINT key sends the LCD screen content to the USB storage device.

#### 3 Data Entry Keys

A keypad array with numerics 0 through 9 with telephone-style assigned letters for parameter entry. All numeric entries need to be followed by ENTER.

CLEAR is used to erase data entry errors. If an illegal value has been entered, CLEAR will erase the error message and re-display the last valid data. Pressing CLEAR on power-up clears any Lock codes. If no Lock codes are present, all user parameters will be cleared to their default values.

Pressing TOGL moves through selection options such as Yes or No or others such as Sensor types. Pressing ENTER continues with the selected choice.



#### 4 System Switches

An array of three keys that provide START, STOP ALL and RESET for process control.

**START**: Starts the cursored Material if in Ready, Idle or Stop and Start Interlock is not in effect.

**RESET**: Places the cursored Material in Stop into the Ready mode.

STOP ALL: Places all Materials into the Stop mode.

#### 5 Handheld Controller Mount

Tapped hole for attaching support bracket.

#### 6 F1, F2, F3, F4 Function Keys

The function keys. They are used to select displays or menu items. Their function is indicated on the display and is described in subsequent sections.

#### 7 USB

Receptacle for a storage device.

#### 8 Remote Control Jack

Receptacle for the optional wired Handheld Controller (IPN 750-262-G1). For more information on the Handheld Controller, see section 3.5.5 on page 3-31.

#### 9 Cursor Keys

An array of five keys used to move the display cursor either up, down, left or right. The MENU key is used to navigate through the Cygnus 2 displays. The keys auto-repeat; the cursor will continue to move as long as the key is held down.

#### 10 Power

This switch controls secondary power to Cygnus 2 between ON and STANDBY.

#### 11 Pilot Light


A green light, adjacent to the power switch, illuminated when secondary power is on.



## 3.2 Rear Panel Interfaces

Interfaces for Cygnus 2 are located on the rear panel, see Figure 3-2.

Figure 3-2 Cygnus 2 rear panel



#### 1 Ground Stud

Refer to section 2.2.2, Connections to Earth Ground, on page 2-5.

#### 2 AC Power Inlet, Fuse and Mains Switch

Provides main power switch, fuse and common connector for international plug sets.

### 3 8 Relay x 14 Input I/O Card (standard)

Provides pin connection for 8 Relays rated for 30 V (dc) or 30 V (ac) RMS or 42 V (peak) maximum, and 14 TTL inputs.

## 4 8 Relay x 14 Input I/O Card (optional)

Provides pin connection for 8 relays rated for 30 V (dc) or 30 V (ac) RMS or 42 V (peak) maximum, and 14 TTL inputs.

#### 5 8 Relay x 14 Output I/O Card (optional)

Provides pin connection for 8 relays rated for 30 V (dc) or 30 V (ac) RMS or 42 V (peak) maximum, and 14 open collector type outputs.

#### 6 Sensor Connectors - Channels 1 and 2 (standard)

Provides connection for two Sensor channels.

#### 7 Sensor Connectors - Channels 3 and 4 (optional)

Expansion panel to accommodate the optional addition of two more sensors, Sensors 3 and 4.



#### 8 Sensor Connectors - Channels 5 and 6 (optional)

Expansion panel to accommodate the optional addition of two more sensors, Sensors 5 and 6.

#### 9 Not used

#### 10 TCP/IP Connector (Optional)

Provides connections for TCP/IP interface.

#### **RS-232C Remote Communication Connector (standard)**

Provides a 9-pin RS-232C communications port.

## 11 For future expansion options

## 12 6-Channel DAC (optional)

Provides recorder output for six channels (15 pin miniature D-sub connector). Outputs are programmable for recorder function.

#### 13 Fan Outlet

Exhaust opening for the Cygnus 2's miniature fan; **Do not block!** 

## 14 24-Volt Supply (standard)

Provides three 24 V (dc) supplies rated at 1.75 Amps. See Table 2-5 on page 2-12.

## 15 6-Channel DAC (standard)

Provides Source control voltage or recorder output for 6 channels (BNC connectors). Outputs are programmable for Source Control or Recorder Voltage.



# 3.3 Displays

Cygnus 2 has many display screens for monitoring and programming processes. The five main types of displays are: Operate, Sensor, Source, Material, and General.

To move from one display to another, use the cursor and MENU keys. Figure 3-3 provides an overview of the Main Menu display hierarchy. Figure 3-4 provides an overview of the Operate display hierarchy.

To maximize the life of the display, it can be set to turn off after a period of 1 to 99 minutes without a key press. See section 6.9, AUDIO / VISUAL Page Set Up, on page 6-9. Pressing a key before the dimmer time elapses resets the dimmer interval to start over. The default setting of 0 disables the dimmer function. When the display is dimmed, the START, RESET and STOP keys remain active. To restore the display to full brightness without stopping or starting the instrument, do not press the STOP or START key.

## 3.3.1 Main Menu Display

From the Main Menu screen, see Figure 3-3, move to any Cygnus 2 display by positioning the cursor to highlight the desired display and press the MENU key. A second pressing of the MENU key returns to the Main Menu display.

Figure 3-3 Main menu

<b>Operate</b>	Genera1		
Sensor Information	Digital I/O		
Sensor	Logic		
Source	Maintenance Counter/Timer		
Material			
	<b>USB Storage</b>		
Main Menu	Crystal Fail		
02/02/2011 12:00			



## 3.3.2 Operate

The default Operate display shows all six Materials, see Operate screen show all materials on page 1-20. To display an individual Material, cursor to it and press F3, Show Graph. The Graph Operate display, Figure 3-4, provides information about the current Material in process. This includes the Material, Source #, and Sensor # currently in process. The rate, thickness, power level, state, state time, Material time, and process time are updated once a second.

The graph gives an analog display of the Power% level or the rate deviation from the desired rate while depositing. With the cursor on the upper Y-axis value, use the TOGL key to choose Rate Deviation or Power% graphing. Similarly, with the cursor on the X-axis label, use the TOGL key to choose the desired Graph Scan Rate. These selections will apply to all six Material graphs.

Below the graph is a message area consisting of five lines. The Status Messages area, see section 13.1, occupies the first four lines. Transient Messages, see section 13.4 and Input Error Messages, see section 13.5, share the fifth line. This area displays error messages, custom user messages and system status information, such as indicating Cygnus 2 is in Test mode. Status messages are displayed as long as a status is true. They are put up and taken down as the condition that set them changes. Since there is limited space for the status messages, if too many status messages are displayed at the same time (greater than 4), newer messages will be displayed. If they are cleared, the old messages will appear again assuming the condition is still applicable.




Figure 3-4 Show graph operate screen



#### **Operate Display Description**

- 1 Rate
- 2 Thickness
- 3 Power Level
- 4 State of Material
- 5 State Timer
- 6 Material Timer
- 7 Material Being Deposited
- 8 Source Number In Use
- 9 Sensor Number In Use
- 10 Crystal Position In Use
- 11 Graphical Display of Rate Deviation or Power
- 12 Date and Time
- 13 Message Area
- 14 Function Key Definitions
- 15 Crucible Position
- 16 State preceding Stop


During the OPERATE display, the function keys below the screen function as explained in Table 3-1.

Table 3-1 Operate display function keys

Key	Function	Description
F1	ZERO THICKNESS	Pressing F1 resets the displayed thickness of the current Material to zero.
F2	TOGGLE MANUAL	Press F2 to put the Material in manual control so that the power level is controlled by the Handheld Controller (section 3.5.5). When in Manual, press F2 again to remove the Material from the Manual state and place it into the DEPOSIT state.
F3	SHOW ALL MATERIALS/ SHOW GRAPH	Press F3 to toggle between showing all Materials (if more are running) or showing only one Material.








## 3.3.3 Sensor Information

## 3.3.3.1 Sensor Information Rate/Xtal Display Description

**NOTE:** N/A (not available) will be displayed in these fields for disabled features or for Sensors not in use.

Figure 3-6 Rate/Xtal display





#### Sensor (Number field)

These numbers correspond to the Sensor connector channel numbers on the rear panel of Cygnus 2. Use the cursor keys to position the box cursor over the desired Sensor number. When either Switch Crystal, Rotate Sensor, Clear S & Q Counts, or Clear Failed Crystals is pressed, that function will be performed on the Sensor indicated by the box cursor if Cygnus 2 is in Ready, Stop or all active Materials are in Idle. Text will only be shown for installed cards, unless you are in TEST.

## **Average Rate**

This average is calculated based on a 2.5 second average of the Filtered Rate.

#### Raw Rate

Shows the instantaneous rate measurement. The rate fields are useful in identifying if a Sensor's rate measurements are becoming erratic.

#### % Life

Cygnus 2 allows a 1.5 MHz frequency shift from 6.0 to 4.5 MHz on the monitor crystal corresponding to 100% crystal life. The value shown represents the amount of crystal life consumed; 0% corresponds to 6.0 MHz, 100% corresponds to 4.5MHz. The amount of useful crystal life is highly dependent on the nature of the material being deposited as well as deposition conditions.

#### Crystal

This field is subdivided into three categories; current position (**Curr**), next position (**Next**), and **Failed**. Information is displayed in these fields only if the Sensor has more than one position.

**Curr**: For a XtalTwo sensor, the Curr field will show either 1 or 2. 1 indicates the active crystal of the dual sensor head. 2 indicates the inactive (shuttered) crystal of the dual sensor head. For a multi-position sensor, the Curr field indicates the current position of the sensor head.

**Next:** The Next field indicates the position to which the sensor head will rotate upon pressing the CrystalSwitch function key.

**Failed**: The Failed field indicates the sensor head positions containing failed crystals.

#### Q Count (Crystal Quality value field)

This field displays the value currently accumulated in the Crystal Quality counter when active. Delay indicates the Crystal Quality counter is not active. The Crystal Quality counter will become active five seconds after entering DEPOSIT and if the Crystal Quality parameter is non-zero, see page 5-9.



## S Single (Crystal Stability value field)

This field displays the positive single frequency shift currently in the Crystal Stability counter, see page 5-9.

#### S Total (Crystal Stability value field)

This field displays the positive total frequency shift currently accumulated in the Crystal Stability counter.

## 3.3.3.2 Crystal Life and Starting Frequency

On the Sensor Information RATE/XTAL display, crystal life is shown as a percentage of the monitor crystal's frequency shift, relative to the 1.50 MHz frequency shift allowed by Cygnus 2. This quantity is useful as an indicator of when to change the monitor crystal to safeguard against crystal failures during deposition. It is normal to change a crystal after a specific amount of crystal life (% change) is consumed.

It is usually not possible to use a monitor crystal to 100% of crystal life. Useful crystal life is dependent on the type of material being deposited and the resulting influence of this material on the quartz monitor crystal. For well-behaved materials, such as copper, at about 100% crystal life the inherent quality, Q, of the monitor crystal degrades to a point where it is difficult to maintain a sharp resonance and therefore the ability to measure the monitor crystal's frequency deteriorates.

When depositing dielectric or optical materials, the life of a gold, aluminum or silver quartz monitor crystal is much shorter— as much as 10 to 20%. This is due to thermal and intrinsic stresses at the quartz-dielectric film interface, which are usually exacerbated by the poor mechanical strength of the film. Many organic materials deposit as non-rigid films which causes the crystal's Q to fall rapidly. For these materials, the %Life of the quartz has very little to do with the monitor crystal's failure.

## 3.3.3.3 Function Key Selection Choices

To enable the function keys for the Sensor Information Rate/Xtal Display, move the cursor key to a Sensor number.

#### F1 Switch Crystal

To initiate a crystal switch for the Sensor number selected, press F1. The crystal switch will be done on the Sensor indicated by the box cursor. Use the cursor arrow keys to position the box cursor.

#### F2 Rotate Sensor

If the Sensor number chosen is a XtalSix, Xtal12 or Generic sensor type, press F2 to sequentially rotate the sensor head through all positions. This is useful to initialize a multi-position sensor after replacing failed crystals. The action is



taken on the Sensor indicated by the box cursor if Cygnus 2 is in Ready, Stop or all active Materials are in Idle. Failed crystal numbers are shown in the Failed column under Crystal.

Generic Sensor Status showing which crystals are good and which are failed relative to the current position is displayed in the bottom region of the table. This information is not retained upon leaving the Sensor Information display. To re-gain this information, press F2 again.

#### F3 Clear S and Q Counts

Press F3 to clear the Quality and Stability counters for the Sensor chosen by the box cursor.

## F4 Clear Failed Crystals

Pressing F4 resets the status of the Sensor that the box cursor is on for failed Sensors and crystal positions.

#### 3.3.3.4 Sensor Information Type/Freq Display Description

Figure 3-7 Type/Freq display

	no.	Sensor	Z-Ratio			Frequency		
Rate/Xta1	Sensor	Туре	Туре	Value	Act	Fundamenta 1	Anharmonic	
Type/Freq	1 2	Single Single	Matl Matl	1.000 1.000	213 0	5955204.007 0.000	0.000 0.000	
Sensor	Infor	mation	3		8 8		Crystal Fai	

#### Sensor

Sensor identifies the Sensor channel. Failed Sensor numbers appear in red.

## **Sensor Type**

Shows the Sensor type configured for the Sensor channel.

#### **Z-Ratio**

This two-column field displays the type and value of the Z-Ratio being used for the given Sensor.



**Matl** indicates the Z-Ratio being used for thickness calculation is the value found in the Material parameter Z-Ratio.

**Auto** indicates Cygnus 2 Auto-Z feature is used for thickness calculations. Auto-Z continually calculates the Z-Ratio for the "as deposited" film. If Cygnus 2 suddenly lost the ability to calculate Auto-Z, Auto would change to either Matl or Sens. Matl has the same meaning as described above, Sens indicates the last calculated Auto-Z value (prior to failure) is used for thickness calculations for this Sensor.

Cygnus 2 determines to use Matl or Sens depending on the frequency of the fundamental resonance. If the fundamental frequency closely matches the last valid fundamental frequency prior to Auto-Z failure, Cygnus 2 will use the Sens value. Otherwise Cygnus 2 will use the Matl value.

#### Act(ivity)

Activity is a measure of the Sensor circuit health or ability to conduct current. The values range from a maximum of 800 (healthiest) to a minimum of 0 (least healthy).

The Activity value is useful for predicting when a crystal needs to be replaced. If a crystal is about to fail, its series resistance will increase, allowing less current to flow through the crystal and hence the Activity value will decrease. The closer the Activity value is to zero, the more imminent a crystal failure.

Activity also can be used to gauge the health of the sensor head electrical contacts. For example, if a new monitor crystal is placed into the sensor head and has a crystal life of near 0%, but the Activity value for this crystal is lower than 550, this indicates the sensor head or in-vacuum cable is in need of repair.

#### Frequency

This field is subdivided into two categories: **Fundamental** and **Anharmonic**. The Fundamental frequency will be shown for all working Sensors. If Auto-Z is in effect for the Sensor, the Anharmonic frequency will also be shown. Frequency value will be displayed.

#### 3.3.3.4.1 TEST XIU

To test any XIU (Crystal Interface Unit), move the cursor onto the respective Sensor number. Pressing F1 then initiates the XIU self test. The XIU self test determines whether the crystal interface unit (XIU) and measurement card pair is operating properly. "XIU Test Passed" message will appear to indicate this. "XIU Test Failed" message will appear when there is a defect in the XIU itself, the XIU interface cable or the measurement card.

For the XIU self test to work properly, the XIU must have the six inch BNC cable (IPN 755-257-G6) attached and must be disconnected from the sensor feedthrough.



#### 3.3.4 Sensor Screen

From the main MENU display, placing the cursor on Sensor and pressing MENU brings up the Sensor display.

The Sensor Overview display, see Figure 3-8, shows the current configuration for all six Sensors.

Figure 3-8 Sensor overview display

Overview	Sensor # Sensor Type	1 Single	2 XtalTwo	3 XtalSix	4 Xta112	5 Generic	6 Single		
Sensor	Switch Out Shutter Out	0	1 0	2 0	3 0	4 0	0		
	Auto-Z	No	No	No	No	No	No		
	Recorder Output	7	8	9	10	11	0		
	Function Range	Thick 100	Rate 100	Thick 100	Rate 100	Rate 100	Rate 100		
	# Positions # Pulses	1	1	1	1	10 1	1		
	Pulse On s Pulse Off s	1.0	1.0	1.0	1.0	1.0	1.0		
ensor	,	9	Caro	usel Open	4	100		Crystal 2	Fai1
2/05/2011	11:33								

Moving the cursor onto one of the Sensor numbers and pressing F1. Select Sensor brings up the Sensor display.


See section 4.1.2, Sensor Parameters, on page 4-2 for programming details.



#### 3.3.5 Source

The Source Overview display, see Figure 3-9, shows the current configuration for all six Sources.

Figure 3-9 Source overview display



Once the right cursor key has been used to move to one of the six Sources, the Select Source function key will appear. Pressing F1 will then display the Source's parameter screen.

The Source display allows configuring the selected Source.

See section 4.2.2, Source Parameters, on page 4-5 for programming details.



#### 3.3.6 Material


This display is organized into eight sub pages accessible thru the Select Menu described below.

See Chapter 5, Material Set-Up for programming details and screen displays.

#### 3.3.6.1 Overview Page

The Material Overview display, see Figure 3-10, shows all 6 available Materials. Materials are initially shown as Material 1 to Material 6. Once a chemical formula or other name has been assigned, that name will be shown. See section 5.1.2, Material Definition, on page 5-2

Figure 3-10 Material overview page



#### 3.3.6.2 Source Page

The Material Source page allows entering or editing Density, Z-Ratio, Crucible to use, Control Loop type and associated control loop parameters. The operating limits for Min. and Max Power are also defined here. If desired, a Recorder Output (one of the unused standard six or optional additional six analog outputs) can be selected for Filtered Rate, Thickness, Rate Deviation or Power and the full scale Range value selected. See section 5.1.3, Material Source Page Parameters, on page 5-3.



#### 3.3.6.3 Sensor Page

The Material Sensor page, see Figure 3-11, allows selecting the Tooling factor. Other choices will be shown according to the Sensor Type. If the Sensor is a CrystalTwo, the Tooling factor for the secondary crystal can be specified. In the case of a multi-position rotary sensor head, the range of crystal positions to use can be specified.

In addition, Quality and Stability settings are available to force a crystal switch to a backup crystal when the primary crystal starts to become unstable.

Figure 3-11 Material sensor page

Overview	Material Number	1	Quality Percent Quality Counts	. 0	*
Source Sensor	Master Tooling	100.0	Stability Singl Stability Total		Hz Hz
Pre/Post					
Deposit	Xtal Position First Xtal Position Last	0			
Lib A-Hf	Failure Action CrystalTwo Tooling	STOP MATL	8		
Lib Hf-Sc	100 A				
Lib Sc-Z					
lateria	1 1	Carousel	Open 4	Crystal 2	Fai

#### 3.3.6.4 Pre/Post Page

Up to three pre-deposition phases with rise times, power levels and soak times can be specified. Also, Auto Soak 2 can be enabled as well as Shutter or Control Delay. See section 5.1.5, Pre/Post Screen Deposit Page Parameters, on page 5-10.

#### 3.3.6.5 Deposit Page

Set the desired deposition rate, Final Thickness, Thickness Limit, Time Limit, Rate Filter Time, Time Power Avg Time, Ion Assist Deposit, and the state to enter after reaching Final Thickness.

Two new rates can be specified while in Deposit and RateWatcher can be enabled.

See section 5.1.7, Deposit Page Parameters, on page 5-14.



#### 3.3.6.6 Lib A-Hf, Lib Hf-Sc, Lib Sc-Z Sub-Displays

These three libraries allow convenient selection of a Material by its chemical formula along with the correct density and Z-Ratio values. Cursor to a Material formula, then press F1 Define Material to select that Material. The Material/Source display will be shown where the remaining parameters can be entered. See section 5.1.2, Material Definition, on page 5-2.

#### 3.3.7 General


The General screen is organized into eight sub screens described below.

See Chapter 6, General Parameters for programming details and screen displays.

#### 3.3.7.1 Process Page

The Process page shows global parameters and allows editing them.

Figure 3-12 Process page



**Thickness Eq 1, 2 and 3**..... allows summing of thicknesses from up to 6 Sources for use in conjunction with a logic statement Thick Sum event.

See section 6.2, General Process Page, on page 6-1

#### 3.3.7.2 DACs Page

Polarity and full scale voltage for all DAC outputs are configured here. 0 output corresponds to 0 Volts. See section 6.3, DACs Page Parameters, on page 6-2.



#### 3.3.7.3 Comm Page

Datalogging of crystal data is enabled here and RS232 and optional Ethernet parameters are entered.

- Datalog Xtal Info
- RS232 / Baud Rate/ Protocol
- Ethernet / IP Address/ Net Mask

See section 6.4, COMM Page Parameters, on page 6-3.

## 3.3.7.4 Message Page

Ten messages of up to 19 characters each can be entered. Display of messages can be turned on and off using Logic statements.

See section 6.5, MESSAGE Page Set-up, on page 6-5.

## 3.3.7.5 Date/Time Page

#### 3.3.7.6 Test Page

Allows executing the programmed Material with a dummy rate signal.

Test.....On/Off

Time Compressed . . . . . . . . . No/Yes to speed up all times by factor of 10

Advanced Test . . . . . . . . On/Off. Responds to crystal failures in "On"

mode.

See section 6.7, TEST Page Set Up, on page 6-7.

#### 3.3.7.7 Lock Page

Allows setting lock codes to prevent parameter changes or file access.

Program Lock Code/ File Access Code

See section 6.8, LOCK Page Code Set-up, on page 6-8.

#### 3.3.7.8 Audio/Visual Page

Audio Feedback: turns key beep on or off.

LCD Dimmer Time: 0 disables, sets time in minutes for screen to be turned off after no keys pressed and no Materials are running7.


See section 6.9, AUDIO / VISUAL Page Set Up, on page 6-9.



# 3.3.8 Digital I/O

The Digital I/O displays show configuration of all inputs, see Figure 3-13, and outputs, see Figure 3-14, and allows configuring inputs and outputs on the three possible I/O boards. See Chapter 7, Digital I/O for programming details.

Figure 3-13 All inputs display



**NOTE:** On All Input and All Output pages, active inputs and outputs are displayed in a standard font. Inactive inputs and outputs are displayed in a shadow font.

Figure 3-14 All outputs display

	Board 1 Relay Output	Board 2 Relay Output	Board 3 Relay Output	Board 3 TTL Output
All Input All Output I/O Bd 1 I/O Bd 2 I/O Bd 3	1 Xtal Switch 2 2 Xtal Switch 3 3 Xtal Switch 4 4 Xtal Switch 5 6 7 8	9 10 11 12 13 14 15	17 18 19 20 21 22 23 24	25 26 27 28 29 30 31 32 33 34 35 36 37 38
Outputs		Carousel Ope	n 4	Crystal Fail



## 3.3.9 Logic

100 logic statements can be set up. Logic statements are evaluated sequentially, 10 times per second, while Cygnus 2 is powered up.

See Chapter 8, Logic Statement Set-Up for programming details.

#### 3.3.10 Maintenance

The Maintenance display is organized into two subscreens: Source Maint(enance) and Sys(tem) Status.

See Chapter 10, Maintenance and Calibration Procedures for programming details.

#### 3.3.11 Counter / Timer

See Chapter 11, Counters and Timers.

## 3.3.12 USB Storage

Config	allows saving and retrieving configuration files to and from the USB storage device.
Datalog	shows datalog files on USB storage device.
Screen Shot	shows Print files on USB storage device.
See Chapter 12, USB Storage.	

# 3.3.13 Programming Guidelines

#### 1 Define Materials.

To define Materials, the MATERIAL pages of the MATERIAL screen are used. Each of up to 6 distinct Materials used must be defined. The Material definition includes rate, density, Z-ratio, tooling, soak power settings, thickness, RateWatcher, rate ramps, time limits and whether to STOP on max power. Control loop characteristics also relate to the Material. Also, one Source and one Sensor are automatically associated with each Material, for example Source 1 and Sensor 1 are fixed to Material 1, etc. up to Source 6 and Sensor 6 for Material 6. See Chapter 5 for a detailed description for programming these parameters.

#### **2** Configure General parameter information.

The final step in defining a process is to program the parameters on the GENERAL display. This includes the Process Thickness Equations, DAC voltage and polarity, Communication parameters, User Messages, Date/Time, Test mode, Lock Codes and Audio Feedback as well as LCD Dimmer time. See Chapter 6 for a detailed description of General parameters.






Figure 3-15 Process state diagram






Figure 3-16 Simplified Cygnus 2 state sequence diagram



# 3.4 State Descriptions

Table 3-2 State descriptions

STATE	CONDITION	RELAY CONTACT STATUS		REMOTE COMM
		Source Shutter	Sensor Shutter	ENCODES
1. READY	Cygnus 2 will accept a START command.	Inactive	Inactive	0
2. CRUCIBLE SWITCH (Crucible Sw)	During this state, the crucible turret is being moved from its current position to the one called out for the given Material. If the idle power of the Source in use is not zero the power is set to zero before the crucible position changes. Cygnus 2 advances to next state when turret input goes low for the programmed position or turret delay has elapsed (depending on parameter settings).	Inactive	Inactive	1
3. PRECON RISE	Source power rises to Precondition power level over the precondition rise time. [PreCon Rise Time]	Inactive	Inactive	2
4. PRECON SOAK	Source is maintained at precondition power level for the precondition soak time. [PreCon Soak Time, PreCon Soak Power]	Inactive	Inactive	3
5. RISE 1	Source is rising to Soak Power 1 level. [Rise Time 1]	Inactive	Inactive	4
6. SOAK 1	Source is being maintained at Soak Power 1 level. [Soak Time 1, Soak Power 1]	Inactive	Inactive	5
7. RISE 2	Source is rising to Soak Power 2 level. [Rise Time 2]	Inactive	Inactive	6
8. SOAK 2	Source is being maintained at Soak Power 2 level. [Soak Time 2, Soak Power 2]	Inactive	Inactive	7
9. SHUTTER DLY	Rate is being controlled. Advances to Deposit State once the Source is in Rate Control within Shutter Delay Accuracy for 5 seconds.	Inactive	Active	8
10. DEPOSIT	Rate control. [Rate, Final Thickness, PID Control, Process Gain, Primary Time Constant, System Dead Time]	Active	Active	9
11. RATE RAMP 1	Rate control, desired rate changing. [New Rate 1, Start Ramp 1, Ramp Time 1]	Active	Active	10
12. RATE RAMP 2	Rate control, desired rate changing. [New Rate 2, Start Ramp 2, Ramp Time 2]	Active	Active	11



Table 3-2 State descriptions (continued)

STATE	CONDITION	RELAY CONTACT STATUS		REMOTE COMM
		Source Shutter	Sensor Shutter	ENCODES
13. TIME POWER	Crystal failed; Source maintained at average control power and average rate prior to crystal failure. [Failure Actions]	Active	Inactive	12
14. Manual	Manual is entered via front panel key or remote communications command.  Thickness is incrementing if Source shutter is open. The Source power is controlled by the hand-held controller or remote communications	Active or Inactive depending on the state when manual is entered. Shutter can be opened or closed by the operator via remote communications during manual.	Active Shutter can be opened or closed by operator via remote communi- cations during manual.	13
15. (Non Deposit Control) NonDep CNTL	The state is entered after the pre-deposit (if "Dep after Pre-dep" parameter set to no) or via external stimulus (remote command, digital input) or after deposit if "On Final Thickness" set to Non-Deposit Control. Thickness is not incrementing. The Source power is controlled to the desired rate by the control loop. The state is ended via external stimulus.	Inactive	Active	14
16. NonDep Hold	Non-deposit hold is entered when in non-deposit control and there are no available crystals to continue the control if the time power option had been chosen. Non-deposit hold can also be entered from time power using the RL3 Remote command. Thickness is not incrementing. The Source power is maintained at the average control power prior to the crystal failure. Both aggregate rate and power can be adjusted via. remote communications. The state is ended via external stimulus.	Inactive	Inactive	15
17. FEED RAMP	Source changing to Feed Power level. [Feed Power, Feed Ramp Time]	Inactive	Inactive	16
18. FEED	Source maintained at Feed Power level. [Feed Time]	Inactive	Inactive	17
19. IDLE RAMP	Source changing to Idle Power level. [Idle Ramp Time, Idle Power]	Inactive	Inactive	18



Table 3-2 State descriptions (continued)

STATE	CONDITION	RELAY CONTACT STATUS		REMOTE COMM
		Source Shutter	Sensor Shutter	ENCODES
20. IDLE	Source resting at Idle Power; will accept a START command.	Inactive	Inactive	19
21. STOP	The respective Material's Source output is set to zero power. The Material's display is frozen at the last thickness value.	Inactive	Inactive	20

NOTE: In STOP Cygnus 2 will accept a START provided a valid crystal is available for the Material being started.

# 3.5 Special Features

Cygnus 2 has several special features to enhance the performance of the instrument.

# 3.5.1 Crystal Switching

Cygnus 2 offers a choice of Single, XtalTwo (CrystalTwo<sup>®</sup>), XtalSix (CrystalSix<sup>®</sup>), Xtal12 (Crystal12<sup>®</sup>), or Generic sensors. The CrystalTwo, CrystalSix, Crystal12, and Generic sensors provide one or more backup crystals in case a crystal fails during deposition. Sensor types are specified on the Sensors screen.

The XtalTwo option requires the 779-220-G1 or 779-220-G2 XTAL2 Switch. The XTAL2 Switch is connected to any Sensor input through an XIU package.

All multi-position and shuttered sensors require the Pneumatic Actuator Control Valve, part number 750-420-G1, and a feedthrough with an air tube.

A crystal switch will automatically occur when:

- Cygnus 2 is configured for a XtalTwo (CrystalTwo) sensor type, a Material is STARTed or running and there is another good crystal available when the active crystal fails.
- Cygnus 2 is configured for a XtalSix, Xtal12 or Generic, a Material is STARTed or running, and there is at least one good crystal left in the carousel when the active crystal fails.
- Using a XtalSix or Xtal12 and pressing START if the current position is not within the First/Last Xtal position range listed on the Sensor page of the Material screen.
- S and Q levels are exceeded while in deposit.



A crystal switch will NOT automatically occur:

- During a state of STOP, READY or IDLE.
- When the designated Sensor fails during pre-deposit. (A Stop Material will occur if the failure action is configured for Time Power.)
- During deposition if the secondary crystal of a XtalTwo switch fails, or the last good crystal of a XtalSix, Xtal12 or Generic fails. (In either case a TIME-POWER, STOP Material, POST DEPOSIT, or STOP ALL will occur, depending on the failure option chosen.)

A crystal switch can be manually executed via the front panel, handheld controller, remote communications, or logic statements when the system is configured for a multi-position sensor.

**NOTE:** When crystal switching with the handheld controller, Cygnus 2 must be on the Sensor Information screen and the cursor on the appropriate Sensor number.

## 3.5.1.1 XtalTwo (CrystalTwo)

In the case of the XtalTwo (a Dual Sensor head with a 779-220-G1 or 779-220-G2 XTAL 2 Switch), the CrystalSwitch output must be wired so that it simultaneously energizes the Pneumatic Shutter Actuator Control Valve which applies the air pressure to actuate the dual sensor shutter mechanism and the RF relay in the XTAL 2 Switch, exposing crystal #2 while covering crystal #1 and rerouting the RF signal. This allows the dual sensor to be operated with only one oscillator kit and requires only one Sensor connection at Cygnus 2.

Power-up initialization is performed on a dual sensor to verify that the secondary crystal is good.

If a crystal fail occurs while in Deposit, Cygnus 2 will switch to the second crystal and continue. The Failed Crystal list can be cleared while in Deposit by pressing the F4 function key on the Sensor Information screen with the cursor positioned on the appropriate Sensor number. While in Ready, the Failed Crystal list can also be cleared by executing a crystal switch with the Hand held controller or by pressing the Switch Crystal function key in the Sensor Information screen or via communications command RG23 (Switch Sensor) see section 9.4.31, Remote General Action, on page 9-43. A good crystal must be available to switch to in the case of using the crystal switch method.



#### 3.5.1.2 XtalSix (CrystalSix)

On power-up, all crystals are read to determine how many good and bad crystals are present. Cygnus 2 uniquely identifies and tracks all six positions in the CrystalSix.

During deposition, Cygnus 2 will automatically switch to the next position with a good crystal when there is a crystal failure. When the last good crystal fails the Xtal Fail message is displayed, the Xtal Fail state becomes true and Cygnus 2 will go directly to Time Power, POST DEP, STOP Material or STOP ALL, as appropriate.

When the Sensor selected is a XtalSix, the relay contacts are pulsed closed for one second, opened for one second, closed for one second, then opened for each position. The first one second closure will advance the CrystalSix carousel into an intermediate position between two crystals. Opening the closure for one second allows the ratchet mechanism to relax whereupon the second contact closure advances the next crystal into the proper position.

#### 3.5.1.3 Xtal12 (Crystal12)

On power-up, Cygnus 2 will rotate the Sensor until position 1 is detected. It will continue to rotate through the other 11 positions to determine the state of all crystals. At the conclusion of the sequence, the Sensor Information screen shows the Sensor in position 1 and the position number of any failed crystals. The Crystal12 has resistors electrically in parallel for each of the 12 positions. Cygnus 2 verifies that the resistance value is correct at each position. If the value is not as expected, Cygnus 2 pulses again and rechecks the position. If position 1 is not detected or after 13 pulses of the wrong value, Cygnus 2 reports a Crystal Sw Fail message. In that case, all crystals are also marked as failed, except for current position status.

When the carousel is removed from the Sensor for crystal replacements, Cygnus 2 displays Carousel Open. This message also appears if the connection between the XIU (oscillator) and the sensor is absent. After the carousel is replaced, Cygnus 2 assumes the current position is 12 and all crystals are failed. A Crystal Switch or Rotate Sensor function must be initiated in the Sensor Information screen or via Remote Communication to enable Cygnus 2 to catalog the state of all crystals and to return to position 1. This must also be done after the Sensor type has been changed to Xtal12. The Rotate Head function is permitted only if the Material is in Ready, Stop or Idle.

During deposition, Cygnus 2 will automatically switch to the next position with a good crystal when there is a crystal failure. When the last good crystal fails, the CrystalFail message is displayed, the Xtal Fail state becomes true and Cygnus 2 will go directly to Time Power or STOP ALL, POST DEP, STOP Material, as appropriate.

When configured for a Xtal12, the relay contacts are only pulsed closed for one second then opened again once for each position. There is no intermediate position.



#### 3.5.1.4 Generic Sensor Crystal Switching

Selecting Generic as the Sensor type enables sequential crystal switching for the #Positions selected (maximum of 12). Upon a crystal switch, the Switch Output will first close for the Pulse On time and then open for the Pulse Off time. The setting #Pulses determines how many On/Off pulse sequences will occur for each movement to the next crystal position. Cygnus 2 will not keep track of which position the Generic Sensor is on nor will it keep track of which crystals are good and which are failed. The Position Selection feature is not available for the Generic sensor.

After a crystal switch sequence, Cygnus 2 will attempt to find the resonant frequency for the crystal in this position. If Cygnus 2 does not find a good resonant frequency for this crystal, it will again pulse the Crystal Switch Output and attempt to find a resonant frequency at the next position. The maximum number of attempts to find a good resonant frequency is one less than the # Positions value. If a good resonant frequency is not found after all attempts, Cygnus 2 will enter the Time Power, POST DEP, STOP Material or STOP ALL state depending on the Sensor / Option Action chosen in the Material/Sensor display.

Start resets all crystal fail flags to good.

#### 3.5.2 Source/Crucible Selection

Cygnus 2 can control a Source with up to 64 crucibles through up to six binary encoded relays. This is configured by setting the Number Of Crucibles, Crucible Outputs, Turret Feedback, Turret Input, and Turret Delay parameters on the SOURCE page of the SOURCE screen. (See section 4.2.2, Source Parameters, on page 4-5 for details on programming the parameters associated with Source/crucible selection.)

To define which crucible to use for a Material, set the Cruc(ible) parameter on the MATERIAL/Source screen. When the Material is started, if the current crucible position is different from the one requested, the system's turret controller will move the crucible into position. This will be signified on the OPERATE screen by the state indicator CRUCIBLE SW(ITCH). The Material sequencing will continue on to Pre-condition Rise Time after either the turret delay time expires or an input indicates the turret is in position, depending on which option is chosen. The specific method used is determined by the parameter Turret Feedback on the SOURCE screen.

**NOTE:** If the Source has been idling at a nonzero power when the START is initiated, the power will be dropped to zero before the crucible is changed.

#### 3.5.2.1 Example: Programming Turret Source Crucible Selection

Interfacing a turret source controller to Cygnus 2 requires both hardware connections to the turret controller and properly defining certain Cygnus 2 parameters.



Proceed to the SOURCE screen and choose the Source that is going to be defined as the turret source. This is accomplished by Editing the chosen Source as follows:

- 1 Designate the Number of Crucibles; for example, four.
- 2 Select the Crucible Output. This defines the number of the first relay that encodes the crucible number selected by the active Material. Relays are defined sequentially with the first relay containing the least significant bit (LSB). The greater the number of crucibles selected, the greater the number of relays required. The number required is based on binary encoding (actual coding is binary -1, with 00 representing position 1 and 11 representing position 4). Any unused sequence of relays may be used if it is long enough to provide sufficient selections. Outputs are NO (Normally Open).
- 3 Determine whether Turret Feedback is desired. This allows the turret position controller to stop further Cygnus 2 processing until the requested turret position is satisfied. If chosen, a turret input must be connected to the turret position controller's feedback signal.
  - Enter a Turret Delay Time which allows an adequate time for positioning to take place. Once the delay time has expired, Cygnus 2 state processing continues.
- **4** The selection of a particular crucible for a Material is defined in the Material page.

#### 3.5.3 Auto-Z

The Auto-Z feature of Cygnus 2 automatically determines the Z-Ratio of a crystal. This feature is enabled on the SENSOR page of the SENSOR screen. For the theory behind Auto-Z, see section 14.1.6, Auto-Z Theory, on page 14-9.

The following information briefly describes Auto-Z and details the conditions under which a crystal is "unable to Auto-Z".

Auto-Z is calculated based on the slightly different mass sensitivities of the fundamental and the first anharmonic resonances of the quartz crystal oscillator. Therefore, the need to measure the frequencies of both the fundamental and the first anharmonic resonances is critical.

When inserting a monitor crystal and attempting to Auto-Z, the fundamental and anharmonic frequencies are measured to determine the status of the crystal. The crystal status may be classified into four categories:

#### 1 New Crystal

The first category is for a "new" crystal, one that does not have any material deposited onto it. If both frequencies fall within the allowed range for new crystals, Cygnus 2 will allow an Auto-Z calculation with this crystal.



#### 2 Known, Used Crystal

The second category is for a "known, used" crystal, to account for the possibility that a person would remove a good monitor crystal and then reinsert the same crystal. Whenever a crystal fail occurs, the last valid crystal frequencies are stored in Cygnus 2. Upon inserting a coated monitor crystal, the measured frequencies for this crystal will fall outside of the allowed range for "new" crystals. These frequencies are then compared with the stored values to determine if this crystal is the same one as was in use prior to the crystal fail. If the crystal is the same as used previously, and Auto-Z was being calculated previously, Cygnus 2 will allow an Auto-Z calculation with this crystal.

#### 3 Unknown, Used Crystal

The third category is for an "unknown, used" crystal. This category is for a used crystal that, upon insertion, shows measured frequencies that are outside of the allowed "new" crystal range and also do not match the frequencies stored within Cygnus 2. This results in an "unable to Auto-Z" condition because the initial frequencies of the uncoated monitor crystal are not known.

#### **4** Unable to detect anharmonic frequency.

As mass is deposited onto the crystal, the oscillation is damped. This damping may be severe enough that the resonance can no longer be determined. If Cygnus 2 loses the ability to measure the first anharmonic frequency, but is still able to determine the fundamental frequency, the "unable to Auto-Z" message is displayed. Cygnus 2 will then continue to use the fundamental frequency to monitor the deposition.

If Cygnus 2 loses the ability to measure the fundamental frequency and all available crystals in a multi-position sensor head are flagged as failed, the Crystal Fail message is displayed and the Xtal Fail logic state becomes true.

#### 5 Unable to Auto-Z

An "unable to Auto-Z" condition occurs whenever:

- The anharmonic frequency cannot be measured.
- The fundamental and anharmonic frequencies of the monitor crystal have not been continuously measured from the uncoated to the coated state.



#### 3.5.4 Rate Watcher

Cygnus 2 includes a sample and hold function which enables periodic sampling of the deposition rate by opening and closing the Sensor shutter. If you are controlling inherently stable deposition sources, this function is useful in maximizing crystal life. When RateWatcher is enabled, during deposit, rate control will be established. The Sensor shutter will close for a designated amount of time. The shutter will once again be opened to validate and adjust the power level. This procedure is repeated throughout the deposition. Three Material/Deposit parameters—RateWatcher Option, RateWatcher Time and RateWatcher Accuracy—control this function. See section 5.1.7, Deposit Page Parameters, on page 5-14.

#### 3.5.5 Handheld Controller

A Handheld Controller, see Figure 3-17, is available as an accessory with Cygnus 2. The Handheld Controller serves as a wired remote to manually control power, switch crystals and produce a STOP.

The Handheld Controller is attached to Cygnus 2 with a modular plug to the front panel.


Power is affected only when in Manual mode by moving the POWER/STOP switch laterally. Pressing to the left as indicated by the INCR arrow, increases the power. Pressing to the right as indicated by the DECR arrow, decreases the power.

A STOP is produced by moving the POWER/STOP switch down.

When on the Sensor Information screen, a crystal switch is activated by pressing the red button on the body of the controller.

The Handheld Controller kit includes a convenience hook for the Handheld Controller that can be attached to Cygnus 2's mounting ears or some other accessible location.

Figure 3-17 Handheld controller





#### 3.5.5.1 Determining Soak Power with the Handheld Controller

The Handheld Controller is a useful tool that can be used to determine the appropriate Soak Power levels. Below is an example of how a typical process Soak 1 and Soak 2 can be determined using the Handheld Controller.

#### **Determining Soak 1**

Use the Handheld Controller to slowly increase power, a few percent-per-minute. Watch the rate until some rate increase is detected. Depending on the type of source used, this may take several minutes. Once a non-zero rate is achieved, note the current percent power. Use a percent or more lower than this for the Soak Power 1 parameter.

#### **Determining Soak 2**

After ~30 - 60 seconds of Soak 1, using the Handheld Controller, again slowly increase the power a percent at a time until the desired Deposition Rate is reached. Use a percent or two less than this number for the Soak Power 2 parameter.

#### 3.5.6 Test Mode

Test can be turned on or off in the General/Test display page. "Test" will be shown in red while Test mode is active.

#### 3.5.6.1 Standard or Time Compressed

This Cygnus 2 contains a software-controlled test mode which simulates actual operation. In Time Compressed mode, all Material times are sped up so that a long process can be simulated in one tenth of the time. The purpose of the test mode is to verify basic operation and to demonstrate typical operation. The rate display during test mode operation is:

Rate Display = 
$$\frac{40}{\text{Density (g/cc)}} \times \frac{\text{Tooling \%}}{100} \text{ Å/sec}$$
 [1]

Crystal fails are ignored in these test modes. Auto crystal switching is disabled. All other relays and inputs operate normally.

#### 3.5.6.2 Advanced Test

In Advanced Test mode, crystal fails are recognized and auto crystal switching is enabled.



# 3.5.7 USB Storage Device

The USB port allows storage of all parameter information, screen shots as well as automatic datalogging information to a storage device. The maximum number of files which may be stored depends on the storage device memory size. Cygnus 2 is limited to displaying 120 files as 8 pages of 15. The directories are Config, Datalog and Screen Shot.

The parameter set may be stored under a new or existing filename and retrieved from an existing file. A file containing the Cygnus 2 parameter set is referred to as a configuration file. Datalog information will be saved only if the USB Datalog Format setting in the Datalog page of the USB Storage screen is set to Comma or Page.

Multiple files may be contained on one storage device. Filenames may be eight characters long; extensions are used to differentiate between configuration files, screen shots and datalogging files. All files must be contained in the appropriate directory. Storage/retrieval from sub-directories is not allowed for screen shots and datalog files

Cygnus 2 supports the writing of filenames using alphanumeric characters selected using the cursor keys. Characters A through Z and numbers 0 through 9 inclusive are available. Cygnus 2 has the ability to display the files contained on the memory stick. A scrolling feature is enabled to view those filenames which cannot fit as indicated by +++ on the screen. Error messages include: Disk Full; File Not Found; Disk Write Protected; Media Error; Disk not Found; File is Read Only.

Datalog files are automatically named using the Date and Material number. See section 3.5.9, Datalog, on page 3-35 for the Datalog string details.

Screen shots are named as DDMMYYXX or MMDDYYXX depending on the date format setting. XX is a number that increments 0-99, resetting to 0 every day.

**NOTE:** A File Access Code parameter is enabled when Cygnus 2 has a Program lock code set. By entering a File Access Code, the Cygnus 2 parameters can be saved to, or retrieved from, the USB storage device only without entering the Program Lock Code. (See Chapter 6, General Parameters.)



#### CAUTION

Do not remove the USB storage device from the Cygnus 2 while a Save or Retrieve operation is taking place.



#### 3.5.8 Lock and Access Codes

Cygnus 2 has several forms of protection to prevent unauthorized changing of parameters. Refer to the General setup section for a description of parameter and Program lock codes and the File Access Code. In addition, a method of locking the entire display is available through the remote communications. Lock codes are entered on the General display. See Chapter 6, General Parameters.

**HINT:** To clear any of the locks, except the File Access Code, hold down the CLEAR key on power up. This will clear all lock codes. **HOWEVER**, if no lock codes are present, all parameters will be cleared by doing this.



# 3.5.9 Datalog

When a Source Shutter closes, an end of deposit occurs, or following a Stop, a set of data will be collected. The data gives the user a snap shot of the layer data as the layer completed.

There are three ways this data can be managed:

#### 1 USB Storage USB Datalog Format set to Page or Comma

The data can be sent to a user supplied USB memory device in a data log file. The file is saved as "MMDDYYC#.IDL" or "DDMMYYC#.IDL" depending on the Date Format chosen in the General screen Date/Time page, see section 6.6, where "C#" is Material Number.The data is formatted depending on the setting of the "USB Data log format". Page format, see section 3.5.9.2, will insert a carriage return and a line feed at the end of each line of data. In Comma format, see section 3.5.9.3, a comma separates each piece of data.

Datalogging the crystal frequency data is an optional subset of the datalog string and is enabled by selecting Yes for Datalog Xtal Info on the Comm page of the General screen.

The information will be saved under a filename on the USB storage device. Datalog files saved to the USB storage device will be automatically named using the date and Material number. The format of the filename is MMDDYYC#.IDL or DDMMYYC#.IDL depending on the Date Format chosen where C# is the Material number. If the USB storage device already contains a file with the same filename as the new datalog information, the new datalog information will be appended to the old file.

At each Source shutter close, the datalog information will be appended to the file (when saved to USB).

#### 2 General Comm RS-232 Protocol set to Dlog Comma or Dlog Page

The data can also be sent to the RS-232 port if the General parameter "RS-232 Protocol" is set to "Dlog Page" or "Dlog Comma". See section 3.5.9.2 and section 3.5.9.3 for format descriptions. The RS-232 port then becomes a "send only" port. The port will supply the data log data and will not accept any commands from a remote computer.

Datalogging the crystal frequency data is an optional subset of the datalog string and is enabled by selecting Yes for Datalog Xtal Info on the Comm page of the General screen.

#### 3 SL16 # and SL17 # commands

The data log information is always available via Status command SL16 # (no crystal history) or SL17 # (with crystal history) in the remote communications. The data is returned in the standard remote communications packet as binary words. For more information, see section 9.4.29, Status Material, on page 9-39.



#### 3.5.9.1 Datalog contents:

The following values make up the data in the datalog. The data is sent in ASCII strings when the RS-232 port is set for data logging. The data is also saved as ASCII strings in the datalog files. The ASCII strings are made up of the labels and values in the following list. ASCII strings are CRLF (Carriage Return Line Feed) terminated. When the data log is requested via the remote status Material command SL16 # (no Crystal History) or SL17 # (with Crystal History), the values are sent in the binary format only.

- Year (Integer)
- Month (Integer)
- Day (Integer)
- Hour (Integer)
- Minute (Integer)
- Material x (Integer)
- Material x (x is the Material number or, in data log files, the name if the name is programmed)
- Material Time seconds (Integer)
- Deposit Time seconds (Integer)
- Ending Thickness kÅ (Float)
- Average Rate A/s (Float)
- Average Rate Deviation A/s (Float)
- Ending Power % (Float)
- Average Power % (Float)
- Where it goes next (Byte):
  - 0 = NonDeposit Control or NonDeposit Hold
  - ◆ 1 = Post Deposit
  - ◆ 2 = Stop
- Termination Reason (Byte) (Matches the "Cause of Stop" Remote encoding comm, see section 13.3, STOP messages, on page 13-5:
  - ◆ 128 = Normal termination,
  - 127 = Manual Source shutter closing,
- Time Power Flag (Byte) (0 = No, 1 = Yes)
- Power Fail Flag (Byte) (0 = No, 1 = Yes)
- Power Fail Thickness kÅ (Float) (0 if not a power fail, otherwise the thickness when the power was lost.)



NOTE: If Data Log Xtal Info Parameter is set to Yes, the following Crystal History will be sent for each Sensor, see Table 3-3. The Crystal history contains the history of every crystal in every Sensor used in the Material. In the Remote status command SL17 #, the crystal history for all twelve crystals in all six Sensors is returned. If there is a minus sign in front of the Freq value, it indicates that this crystal failed during the layer. The frequency value shown in that case is the last valid reading obtained before the crystal failed. If the General Comm Datalog Xtal Info parameter is set to No, all zeros are sent in the remote status command SL17 #.

Table 3-3 Sensor 1 to 6

Crystal	Begin Freq	End Freq	BegLife	EndLife	Beg Activity	End Activity	Stability Value	Quality Value
1	<float></float>	<float></float>	<integer></integer>	<integer></integer>	<integer></integer>	<integer></integer>	<integer></integer>	<integer></integer>
2								
3								
4								
5								
6								

Table 3-3 is extended as necessary to show all crystals in a sensor.



#### 3.5.9.2 Page Format ASCII Example:

To USB Storage Device and/or RS-232 Protocol Dlog Page for Material #1.

DATE: 09/16/2010

TIME: 09:13

LAYER #: 1

MATERIAL NAME: ONE

LAYER TIME: 01:02

DEPOSITION TIME: 01:02

THICKNESS: 2.504 kAng

AVE. AGG. RATE: 40.0 Ang/S

AVE. RATE DEV.: 0.0 Ang/S

ENDING POWER: 0.0 %

AVE. POWER: 0.0 %

WHERE NEXT: Post Deposit

COMPLETION MODE: NORMAL

If Datalog Xtal Info was set to Yes, Crystal History is also sent as shown:

Sensor number of the sensor used, Crystal number of crystal(s) used, labels and values are sent in the order displayed below.

### SENSOR 1

XTAL	_	END FREQ.	_		_		STAB.	QUAL.
1	5976244	5976243	0%	0%	187	189	0	0
3	5966388	5966388	0%	0%	331	328	0	0
5	5971051	5971051	0%	0%	669	674	00	

If there is a minus sign in front of the Freq value, it indicates that this crystal failed during the layer. The frequency value shown in that case is the last valid reading obtained before the crystal failed.



#### 3.5.9.3 Comma Format ASCII Example to USB Storage Device:

"09/15/2010","14:04", 1,"ONE ","00:15","00:15", 0.600, 40.0, 0.0, 0.0, 0.0,"Post Deposit ","TIME POWER"

If Datalog Xtal Info was set to Yes, Crystal History consisting of Sensor #, Crystal#, with the crystal data for twelve crystals is sent as displayed below.

The Dlog Comma protocol format is actually comma-and-quote delimited intended for file importation into a spreadsheet program. When a spreadsheet program imports a file having the comma delimited format, data groups that are strictly numbers become value entries, data groups surrounded by quotes are stored as labels.

For the comma delimited format, all the data fields are returned for all the crystals in a multi-position sensor. If a crystal is not used during the deposition, the data fields will contain zeros.



# 3.5.10 DAC Monitoring

Cygnus 2 continually compares the actual output voltages at the DAC BNC connectors with the internally generated values to detect external or internal equipment malfunction. If the values do not agree, Cygnus 2 takes the following action:

If the DAC output is assigned for Source control:

- Stop the Material.
- Display Source Fault message.
- Set this Source Output to zero.

If the DAC output is assigned for Recorder use:

- Set this output to zero.
- Display Recorder Fault message.

Both types of faults remain active until a RESET is performed.

# 3.5.11 Trend Analysis

Along with control of the deposition process, Cygnus 2 allows rate and thickness information from individual quartz crystal sensors to be output to the Digital-to-Analog (DAC) outputs. This enables mapping of an individual sensor's information, which is useful in monitoring the change in source flux distribution during the deposition process.

#### 3.5.11.1 Cygnus 2 Parameters Associated with the Trend Analysis Feature

**RECORDER OUTPUT....** 0 to 12

This parameter designates which of the DAC outputs is to be used as a recorder output. 0 indicates there is not a DAC identified with this particular Material. Values 1 through 6 correspond to the six DAC BNC outputs on the back of the Cygnus 2 labeled DAC 1 to DAC 6. DAC outputs 7 to 12 require the optional DAC outputs card.

## SENSOR RECORDER FUNCTION. Rate/Thick/RateDev

This parameter determines the function of the Sensor's recorder output. Default is (Unfiltered) Rate, not affected by the Rate Filter Time.

#### RECORDER RANGE...... 0 to 99999

The full scale range value selected corresponds to the value selected in the General/DACs page for the DAC output. Default value is 100.

A recorder output cannot be associated with a DAC that is configured as a Source output. An error message will be displayed if this is attempted.



# Chapter 4 Sensor and Source Set-Up

# 4.1 Sensor Set-Up Introduction

The basic Cygnus 2 has one sensor measurement board with two Sensor channels, identified as CH1 and CH2 on the Cygnus 2 back panel and as Sensor # 1 and Sensor # 2 on the display screens. Two more sensor measurement boards can be added to support up to six sensors. The second sensor measurement board will be installed in the next slot labeled CH3 and CH4 and the associated sensors will be Sensor# 3 and Sensor# 4 etc. Each Sensor connection requires an external oscillator (XIU) package.

Sensor Set-Up is initiated by moving the cursor to the Sensor heading on the Main Menu and pressing MENU. To return to the Main Menu display, press MENU again.

# 4.1.1 Sensor Display Navigation

The Sensor Overview display, see Figure 4-1, shows the current configuration of all six possible Sensors even if only one measurement board is installed.

To make changes, use the left/right cursor to move to the appropriate Sensor, then press F1 Select Sensor to bring up that Sensor's screen. See Figure 4-2.

Sensor # 5 Overview Sensor Type Single XtalTwo Xta1Six Xta112 Generic Single Switch Out Sensor 0 0 0 Shutter Out 0 0 0 Auto-Z No No No No No Recorder Output 10 11 Function Thick Rate Thick Rate Rate Rate 100 100 100 100 Range 100 100 # Positions 10 # Pulses Pulse On 1.0 1.0 1.0 1.0 1.0 1.0 Pulse Off 1.0 1.0 1.0 Crystal Fail Carousel Open 4 Sensor 02/05/2011 11:33 Sensor

Figure 4-1 Sensor overview



Figure 4-2 Sensor parameter editing

0.0	000Å/s 2.3	60 <sub>kå</sub> 0.	00%	READY
Overview	Sensor Number	5		
Sensor	Sensor Type Switch Out	Generic 4	# Positions # Pulses	10 1
	Shutter Out	0	Pulse On	1.0 s
	Auto-Z	No	Pulse Off	1.0 s
	Recorder Settings			
	Output	_ 11		
	Function Range	Rate 100		
Sensor		Carousel Op	en 4	Crystal Fail 2
02/05/2011	13:40			0.00

## 4.1.2 Sensor Parameters

Values in brackets are used with the remote communication commands. This parameter enables the Crystal Switch feature for the multi-position heads and enables the crystal indexing feature on the handheld controller. If a multi-position sensor is selected, the Switch Out parameter appears. Additional parameters appear for a Generic type, see section 1.4.3.2, Sensor Parameters, on page 1-7. This parameter cannot be changed while executing a process.

#### 

This parameter appears when the Sensor type is not Single. It designates which of the 38 outputs is to be used as the Crystal Switch output for this Sensor. Values 1 through 38 correspond to the appropriate output. Value 0 indicates that the Crystal Switch Output is not used. The default value is 0. If a value other than 0 is entered, the output chosen as the Crystal Switch output is designated as such on the Digital I/O display. The default setting for the contact closure on this output is Normally Open.



#### **SHUTTER OUT** . . . . . . . . . . . . 0 to 38

This parameter designates which of the 38 outputs is to be used to activate the Crystal Shutter for this Sensor. Values range from 0 to 38. Values 1 through 38 correspond to the appropriate output. Value 0 indicates that a shutter is not used. The default value is 0. If a value other than 0 is entered, the output chosen as the Crystal Shutter output is designated as such on the Digital I/O display. The output is set to be true as long as the Material containing the Sensor is in SHUTTER DELAY, DEPOSIT, NON DEPOSIT CONTROL, MANUAL, or in the Sample period of the RateWatcher function. The condition remains true until the end of POST DEPOSIT, TIME POWER, and HOLD, or until a STOP command is received, or during the Hold period of the RateWatcher function.

#### **Auto-Z** . . . . . . . . . . . . . . . . . No (0), Yes (1)

This parameter designates the method in which the Z-Ratio value will be obtained for use in computing thickness with this Sensor. No indicates that the Z-Ratio established in Material Definition is used. Yes indicates that the Auto-Z calculation feature of the system is used. Auto-Z cannot be enabled on a crystal which is "unable to Auto-Z". Refer to section 3.5.3 on page 3-29 for details on why a crystal is unable to Auto-Z. The default value is No for the Material Z-Ratio.

#### Recorder Settings

OUTPUT	0 to	12
	 U LU	1 4

This parameter designates which of the DAC outputs is to be used as this Sensor's recorder output. Values range from 0 to 12. 0 indicates there is no DAC used with this Sensor. Values 1 through 6 correspond to the six DAC BNC outputs on the back of the Cygnus 2 labeled DAC 1 to DAC 6. DAC outputs 7 to 12 require the optional DAC output card.

**FUNCTION**..... (Unfiltered) Rate (0), Thick (1), RateDev (2)

This parameter determines the function of the Sensor's recorder output. Default is 0 for the unfiltered Rate, not affected by the Rate Filter Time.

RANGE ..... 0 to 99999 (for Rate and Thick)

The full scale range value selected corresponds to General Parameter DAC Scale and Polarity. Default is 100. Grayed out if RateDev is selected.



# 4.2 Source Set-Up Introduction


Cygnus 2 provides the capability to configure the six Source control channels. Each Source control channel is treated as an individual device.

Source Set-Up is initiated by moving the cursor to the Source heading on the Main Menu and pressing MENU. You may return to the Main Menu display by pressing MENU again.

# 4.2.1 Source Navigation

The Source Overview page shows the current configuration of all six Sources.

Figure 4-3 Source overview page



To make changes, use the left/right cursor to move to the appropriate Source, then press F1 Select Source to display that Source's screen



#### 4.2.2 Source Parameters

Figure 4-4 Source parameter page

-0.0	13 <sub>k/s</sub> 2.366	6 <sub>kå</sub> 0.00 <sub>%</sub>	READY
Overview	Source Number	1	
Source	DAC Output	1	
	Shutter Output	0	
	Number of Crucibles Crucible Output Turret Feedback Turret Input Turret Delay	One 0 No 0 5 s	
Source		Carousel Open 4	Crystal Fail
02/05/2011	13:47		

The following parameters can be edited for each of the 6 Source control channels.

SOURCE NUMBER . . . . . . . . . . . 1 to 6

Enter the number of the Source to be edited.

**DAC OUTPUT** . . . . . . . . . . . 0 to 12

This parameter designates which of the DAC outputs is to be used as a Source output. Values range from 0 to 12, with 0 indicating there is no DAC identified with this particular Source. Values 1 through 6 correspond to the six DAC BNC outputs on the back of the Cygnus 2 labeled DAC 1 to DAC 6. DAC outputs 7 to 12 require the optional DAC outputs card.

SHUTTER OUTPUT ..... 0 to 38

This parameter designates which of the 38 outputs is to be used as the Source Shutter relay. Values range from 0 through 38. 0 indicates that a shutter is not used and values 1 through 38 correspond to the appropriate relay or open collector type output. The default value is 0. If a value other than 0 is entered the relay chosen as the Source Shutter relay is designated as such in the Digital I/O Display. When running a Material containing the Source for which the Shutter Output parameter is programmed, the logic condition is set to be true when the Material is in DEPOSIT, TIME POWER, RATE RAMPS or MANUAL. The condition remains true until the end of DEPOSIT or until a STOP command is received.



#### **NUMBER OF CRUCIBLES** . . . . . . One(0), Four(1), Eight(2), 16(3), 32(4), 64(5)

Values in brackets are for use with remote communication commands. Refer to section 3.5.2, Source/Crucible Selection, on page 3-28 for an example of programming Turret source crucible selection. This parameter can be used to automatically index the turret position when using a multiple pocket turret source. The value is selected using the TOGL and ENTER keys. The default value is 0 and indicates a single pocket source. If a 0 is chosen, the parameters Crucible Output, Turret Feedback and Turret Delay or Turret Input are grayed out on the Display. The number of crucibles determines the number of relays needed for the crucible output. As the relays are binary encoded (actual coding is binary - 1, with 000 representing position 1 and 111 representing position 8), 2 relays are needed for 4 crucibles, 3 for 8, 4 for 16, 5 for 32 and 6 for 64.

#### CRUCIBLE OUTPUT . . . . . . . . . 0 to 37

This parameter designates which of the outputs are to be used as Crucible Outputs. Values range from 0 to 37. The default is 0 and indicates the Crucible Output is inactive. The value entered into this parameter indicates which of the outputs begins the sequence of outputs used as crucible control outputs. For example, a Four(1) entered into the Number of Crucibles parameter and a 1 entered into the Crucible Output parameter will designate output relays 1 and 2 as crucible control outputs with the least significant bit of the binary coding in relay output 1. An Eight(2) entered into the Number of Crucibles parameter and a 1 entered into the Crucible Output parameter will designate output relays 1, 2, and 3 as crucible control outputs with the least significant bit of the binary coding in relay output 1.

#### TURRET FEEDBACK . . . . . . . . . Yes (1), No (0)

Some turret source indexers provide feedback to signify when the turret is in the proper position. This parameter allows Cygnus 2 to accept this input and respond accordingly. Parameter entry may be either Yes or No. Yes indicates that Turret Feedback is expected and the Turret Input parameter is displayed on the screen. No indicates there is no Turret Feedback. The default value is No. See the Turret Input and Turret Delay descriptions below.

**NOTE:** If the turret feedback is set to Yes and the Material is STARTed, Cygnus 2 will proceed to the CRUCIBLE SW state. If the turret input is not received within the Turret Delay time, the Material will STOP.

#### 

This parameter designates which of the 28 inputs is to be the Turret Feedback input. Values range from 0 to 28. Values 1 through 14 correspond to the appropriate input on I/O Relay Module 1, values 15 to 28 require the I/O Relay Module 2. Value 0 indicates that an input for turret feedback is not used. The default value is 0. However, an input must be assigned or the state sequence



will never proceed past the Source switching state. If a value other than 0 is entered, the input chosen as the Turret Input is designated as such on the Digital I/O display. Input lines are activated with a contact closure to ground.

#### **TURRET DELAY** . . . . . . . . . . . 2 to 180 s

The Turret Delay time sets the maximum amount of time the Process will remain in CRUCIBLE SW(itch), waiting for rotation to complete without turret feedback before proceeding to the pre-condition state. If a Turret Input signal is expected (Turret Feedback = Yes) this is the time Cygnus 2 will wait to receive the input signal. If the signal is not received within this time, Cygnus 2 will stop. If the Turret Input becomes active during the delay time, processing continues immediately. Permissible values are 2 to 180 seconds. The default value is 5 seconds.



#### **CAUTION**

Cygnus 2 will proceed to the Pre-Condition state after the Turret Delay time expires. This could result in damage to your equipment if the crucible is not in position after expiration of the Turret Delay time.

# 4.3 DAC Output Selection Rules

The six standard DAC outputs, DAC 1 to DAC 6, located on the back of the Cygnus 2 and the six optional DAC outputs, DAC 7 to DAC 12, may be used for rate control or to record rate, thickness and rate deviation. Since these outputs can be set up for different functions, certain rules apply.

- No DAC output can be set up as both a recorder output and a Source output.
   If this is attempted, an error message will be displayed.
- A DAC output cannot be set up for more than one Source. If this is attempted the error message DAC Used Source # will be displayed.
- A DAC output can be set up for more than one recorder output including any combination of Material or Sensor recorders Rate/Thickness or Sensor Rate/Thickness.
- If a DAC output is set up for multiple recorder outputs that are required to be operative at the same time, the error message Recorder Conflict will appear.
   This is a non-fatal error (that is, it will not cause Cygnus 2 to STOP) and the message will remain until the conflict is resolved or a STOP takes place.

The priority of a recorder output that is in conflict is:

- a. Filtered Rate/Thickness on the Material
- b. Sensor Unfiltered Rate/Thickness from Sensor.



# Chapter 5 Material Set-Up

# 5.1 Introduction

Cygnus 2 can store definition parameters for up to 6 Materials. Any Material that is to be used must be defined. Materials can be defined by referencing the internal Material Library containing more than two hundred cataloged materials and by completing a series of parameter entries at the front panel.

Material Set-Up is initiated by moving the cursor to the Material heading on the Main Menu and pressing MENU. To return to the Main Menu screen, press MENU again.

# 5.1.1 Material Overview Page

The Material Overview display, see Figure 5-1, shows all 6 available Materials. Materials are initially shown as Material 1 to Material 6. Use the right arrow cursor to move into the Material table.

Overview 1 Material 1 Source 2 Material 2 Sensor 3 Material 3 Pre/Post 4 Material 4 Deposit 5 Material 5 6 Material 6 Lib A-Hf Lib Hf-Sc Lib Sc-Z Carousel Open 4 Crystal Fail 1 Material 02/05/2011 11:46 Select Material

Figure 5-1 Material overview display

With the cursor on one of the 6 Materials, press F1 Select Material. See Figure 5-3 on page 5-3. The screen changes to show the Material screen. To assign one of the chemical formulas with its correct density and Z-Ratio values to this Material #, move the cursor to the appropriate library display: Lib A-Hf, Lib Hf-Sc or Lib Sc-Z.



#### 5.1.2 Material Definition

Figure 5-2 Material library A - Hf display

	lu	0.000					
<b>0</b>	Material	Paradil sama	C41				
Overview	Density	10.500	Silver	A D-414	0-1		
6	Z-Ratio	0.529	(*) Indica	tes Default	. value		
Source	40.	B000	D : 000	CaTiO3	•	00	0.1.
	Ag	B203	B1203		Cr	CuS	Ga As
Sensor	AgBr	B4C	B1253	CaW04	Cr203	Dy	GaN
D /D /	Ag C 1	BN	Bi2Se3	Cd	Cr3C2	Dy203	GaP
Pre/Post	A1	Ba	Bi2Te3	CdF2	CrB	Er	GaSb
400000000000	A1203	BaF2	BiF3	CdO	Cs	Er203	Gd
Deposit	A14C3	Ba N 206	C	CdS	Cs2504	Eu	Gd 203
	A1F3	Ba O	C	CdSe	CsBr	EuF2	Ge
Lib A-Hf	AIN	BaTi03	C8H8	CdTe	CsC1	Fe	Ge3N2
	A1Sb	BaTi03	Ca	Ce	CsI	Fe203	Ge02
Lib Hf-Sc	As	Be	CaF2	CeF3	Cu	Fe0	GeTe
	As2Se3	BeF2	Ca O	CeO2	Cu 20	FeS	Hf
Lib Sc-Z	Au	Be0	CaOSiO2	Co	Cu2S	Ga	HfB2
	В	Вi	CaS04	CoO	Cu2S	Ga 203	HfC
ateria	1 1		Carouse	l Open 4			Crystal Fail
2/05/2011	13:54						-

The three Material Libraries—Lib A - Hf, Lib Hf - Sc and Lib Sc - Z—provide an alphabetic list of materials by chemical name along with their density and Z-Ratio. Once a Material is selected from the library listing by moving the cursor to it, press F1 Define Material. The correct chemical formula and library name, density and Z-Ratio values will now be imported to this Material # and the Material/Source page will appear. To rename this Material, cursor to the name and use the keys in cell-phone format to enter up to 15 characters.

To move among and through the Materials, use the four cursor keys.



# 5.1.3 Material Source Page Parameters

Figure 5-3 Material source screen

Overview	Material Number Name Material 1	1		Crucible	1	
Sensor	Density Z-Ratio Control Loop	1.000 1.000 NonPID	g/cc	Maximum Power Max Power Option	90.00 STOP MATL	*
Pre/Post	Process Gain	10.000	Å/s/%	Minimum Power	0.00	*
Deposit Lib A-Hf Lib Hf-Sc	Time Constant Dead Time	1.000 1.000	S S	Recorder Output Recorder Function Recorder Range	0 Rate 100	
Lib Sc-Z lateria	 n1 1	Carouse	1 Open 4	4	Crystal 2	Fai1

Change the number to edit or create a different Material.

The default will be Material #. The default name is returned as a blank entry when queried via communications. Materials selected from the library will be shown by their chemical formula. The Name can be edited using the keys in cell-phone fashion.

**DENSITY** . . . . . . . . . . . . . 0.100 to 99.999 g/cc

This parameter is specific to the material being deposited onto the Crystal. It is one of two parameters that relate the mass loading on the crystal to a thickness. If a material is chosen from the Material Library, the density is automatically entered. The default value is 1.000.

This parameter is specific to the material being deposited. It is one of two parameters that relate the mass loading on the crystal to a thickness. If a material is chosen from the Material Library the Z-Ratio is automatically entered. The default value is 1.00. This parameter is superseded if Auto-Z-Ratio is selected in Sensor Set-Up.



#### **CONTROL LOOP** . . . . . . . . . NonPID (0), PI (1), PID (2)

The bracketed value is used for changing the setting via the remote communications commands. This parameter establishes the control loop algorithms pertaining to either a slow responding source or a fast responding source. The default value is NonPID (0).

**NonPID** is best for fast and medium speed responding systems with **high noise** levels (for example, an electron beam gun with or without a liner, having a large sweep amplitude of low frequency, 10 Hz or less).

**PI** is best for fast, medium, or slow systems with **medium noise** levels (for example, an electron beam gun with medium sweep amplitude frequency, 20 to 100 Hz; also, sputtering and resistive sources).

**PID** is best for fast, medium or slow systems with **low noise** levels (for example, an electron beam gun with sweep off or at a high frequency, 100+ Hz, and sputtering and resistive sources).


#### PROCESS GAIN . . . . . . . . . . 0.010 to 999.990 Å/s/% pwr

This parameter determines the change in % Power for a given rate deviation (dRate/dPower). The larger the Process Gain value, the smaller the change in power for a given rate error. Process Gain is calculated by dividing the change in rate caused by the corresponding change in power. The default value is 10.00.

#### **TIME CONSTANT** . . . . . . . . . . 0.010 to 9999.99 s

This is the evaporation source's time constant. This value is defined as the time difference between the actual start of a change in rate and the time at which 63% of the rate step is achieved. This value may be measured according to the above criterion or it may be determined empirically. The default value is 1. This parameter is disabled if the CONTROL LOOP option parameter is set to 0 (NonPID).

Figure 5-4 Time constant






**DEAD TIME** . . . . . . . . . . . . . . . . 0.010 to 9999.99 s

This value is defined as the time difference between a change in % power and the start of an actual change in rate. The default value is 1.0. This parameter is disabled if the CONTROL LOOP option parameter is set to 0 (NonPID).

Figure 5-5 Control delay time DT



CRUC(IBLE) ...... 1 to 64

The Crucible parameter is used in conjunction with the Number of Crucibles selected in Source Set-Up. The value entered sets the state of the Crucible relays. Values range from 1 to the number of Crucibles chosen, up to a maximum of 64. This parameter is set to 1 if the Crucible function is not chosen in configuring the Sources. The default value is 1.

#### **MAXIMUM POWER** . . . . . . . . . 0.01 to 99.99%

This parameter is used to set the maximum permissible % power level. The control voltage output will not exceed this limit. The default value is 90.00%.

MAX POWER OPTION . . . . . . . . Continue (0), Post-Dep (1), Stop All (2), Stop Matl (3)

This parameter provides a safety feature.

- 0 = Continue. Allows the Material to continue in its current state.
- 1 = PostDeposit. The Material will proceed to the programmed post deposit state(s).
- 2 = Stop All. Source control voltages for all Materials are set to zero.
- 3 = Stop Material. Source control voltage for the designated Material is set to zero.

The default setting is Stop Matl (3).



MINIMUM POWER ..... 0.00 to 99.98%

This parameter is used to set the minimum permissible % power level. It must be less than the Maximum Power value. The control voltage output will not exceed this limit. The default value is 0.00%.

**RECORDER OUTPUT....** 0 to 12

There are twelve (six standard, six optional) DAC outputs available which may be divided among Source control voltage outputs, individual Sensor rate/thickness recorder outputs, aggregate rate/thickness or power level recorder outputs. A value of zero indicates there is not a recorder output chosen for that function. Values 1 through 6 correspond to the six DAC BNC outputs on the back of the Cygnus 2 labeled DAC 1 to DAC 6. DAC outputs 7 to 12 require the optional DAC outputs card. The default value is zero for Filtered Rate, see Rate Filter Time in section 5.1.7.

**RECORDER FUNCTION** . . . . . Filtered Rate (0), Thick(ness) (1), RateDev(iation)(2), Power (3)

Default is Zero.

**RECORDER RANGE**...... 0 to 99999 (for Rate and Thick)

Selects the full scale value in the appropriate units, Parameter is grayed out for RateDev and Power. Units are Å/s for Rate and Å for Thickness. Default value is 100. Full scale values are fixed at  $\pm$  10 or 20 Å/s for Rate Deviation, depending on what was selected on the Operate screen and 100% for Power.



# 5.1.4 Material Sensor Parameters Page

Figure 5-6 Material sensor page

Overview	Material Number	1	Quality Percent Quality Counts	0 % 0
Source Sensor	Master Tooling	100.0 %	Stability Single Stability Total	0 Hz 0 Hz
Pre/Post				
Deposit	Xtal Position First Xtal Position Last	0		
Lib A-Hf	Failure Action	STOP MATL		
Lib Hf-Sc	CrystalTwo Tooling	100.0 %		
Lib Sc-Z				
lateria	1 1	Carousel Op	en 4	Crystal Fai
2/06/2011				

MATERIAL NUMBER ..... 1 to 6

Change the number to edit or create a different Material.

Tooling is a correction factor used for correlating the rate and thickness accumulation on the crystal with the thickness accumulation on the substrate. This thickness difference is due to the geometric distribution of material flux from the source.

The MASTER TOOLING factor is calculated using equation [1].

TOOLING = 
$$TF_i \times (T_m/T_x)$$
 [1]

where  $TF_i$  = Initial Tooling Factor,  $T_m$  = Actual Thickness at the Substrate, and  $T_x$  = Thickness on the Crystal.

The default value is 100%.

If the TOOLING is changed, the new TOOLING value is used for subsequent calculation of the individual as well as aggregate rate and thickness. Also, the thickness accumulated thus far will be re-scaled based on the change to the TOOLING.



#### If the Sensor type is XtalSix (CrystalSix) or Xtal12 (Crystal12)

XTAL POSITION FIRST . . . 0 to 6 (12 for Xtal12)

XTAL POSITION LAST. . . . 0 to 6 (12 for Xtal12)

If all available positions are to be used for this Material, set both values to 0. Otherwise, enter values to select the set of positions to use for this Material. Permissible values for a CrystalSix are 0 to 6, 0 to 12 for a Crystal12. Default is 0.

If an out-of-range position condition results when a Sensor type is changed, the position values will be defaulted to 0.

(SENSOR) FAILURE ACTION. . . . . PostDp (1), Stop All (2), Stop Matl (3), TimePw (4)

Desired process change when the Sensor fails. PostDp (1) continues into post-deposit states. In Stop All (2), all Source control voltages will be set to zero. In Stop Material (3), only the associated Material will enter the stop state. Its Source control voltage will be set to zero. TimePw (4) continues to Final Thickness using stored average power and rate. The default setting is Stop Material (3).

#### **CRYSTALTWO TOOLING..........** 1.0 to 999.9%

This parameter applies only if the Sensor type is XtalTwo (CrystalTwo). Sets the Tooling factor when a dual sensor or two single sensors are connected to the same Sensor channel using a CrystalTwo switch. Default value is 100%.

#### **QUALITY PERCENT** . . . . . . . . . 0 to 99% and >0.5 Å/s

Quality Percent selects the permissible rate deviation in percent of the measured rate relative to the desired rate. The default value is 0% which disables the function.



#### **QUALITY COUNTS** . . . . . . . . . . 0 to 99

This sets the number of measurements that must be outside the allowed Quality Percent before the crystal is declared failed. If the rate deviation relative to the 2.5 sec average rate is greater than the programmed Quality Percent limit, the Counts value is incremented. If the rate deviation is less than the programmed Quality Percent, the Counts value is decremented. Counts are not allowed to have negative values. If Counts exceeds the value programmed, Cygnus 2 will automatically crystal switch, complete the process on TIME-POWER, POST DEP, or STOP the process. The rate deviation is computed on each individual rate measurement during the deposit phase, that is, every 100 ms. Upon entering Deposit, the Quality Count is delayed by five seconds. The Q Count on the Sensor Information screen will show DLY (delay) when in pre-deposit, and during the delay period at the beginning of Deposit.

The default value is 0, which disables the function.

**NOTE:** After a crystal fails due to exceeding the Counts value, the Crystal Fail can be cleared by installing a new crystal or pressing the F3 key to Clear S and Q counts on the Sensor Information screen. This action must be repeated for each Sensor used by cursoring to the appropriate Sensor number.

**STABILITY SINGLE**...... 0 Hz and 25 to 9999 Hz (Values 1 to 24 are not allowed)

This sets the maximum permissible increase in frequency from one measurement to the next that will cause a crystal fail. The default value is 0 Hz which disables the function.

This sets the maximum total permissible increase in frequency accumulated during the active Material that will cause a crystal fail. The default value is 0 Hz which disables the function.

**NOTE:** After a crystal fails due to exceeding the allowable Hz value, the Crystal Fail can be cleared by installing a new crystal or pressing the F3 key to Clear S and Q counts on the Sensor Information screen. This action must be repeated for each Sensor used by cursoring to the appropriate Sensor number.



# 5.1.5 Pre/Post Screen Deposit Page Parameters

Figure 5-7 Material pre/post page

Overview						
	PreCon Rise Time	00:00	mm:88	Delay Option	None	
Source	PreCon Soak Power	0.00	*	Control Delay Time	00:00	mm:ss
	PreCon Soak Time	00:00	mm:88	Shutter Delay Accur	5	%
Sensor						
	Rise Time 1	00:00	mm:88			
Pre/Post	Soak Power 1	0.00	*			
	Soak Time 1	00:00	mm:88			
Deposit				Feed Ramp Time	00:00	mm : 8
	Rise Time 2	00:00	mm:88	Feed Power	0.00	*
Lib A-Hf	Soak Power 2	0.00	*	Feed Time	00:00	mm:s
	Soak Time 2	00:00	mm:88	and the state of t		
Lib Hf-Sc	(1949)			Idle Ramp Time	00:00	mm : 3 :
	Auto Soak 2	No		Idle Power	0.00	*
Lib Sc-Z	Dep After Pre-Dep	Yes				
lateria	1 1	Carouse	1 Open 4	4	Crystal 2	Fail

#### MATERIAL NUMBER ..... 1 to 6

Change the number to edit or create a different Material

**NOTE:** The first power ramp consisting of Pre-Cond Rise and Pre-Cond Soak is skipped if the Idle power is nonzero.

This parameter provides the time period over which the Source power is ramped from 0 to Pre-Cond Soak Power. The default values is 00:00.

**PRECON SOAK POWER** . . . . . . . 0.00 to 99.99%

This parameter is usually set to the power level at which the source material just begins to glow. Cygnus 2 ramps the power level from zero to Pre-Cond Soak Power linearly over the time period Pre-Cond Rise Time. The default value is 0. If set to a value greater than Maximum Power, Maximum Power has priority.

PRECON SOAK TIME........... 00:00 to 99:59 min:s

This parameter provides the time period for which Cygnus 2 holds at Precon Soak Power. The default value is 00:00.



This parameter provides the time period over which the power is ramped from 0 or from Precon Soak Power if programmed to Soak Power 1. The default values is 00:00.

**SOAK POWER 1** . . . . . . . . . . 0.00 to 99.99%

This parameter is usually set to the power level at which the material just begins to melt. Cygnus 2 ramps the power level from zero or Precon Soak level if programmed to Soak Power 1 linearly over the time period Rise Time 1. The default value is 0. If set to a value greater than Maximum Power, Maximum Power has priority. See section 3.5.5.1for information on determining appropriate Soak Power using the optional Handheld Controller (IPN 755-262-G1).

This parameter provides the time period for which Cygnus 2 holds at Soak Power 1. The default value is 00:00.

This parameter sets the time period in which Cygnus 2 linearly ramps the power level from Soak Power 1 to Soak Power 2. The default value is 00:00.

**SOAK POWER 2** . . . . . . . . . . . 0.00 to 99.99%

This parameter sets the power level at which the rate from the Material very nearly matches the desired deposition Rate. Cygnus 2 can ramp the power level if programmed from zero, from idle power, from Soak Power 1 linearly to the Soak Power 2 level over the time period RISE TIME 2. The default value is 0%. If set to a value greater than Maximum Power, Maximum Power has priority.

This parameter sets the time period for which Cygnus 2 holds the power level at Soak Power 2. The default value is 00:00.

**AUTO SOAK 2.....** Yes (1), No (0)

The Auto Soak 2 option, when enabled by selecting Yes (1), calculates an average power setting during the DEPOSIT state. This average power replaces the value programmed in Soak Power 2 so the next time this Material is executed, the Soak Power 2 level is the Auto Soak 2 value. In this manner the Soak Power 2 value closely matches the power level required to achieve the desired deposition rate. The power is the average over the interval defined under the Time Power Averaging Time parameter, see section 5.1.7. The default value is No (0).



#### **DEP AFTER PRE-DEP** . . . . . . Yes (1), No (0)


Selects the state to follow the last Soak. Standard processing will continue with Deposit. In special cases, No (0) or Non-deposit control may be appropriate. In this state, the rate is controlled but thickness is not incremented and the Source shutter relay is not active. Default is Yes(1) for Deposit.



#### CAUTION

The Sensor must be positioned so the rate can be monitored with the Source shutter closed when going to the non-deposit control state.

Figure 5-8 Source power level profile



The default value is None (0).

**Shutter (1)**: The Source shutter relay remains in its normal state and the crystal shutter relay is active. The Sensor, which must be positioned to sample the source flux with the Source shutter closed, provides closed loop rate control. The rate control must be within the specified Shutter Delay Accuracy or 0.5 Å/s of the desired deposition rate for 5 seconds before Cygnus 2 will enter the DEPOSIT state, opening the Source shutter and thus exposing the substrate to a well controlled rate of evaporant flux. If the required rate control accuracy cannot be achieved within 60 seconds, the Material will STOP.

**Control (2):** Control delay suspends DEPOSIT control loop action on the Source control power for the time interval programmed in Control Delay Time. During Control Delay, the Source and Sensor shutters are activated.

**Both (3):** Cygnus 2 will first enter a shutter delay state followed by the control delay interval.



#### **CONTROL DELAY TIME** . . . . . . . . . . 00:00 to 99:59

This is the time interval for Cygnus 2 to be held in the Control Delay state. The parameter is displayed only if the Delay Option chosen is Control or Both. The default value is 00:00.

#### SHUTTER DELAY ACCURACY ... 1 to 99%

Specifies how close the rate value must be to the setpoint value for 5 seconds before opening the Source shutter. The parameter is displayed only if the Delay Option chosen is Shutter or Both. The default value is 5.

# 5.1.6 Post Deposit Parameters

#### **Feed Ramp State**

The next three parameters define a feed ramp provided to maintain power levels during a wire feed. After reaching Final Thickness, Cygnus 2 will enter the Feed Ramp state for the specified time. Control voltage is ramped from the power level at the end of the DEPOSIT state to the Feed Power level. Feed Power is held constant until the end of Feed Time. At the end of Feed Time, Cygnus 2 will proceed to the Idle ramp state. Source and Sensor shutter are inactive.

#### **FEED POWER** . . . . . . . . . . . . . . . 0.0 to 99.99%

This is one of three parameters used to affect a Feed Ramp. This value establishes the control voltage power level at which the Source is maintained during wire feed. The default value is 0. If set to a value greater than Maximum Power, Maximum Power has priority.

#### **FEED RAMP TIME.....** 00:00 to 99:59 min:s

This is the time interval for the Source power to ramp linearly from the power level at the end of Deposit to Feed Power level. The Feed state is active during Feed Ramp Time. The default value is 00:00.

#### 

This is the time interval for which the Source power is maintained at Feed Power. The Feed state is active during Feed Time. The default value is 00:00.

#### **Idle Ramp State**

The next two parameters define an idle ramp provided to establish the Source power level after the Deposit or Feed state. Control voltage is ramped from the power level at the end of the Deposit state (or Feed Power, if one is set) to the Idle Power level. The control voltage is maintained at the Idle Power level until Cygnus 2 enters the STOP state or until the next Material, using the specified Source, is started, or the turret source is rotated.



This value is the power level at which the Source is maintained after the DEPOSIT state (or after Feed state if one is set up). Idle Power is usually the same as Soak Power 1. The default value is 0%. If set to a value greater than Maximum Power, Maximum Power has priority. The power level will be set to zero before a crucible switch is done.

**IDLE RAMP TIME** . . . . . . . . . . . . . . . . . 00:00 to 99:59 min:s

This is the time interval over which the Source power is ramped linearly from the power level at the end of Deposit (or Feed state if one is set) to Idle Power. The default value is 00:00.

# 5.1.7 Deposit Page Parameters

Figure 5-9 Material deposit page

	Material Number	1				
Overview	20.00	700000000		120 0 120 0	5100 St 200702	
100	Rate	1.234		Ramp 1 Rate	2.345	
Source	Time Limit	99:59	mm:88	Start Ramp 1	0.123	1000000
_	Rate Filter Time	Ten	S	Ramp 1 Time	00:30	mm:s
Sensor						
	Time Power Avg Time	5	Min			112
Pre/Post	Ion Assist Deposit	No		Ramp 2 Rate	0.234	
	On Final Thickness No	onDepCnt1		Start Ramp 2	0.234	kÅ
Deposit				Ramp 2 Time	00:30	mm : s
Lib A-Hf	Final Thickness	1.234	kÅ	RateWatcher		
	Thickness Limit	0.500	kÅ	Option	No	
Lib Hf-Sc				Time	00:00	mm:s
				Accuracy	5	%
Lib Sc-Z						
ateria	1 1	Carouse	1 Open	4	Crysta1	Fai1
ateria					2	Marin.

#### MATERIAL NUMBER ..... 1 to 6

Change the number to edit or create a different Material

**RATE** . . . . . . . . . . . . . . . 0.000 to 999.9 Å/s (default = 0.000)

**NOTE:** Rate = 0.000 will take a Material in control to post-Deposit state. This specifies the rate at which the deposition is to be controlled during the DEPOSIT and NON-DEPOSIT CONTROL states. The Rate is calculated

based on:

- The rate information acquired by the Sensor in use, based on the density and Z-Ratio values entered for this Material.
- The tooling factors that correct for any relative difference in flux distribution reaching the Sensor used for this Material.



This is the deposition time at which the Time Limit is triggered. This time begins to accumulate at the start of the Deposit state. The Time Limit, once triggered, remains active until the start of the IDLE state. The default value is 00:00.

**RATE FILTER TIME**..... One Tenth (0), Four Tenths (1), One (2), Four (3), Ten (4), Twenty (5), Thirty (6) seconds

This parameter is used to apply a boxcar filter to the measured raw rate which is used to produce the Rate DAC output voltage.

The Rate Filter Time may be used for enhanced resolution. If a source has a long time constant, rate may be taken as constant over longer intervals. Averaging provides an opportunity to reduce rate noise. Depending on the source of the noise, averaging can improve rate resolution:

- If the noise is crystal frequency resolution limited—the thickness change over one second provides ten times the thickness change vs. the thickness change measured over a tenth of a second. A one second averaging interval will improve rate resolution by 10 times.
- If the sensor noise is random, then RMS reduction of rate noise is provided by the square root of the number of point's averaged (example a 10 point average provides a factor of 3.1 noise reduction).

The selection of the appropriate Rate Filter Time value will be dependent on the characteristics of the source. The default value is One Tenth.

#### TIME POWER AV(ERA)G(ING) TIME0 to 30 min. (default = 0)

This parameter value determines the amount of time used in calculating the average rate and average power for use in Time Power and for Auto Soak 2.

The Averaging Time parameter is the time interval used to calculate both the average rate and average power applied, if a crystal fails, for Time-Power and Non-Deposit Hold states. When the Averaging Time parameter value is 0, then a 2.5 second average, ignoring the most recent 0.5 second, is the averaging interval.

The status message ABBR(EVIATED) AVERAGE is generated if the averaging interval has not been reached, but there was at least a complete whole minute of data to average.

The status message NO or NEG AVERAGE is generated and Stop is entered if a crystal fail occurred within the first minute of control with Averaging Time set >0. This error also occurs if there is a crystal fail during the first 2.5 seconds of control with the Averaging Time = 0. (There are also remote communication commands to get and set the average rate and average power values.)



ION ASSIST DEPOSIT ......... No (0), Yes (1).

Sets the logic condition to True if Yes (1) is selected and the Deposit state is entered. Default is No (0).

ON FINAL THICKNESS. . . . . . . . . Continue (0), Post-Dep (1), NonDepCntl (2).

Selects the state to enter after reaching Final Thickness. Standard processing will continue with Post-Deposit (1), the default setting. In special cases, Non-Dep(osit)Cntl(Control) (2) may be appropriate. In this state, the rate is controlled but thickness is not incremented and the Source shutter relay is not active. Continue (0) ignores reaching Final Thickness but the logic condition is set to True.



#### CAUTION

The Sensor must be positioned so the rate can be monitored with the source shutter closed when going to the non-deposit control state.

#### FINAL THICKNESS . . . . . . . . . . . 0 to 999.99 kÅ

This is the thickness setting that triggers the end of the DEPOSIT state. A value of 0.000 kÅ allows skipping the deposit state. The Source Shutter and Sensor Shutter relays return to their normal states and the Material enters the Idle Ramp or the Feed Ramp state. The default value is 0.000 kÅ, see Skip Deposit, section 5.2.1.

#### THICKNESS LIMIT . . . . . . . . . . 0.0 to 999.99 kÅ

This sets the thickness at which the Thickness Limit logic state is set True. This thickness begins to accumulate after entering the Deposit state. The state remains active after reaching Thickness Limit until the beginning of the IDLE state. The default value is 0.000 kÅ.

#### **RAMP 1 RATE.....** 0.000 to 999.9 Å/s

Rate Ramp 1 is provided to effect a rate change while depositing a Material. The aggregate rate is ramped linearly from the original rate setpoint to the New Rate 1 value over the time interval Ramp 1 Time. It is allowed to ramp to a higher or a lower rate. The default value is 0.0.

#### **START RAMP 1**.............................. 0.000 to 999.9 kÅ

This value sets the thickness at which to start the Rate Ramp. This thickness value must be less than the Start Ramp 2 thickness value if the value of Start Ramp 2 is non-zero. A value of zero disables the feature. The default value is 0.



#### **RAMP 1 TIME** . . . . . . . . . . . . . . . . . . 00:00 to 99:59 min:s

This value determines the time period over which to ramp the rate from the original rate to New Rate 1. The default value is 00:00.

#### **RAMP 2 RATE**........................0.000 to 999.9 Å/s

Ramp 2 Rate is provided to effect a rate change while depositing a Material. The aggregate rate is ramped linearly from the original Ramp 1 Rate setpoint to the New Rate 2 value over the time interval Ramp 2 Time. It is allowed to ramp to a higher or a lower rate. The default value is 0.0.

#### **START RAMP 2**............................... 0.000 to 999.9 kÅ

This value determines the thickness at which to begin Ramp 2 Rate. A value of zero disables this feature. Start Ramp 2 thickness must be greater than Start Ramp 1 thickness. Also, Ramp 2 Rate can not be started until the completion of Ramp 1 Rate. If the thickness of Start Ramp 2 is exceeded while in Ramp 1 Rate, Ramp 2 Rate will begin immediately after Ramp 1 Rate The default value is 0.

#### **RAMP 2 TIME** . . . . . . . . . . . . . . . . . . 00:00 to 99:59 min:s

This value is the time interval over which the rate is ramped linearly from New Rate 1 to New Rate 2. The default value is 00:00.

## 5.2 Special Material Parameter Features

## 5.2.1 Skip Deposit

If the Final Thickness is set to 0.000 kÅ, Cygnus 2 will skip the DEPOSIT State. State processing will go directly to the post-Deposit parameter state from the last pre-Deposit state.

# 5.2.2 RateWatcher™ Sample and Hold Feature

Two parameters, Ratewatcher Time and Ratewatcher Accuracy, define the Sample and Hold feature. When enabled by selecting RateWatcher Option = Yes, this feature periodically samples the deposition rate by automatically opening the sensor shutter and exposing the sensor to the deposition source. The power is adjusted so the actual rate is set to the desired rate. The sensor shutter is then automatically closed and power is held constant at the adjusted level. A five second time delay for thermal stabilization occurs between opening the shutter and taking measurements. During this time, DELAY is displayed in Cygnus 2 message area.

The RateWatcher Sample phase uses the measured deposition rate to control the source power. When the deposition rate meets the requirements of the RateWatcher Accuracy parameter, the RateWatcher Acceptance Window Time is started. If the rate falls out of the RateWatcher Accuracy requirement, the RateWatcher Acceptance Time Interval is reset to zero.



If the deposition rate meets the RateWatcher Accuracy requirement for the duration of the Acceptance Window Time, the sensor shutter is closed and RateWatcher enters Hold phase for the RateWatcher Time duration.

Finally, after the Hold Time has elapsed, RateWatcher will enter a 5 second Delay phase. During the Delay phase, the crystal is exposed to the deposition, but the accumulated rate and sustained power are that from the previous Hold phase. This Delay phase allows the crystal to thermally stabilize to the deposition before re-entering the RateWatcher Sample phase.

The RateWatcher Sample Acceptance Window Time (that is, the length of time that the rate must be within the accuracy range before going into hold) will be calculated as follows:

Time Power Avg Time	Rate Filter Time	RateWatcher Sample Acceptance Window Time	Rate and Power Averages Used
0 min	<10 sec	5 seconds	2.5 minus 0.5 second averages
0 min	10 sec	10 seconds	2.5 minus 0.5 second averages
1 min	anything	60 seconds	2.5 minus 0.5 second averages
>1 min	anything	Average Time * 60 seconds	Average of minute averages (as with Time Power) of Average Time - 1 minute

RateWatcher OPTION.......... No (0), Yes (1)

Default is No (0) which disables the function and grays out the Time and Accuracy parameters.

RateWatcher TIME . . . . . . . . . . . . . 00:00 to 99:59 min:s

Ratewatcher Time determines the time interval between sample periods. The crystal shutter relay is in its normal state during this time. Values range from 00:00 to 99:59 minutes:seconds. The default value is 00:00, which disables the function.

During a Rate Ramp, the Sample and Hold feature is inactive; the crystal shutter is open and the rate is controlled by the crystal.

#### RateWatcher ACCURACY . . . . . . 1 to 99%

During the rate sampling period, the deposition rate is measured by the crystal; source power control is active. When the rate is within the desired accuracy continuously for five seconds, the shutter is closed and the deposition state returns to HOLD. The minimum accuracy is 1% or 0.1 Å/s, whichever is greater. Values range from 1 to 99%. The default value is 5%



# Chapter 6 General Parameters


# 6.1 General Set-Up Overview

Cygnus 2 provides the capability to modify a series of top level parameters that define the controller's method of handling system level activities. Some of the parameters are automatically incremented by Cygnus 2.

General Set-Up is initiated by moving the cursor to the General heading on the Main Menu and pressing MENU. This will invoke the General display (see Figure 6-1). You may return to the Main Menu display by pressing MENU again.

# 6.2 General Process Page

Figure 6-1 General/Process display



Select a parameter for entry by positioning the box cursor at the desired value following the parameter description. New values are input from the front panel followed by pressing the Enter key input. Values are cleared by pressing the Clear key.



#### **THICKNESS EQUATION 1, 2, 3** . . . 0 to 654321

Each of the three thickness equations can be set up to sum the thickness of the specified Sources. Each Source can only be used once in an equation and can be used in all three equations. For example, 12 means sum the thickness of Sources 1 and 2, 1234 sums the first four Sources. Thickness equations are designed to be used in logic statements. The default value is 0.

# 6.3 DACs Page Parameters

Polarity and full scale voltages can be set up for all DACs, see Figure 6-2. Move the cursor key to the DAC. Use the TOGL key to select + or - for the polarity. Use the numeric keys to enter the full scale voltage in the range of 0.1 to 10.0 volts. These parameters cannot be updated for a Material that is running. Default is -10.0.


Figure 6-2 General DACs page

Genera 1			Carousel Open 4			Crystal Fail 2
udio/Visual						
Lock					(1.51.T)	
Test	DAC 6	- 10.0		DAC 12	- 10.0	
Date/Time	DAC 5	- 10.0		DAC 11	- 10.0	
	DAC 4	- 10.0		DAC 10	- 10.0	
Message	DAC 3	- 10.0		DAC 9	- 10.0	
Comm	DAC 2	- 10.0		DAC 8	- 10.0	
DACs						
Process	DAC 1	- 10.0		DAC 7	- 10.0	



# 6.4 COMM Page Parameters

Figure 6-3 General comm display



DATALOG XTAL INFO. . . . . . . . . Yes (1), No (0)

This parameter selects whether to output the crystal use history in addition to the standard set of datalog information. Default is No.

#### **RS-232**

**BAUD RATE**......9,600 (0), 19,200 (1), 38,400 (2), 57,600 (3), 115,200 (4)

Default is 115,200. Use the TOGL key to select the desired rate.

PROTOCOL . . . . . . . . . . . Standard (0), Dlog Page (1), Dlog Comma (2)

Standard enables receiving communication commands from an external host and sending the expected responses. Dlog Comma and Dlog Page allow only one-way transmission of information from Cygnus 2 to the external device. The Dlog Comma format allows importation of the Data Log string into a spreadsheet program. Dlog Page format is designed for use as text only. A carriage return (d13, h0D) and line feed (d10, h0A) are inserted at the end of each line of data. The Dlog information is transmitted when the Source shutter closes at the end of Deposit or following a Stop or a Suspend while in Deposit. The default is Standard (0).



#### If the Ethernet option is installed, the following parameters will be shown

IP ADDRESS . . . . . . . . . . . . . . . . nnn.nnn.nnn

Use the up and down cursor keys to scroll through the address and the numerics keys to enter the desired address. The default address is 10.211.72.203. This setting is not cleared on pressing CLEAR on power-up.

NET MASK ......nnn.nnn.nnn

The net mask is some number of leading bits set to 1, followed by all 0. The default net mask value is 255.255.0.0: This setting is not cleared on pressing CLEAR on power-up.

255 .255 .0 .0 11111111 1111111 00000000 000000000

#### **Test RS-232 Function Key**

Once the cursor is in the parameter area, the Test RS-232 function can be performed by pressing the F1 function key. Plug the loop-back connector 760-406-P1 supplied in Cygnus 2 ship kit into the RS-232 connector on the rear panel and press F1. Message RS-232 Test Failed or RS-232 Test Passed will appear. If the loop-back connector is not available, jumper pins 2 and 3 to perform the test. Contact INFICON Service if the RS-232 Test Failed message appears.



# 6.5 MESSAGE Page Set-up

Ten 19 character messages can be created by the user from the front panel or via communications. ASCII characters allowed include all the characters starting with the space character h20 through the character h7E. These Messages are turned on and off under control of logic statements. Up to four Messages can be displayed in the Message area. Newer Messages will displace older ones. Cygnus 2 status messages have priority and will also displace user Messages.

Move the cursor key to one of the 10 Message lines. Then use the alphanumeric keys in cell-phone fashion to enter characters. Use 0 for a space and the \_ character, A second press on 0 enters numeric 0. #,& and \* characters can be entered by pressing 1 multiple times. To edit a Message, move the cursor to the Message and press any numeric key.

 Process
 6

 DACs
 1

 Comm
 2

 Hessage
 3

 Date/Time
 8

 Test
 4

 Lock
 5

 Audio/Visual
 10

 General
 Crystal Fail


 02/06/2011
 08:51

Figure 6-4 General message page



# 6.6 DATE / TIME Set Up

Figure 6-5 General date/time page



DATE FORMAT . . . . . . . . . . . . . . . . MM/DD/YYYY, DD/MM/YYYY

Default is MM/DD/YYYY. Use the TOGL key to select DD/MM/YYYY.

#### **CALENDAR**

**DAY** ...... 1 to 31

**MONTH** . . . . . . . . . . . . . . 1 to 12


**YEAR** . . . . . . . . . . . . . . . . . . 2001 TO 2099

SYSTEM TIME..... HH:MM



# 6.7 TEST Page Set Up

Figure 6-6 General test page



Press the TOGL key to move through the choices. The default is Off. Cygnus 2 contains a software controlled Test Mode which simulates actual operation. The purpose of the Test Mode is to verify basic operation and for demonstrating typical operation to the technician. The word "TEST" will be displayed when TEST is on.

The Rate displayed during Test Mode operation is determined as shown in equation [1].

Displayed Rate = 
$$\frac{40}{\text{DENSITY (g/cc)}} \times \frac{\text{TOOLING (\%)}}{100\%} \text{Å/sec}$$
 [1]

Relays, inputs, Source and recorder outputs operate normally during Test Mode but Crystal fails are ignored unless Advanced Test is set to On.

When in TEST mode, TIME COMPRESSED allows a faster than real time execution of the Process. This is useful when testing a long Process. A value of Yes increases the speed of execution 10 to 1. The default value is No.

If set to On, Cygnus 2 will respond to crystal fails and switch to backup crystal positions. The text "A TEST" will be displayed when the Advanced Test is On. The default value is Off.



# 6.8 LOCK Page Code Set-up

Figure 6-7 General lock page

Process DACs Comm Message Date/Time Test Lock	Program Lock Code XXXX  File Access Code XXXX	
Genera		Crystal Fail
	09:04 Test	

#### PROGRAM LOCK CODE . . . . . . . 1 to 9999

The lock code is set by moving to Program Lock Code and entering the desired code of up to 4 digits. If no lock code is desired, no entry needs to be made. The lock code will be in effect after turning the unit off and an again. The text "L LOCK" will be displayed when Program Lock is set. Default value is 0.

NOTE: If a lock code was previously programmed, that code must subsequently be entered on the Main Menu screen, with the cursor positioned on XXXX at the Lock Code XXXX at the lower right corner of the Main Menu options area. After entering the lock code on that screen, the lock code can be cleared if desired by entering 0 for the Program Lock Code on the General / Lock page. The lock code can also be cleared by pressing CLEAR on power-up, however, if no lock code has been programmed, this will reset all parameters to their default values.

**NOTE:** Program lock codes are not stored on and retrieved from the USB port.



#### 

The File Access Code allows configuration file retrieval from the USB port when the Program Lock Code is locked. This allows a process recipe to be entered into Cygnus 2 from a USB storage device without unlocking the Program Lock Code. If the File Access Code has not been enabled, USB port retrieval is not allowed when a Program Lock Code is present. This parameter has no effect if there are no lock codes, or the access code is set to zero. Default value is 0. When pressing CLEAR on power-up, the File Access Code is cleared when the parameters are cleared, not when the lock codes are cleared. The File Access Code is not stored on nor retrieved from the USB port.

# 6.9 AUDIO / VISUAL Page Set Up

Process DACS Comm Audio Feedback No Message LCD Dimmer Time Ω min Date/Time Test Lock Audio/Visual Crystal Fail Genera 1 02/22/2011 09:11

Figure 6-8 General audio/visual page

#### AUDIO FEEDBACK..... Yes (1), No (0)

Default is No. Yes Activates Audio Feedback, signifying keyboard interaction.

#### LCD DIMMER TIME...... 0 to 99 min

Determines the time before the backlight is turned off to conserve display life. Default is 0 minutes which disables the dimmer function.

**NOTE:** The backlight is ON when a process is running. It is only OFF when time elapsed since last key press and in READY or IDLE and end-of-process exceeds the LCD Dimmer Time setting.

**NOTE:** All keys previously active in the dimmed page remain active. Pressing any active key performs that key's function and restores the display.



# Chapter 7 Digital I/O

# 7.1 Digital I/O Screen

The Digital I/O screen is selected by moving the cursor on the Main Menu screen to Digital I/O and pressing Menu. The I/O Map display for board 1 is shown in Figure 7-3 on page 7-3. Upon entry the cursor will be placed at the last referenced output or input number.

# 7.2 All Input Page

Figure 7-1 All input page

	Board 1 Input		Board 2 Input	
All Input	1		15	
VALUE CONTRACTOR OF THE TREE	2		16	
All Output	3		17	
	4		18	
I/O Bd 1	5		19	
I/O Bd 2	6		20 21	
170 bu Z	8		22	
I/O Bd 3	9		23	
	10		24	
	11		25	
	12		26	
	13		27	
	14		28	
Inputs		Carousel Open 4		Crystal Fail 2

All input names assigned by Cygnus 2 or by the user are shown to facilitate system diagnosis. Darker font color designates inputs that are currently active.



# 7.3 All Output Page

Figure 7-2 All output page

	Board 1 Relay Output	Board 2 Relay Output	Board 3 Relay Output	Board 3 TTL Output
All Input All Output I/O Bd 1 I/O Bd 2 I/O Bd 3  All Output I/O Bd 2 I/O Bd 3		9 17 18 18 19 12 20 13 21 14 22 15 23 16 24		25 26 27 28 29 30 31 32 33 34 35 36 37
Outputs		Carouse1 Oper	1 4	Crystal Fail 2

All output names assigned by Cygnus 2 or by the user are shown to facilitate system diagnosis. Darker font color designates inputs that are currently active.



# 7.4 I/O Board Page

Figure 7-3 I/O map board 1 page

	Relay Name	Output Type	TTL Name	Input
All Input All Output I/O Bd 1 I/O Bd 2 I/O Bd 3	11 Input	NO NO NO NO NO NO	1	
[/O Boa	rd 1			Crystal Fail 2

Names, up to 15 characters in length, can be entered by the user for any input or output unless Cygnus 2 has automatically assigned a name. Names created by Cygnus 2 cannot be edited. To enter or edit a user name, move the cursor onto the appropriate input or output and use the keyboard in cell phone fashion to create or edit the name.

# 7.4.1 Output Type

Output Types may be defined as normally open (NO) or normally closed (NC). Relay and TTL output types are changed by positioning the cursor on an output type and pressing the TOGL key followed by the ENTER key.



# Chapter 8 Logic Statement Set-Up

# 8.1 Logic Statement Overview

Cygnus 2 programmable logic capabilities allow it to respond to digital external inputs to control the execution of a Material or series of Materials without operator intervention. You can tailor these capabilities by programming the logic statements.

A logic statement consists of an IF part and a THEN part. The IF part consists of one or more conditional events selected from a table. IF parts can be based on external inputs or internal system conditions or a combination of both. The THEN part similarly consists of one or more actions selected from another table. When the event string is determined to be true, the associated actions are executed in left to right order. The state of the Logic statement is indicated on the Logic Overview display and on logic statement group pages. The color of the logic statement number will turn green to indicate the IF part of the statement is true. Also, three stars (\*\*\*) will be present. The expressions are evaluated in numerical sequence starting with logic statement 1.

- Programming is accessed by moving the cursor to the Logic heading of the main menu and pressing MENU.
- Single or multiple actions may be triggered by inputs or the fulfillment of a user specified logical condition.
- Inputs are only processed when they or the statement they are used in undergo a transition and on Cygnus 2 power-up.
- Single or multiple complex defined conditions are used to define an event.
- The Logical operators; AND, OR, and NOT (negate) as well as grouping operators (parentheses) are available to define very precise conditions. An additional operator, ON, specifically ties certain events together.
- It is possible to execute an action immediately or delay it for a definable period of time through use of a timer or a counter.
- Each Logic statement is evaluated every measurement cycle of 100 ms, but evaluation is suspended while a configuration file is being loaded.
- Material entries for each logic statement can be made exclusive or inclusive.
- The components of the Logic statements may be the transition between or entry of a specific state, specific programmable time limits, programmable thickness limits or various error conditions.
- There are user defined messages which may be displayed.



- Inputs and outputs may be named on an I/O map display. Additionally on this display, the outputs may be defined as normally open (NO) or normally closed (NC).
- Logic statements may be chained together using the Statement ### Event.

These features allow moderately complex vacuum processing plants to be controlled without the addition of any other intelligent machines.

Fourteen TTL inputs and eight relay outputs are standard. An additional fourteen inputs and eight relay outputs are available with an optional I/O card. With a second optional I/O card, eight more relays and fourteen open collector outputs are available.

Cygnus 2 has the capacity for 100 logic statements.

# 8.2 Editing the Logic Statements

All Materials must be in Ready, Idle or Stop to edit or create logic statements. Logic Set-Up is initiated by moving the cursor to the Logic heading on the Main Menu and pressing MENU. This will invoke the Logic display (see Figure 8-1). You may return to the Main Menu display by pressing MENU again. Upon entry to the Logic display, the cursor will be placed at the last referenced Logic statement.

There will be an indication for each statement programmed, (the > symbol next to the statement number) and an indication that the statement is True (green color change and three stars \*\*\* will be present).

2 > \*\*\* Overview Logic 1-4 74 75 76 Logic 5-8 7 Logic 9-12 Logic 13-16 Logic 17-20 Logic 21-24 Logic 25-28 Logic 29-32 Logic 33-36 Crystal Fail Logic 02/22/2011 11:50 Select

Figure 8-1 Logic overview page


Logic statements that are "true" are indicated in green and with \*\*\* asterisk.



## 8.2.1 Logic Statement Groups

To view logic statements in groups of four, move the cursor in the left pane down to that group. Individual statements in that group can then be edited by moving the cursor to the statement number and pressing F1 Edit, see Figure 8-3.

Figure 8-2 Logic 1 - 4 page



From the Logic Overview display, a logic statement can also be selected for editing by positioning the cursor at the desired statement number and pressing F1 Select. See Figure 8-2.



### 8.2.2 Logic Statement Editing

Figure 8-3 Logic event IF selection





Figure 8-4 Logic action Then selection



While in logic-edit, the select menu area will be cleared from the screen. This allows the whole screen to be used for statement editing. A single statement is displayed to edit. The lower portion of the screen will be used to display either the



event or the action list. Events are displayed if the cursor is on the IF portion of the statement and Actions are displayed if the cursor is on the THEN portion of the statement. Cursor begins on the first IF item.

The following function keys are active when the cursor is on the upper half of the page.

- Event/Action key will move the cursor to the event or action list on the lower half of the screen to select an event or an action. The cursor will jump to whichever event or action in the list that the cursor had been on in the upper half. The event or action in the statement will be highlighted to indicate which element is being worked in.
- Delete Element key will remove the element the cursor is on from the statement.
- Cancel Changes key returns the statement to the way it was before editing was started.
- Save & Exit key will save the statement and re-display the four-statement screen with the select menu.


When the cursor is on the lower half (event or action list) of the page the following function keys are active:

- If/Then (F1) key will return the cursor to the IF/THEN statement, with the cursor returning to the highlighted element in the logic statement.
- **Replace** (F2) key will write over the highlighted element with the selected Action/Event. The highlight moves to the next element in the statement.
- Insert (F3) key will insert the selected action or event into the highlighted element and moves the elements programmed to the right. The highlight remains on the inserted element in the statement. If the statement is full then a full statement error message will appear.
- **Negate** (F4) key will negate the highlighted event element in the statement. Actions cannot be negated.

To add or delete parenthesis use the cursor in the Event list to select the event Parenthesis. Pressing Insert or Replace, see Figure 8-5, will add a parenthesis before or after the highlighted event in the statement. If a parenthesis is already there, Insert will act as a toggle, removing the parenthesis.



Figure 8-5 Function Keys IF/THEN, REPLACE, INSERT



With the cursor in the lower half of the Event page, the F4 key will carry the Negate function in addition to the first three shown above.

When moving the cursor from an event or action, the next element is a numeric field, if required.

A connector field is required between events. The Toggle key is used to select the connector in the statement.

# 8.2.3 AND/OR and ON Logic Connectors

If the cursor is on a connector designated by ccc, pressing TOGL will toggle the ccc between a logical AND and a logical OR.

For those Events which are Material specific an additional operator can be selected. This is the ON operator and pressing the TOGL key will now toggle between AND, OR, and ON.

#### 8.2.3.1 ON Operator

The ON operator is designed for use in multi-Material applications to link an event to a particular Material.

The only Event allowed following the ON connector is Material ###. Only the events that can be associated with Material can precede the ON operator. This includes all States, Pre-Deposit, Deposit, Post-Deposit, Non-Deposit, Final Thickness,



Thick Limit, Time Limit, Material, Material End, Crystal Fail, Crystal Switching, Max Power, Min Power, Backup Sensor In Use, Crucible Switch Fail, Rate < 0.1, Auto-Z Fail, Ion-Assist, and Rate Deviation Error.

There cannot be two consecutive ONs in a statement. A ON B ON C is not allowed. A ON B and C ON D is acceptable.

Neither the event preceding nor the event following the ON can have a NOT function or a parenthesis. For example ~A ON B or A ON ~B is not allowed. Neither is A ON (B and C) or (A and B) ON C.

The ON connector always takes precedence over the AND and OR operators no matter where it appears in the statement. For example, A AND B ON C will be evaluated as A AND (B ON C) not as (A AND B) ON C.

### 8.3 IF Event Definitions

If two or more Materials are active simultaneously, an Event condition is considered TRUE if it is true for any Material (for example, if the first Material is in DEPOSIT and the second Material is in PRE-DEPOSIT, both the DEPOSIT and the PRE-DEPOSIT Events would be TRUE).

The presence (or absence) of an input's leading edge detection on the transition from high to low (or low to high) is used to evaluate the event condition. Inputs are not re-evaluated if held level at either the high or low state.

IF events can be connected using logic connectors, refer to section 8.2.3, AND/OR and ON Logic Connectors, on page 8-6. IF events can be negated.

#### **AUTO-Z FAIL #**

Sets the logic condition to be true whenever an Auto-Z fail condition occurs on Sensor #. The condition remains true until the Auto-Z Fail condition is cleared. Numeric inputs for Sensor # range from 0 through 6 (0 for any Sensor).

#### **COMPUTER CNTRL**

Sets the logic condition to be true when a Set Logic Statement vvv (1 to 100) command is received from the remote communications port. The logic condition remains true until a Clear Logic Statement vvv command is received from the remote communications port. See Remote Commands RG5 and RG6 (see section 9.4.31, Remote General Action, on page 9-43).

#### **COUNT LIMIT XX yyy** (xx can be 1 to 20 and yyy can be 0 to 999)

Sets the logic condition to be true when the specified counter XX (1 to 20) has reached the count number set by yyy (1 to 999). The condition remains true until the specified counter is cleared using Clear Counter XX.



#### **CRUC SWCH FAIL**

Sets the logic condition to be true if a Turret Feedback input is specified and is not received within the allocated time span. The condition remains true until the input arrives or a Reset is done.

#### **CRUCIBLE SWITCH**

Sets the logic condition to be true while switching crucibles. The condition remains true until the turret delay time has expired or the turret input arrives or a Reset is done.

#### **DEPOSIT**

Sets the logic condition to be true at the beginning of the Deposit state. The condition remains true until the end of the DEPOSIT state, or when a STOP/RESET or STOP/START sequence is executed. Rate Ramps, Time Power and Manual are considered part of the Deposit state.

#### **EXTERNAL INPUT ##** (## can be 1 to 28)

Designates a hardware input which, when it changes state, can be used to trigger an Action. Inputs can be given names up to 15 characters long. Inputs are activated by pulling the specific input's terminal to ground (<0.8 V) through a contact closure to common (GND) or with TTL/CMOS logic having current sink capability of 2 mA (1 low power TTL load).

#### **FEED**

Sets the logic condition to be true at the start of Feed Time. The condition remains true until the end of Feed Time. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### **FEED RAMP**

Sets the logic condition to be true at the start of Feed Ramp. The condition remains true until the end of Feed Ramp. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### **FINAL THICK**

Sets the logic condition to be true once the Final Thickness is achieved while in Deposit or Manual or when the Final Thickness Trigger action is activated. The condition remains true until the Material which has achieved Final Thickness enters the IDLE state, or until a Zero Thickness or a STOP/RESET sequence is executed.



#### **IDLE**

Sets the logic condition to be true at the beginning of the Idle state. The condition remains true until the end of Idle. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### **IN DEPOSIT**

Sets the logic condition to be true at the beginning of the Deposit state and **includes** Time-Power and Rate Ramps. It is also true while in Manual **and** the Source/Substrate shutter output is active. The condition is cleared when entering the post-deposit state, or when a STOP/RESET or a STOP/START sequence is executed.

#### **IDLE RAMP**

Sets the logic condition to be true at the start of Idle Ramp. The condition remains true until the end of Idle Ramp. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### **ION ASSIST DEP**

Sets the logic condition to be true at the start of Deposit if Ion Assist Deposit has been enabled for this Material. The condition remains true until the end of Deposit. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed

#### XTAL LIFE > # ##

Sets the logic condition to be true whenever the Life value ## on Sensor # is greater than the value entered for ##, which can be 1 to 99, for at least 5 seconds. The condition remains true until the Life value is less than ## for at least 5 seconds. Numeric inputs for Sensor # range from 0 through 6 (0 for any Sensor).

#### **MANUAL**

Sets the logic condition to be true when the Manual state is entered. The condition remains true until leaving the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### MATERIAL ##

Sets the logic condition to be true whenever a Material ## is in the READY state or when it is STARTed. The condition remains true until the Material is no longer active. Values for ## range from 1 to 6.



#### **MATERIAL END ##**

Sets the logic condition to be true when the specified Material ## enters the IDLE state. The condition remains true until a START or a STOP ALL/RESET command is received. Numeric inputs range from 0 to 6, with 0 indicating any Material.

#### **MAX POWER**

Sets the logic condition to be true as long as any Source is at Max(imum) Power. The condition remains true until every Source is less than Maximum Power.

#### **MIN POWER**

Sets the logic condition to be true as long as any Source is at Min(imum) Power. The condition remains true until every Source is greater than Minimum Power.

#### NON-DEP CONTROL

This Event is evaluated true if a Material is in the Non-Deposit Control state, that is, there is rate control with the Source/substrate shutter closed. The condition remains true until the end of the Non-Deposit Control state.

#### **NON-DEP HOLD**

This function is similar to Time Power except the Source/substrate shutter is closed and there is no determinant end point. The condition remains true until the state is exited, for example when a Stop command is given.

#### POST-DEPOSIT

Sets the logic condition to be true at the beginning of the Feed state or the beginning of the Idle Ramp state. The condition remains true until a START command is received or until a STOP/RESET sequence is executed.

#### PRE-COND RISE

Sets the logic condition to be true at the beginning of the Pre-Cond Rise state. The condition remains true until the Pre-Cond Soak or a subsequent non-zero state is entered, or until a STOP/RESET sequence is executed.

#### PRE-COND SOAK

Sets the logic condition to be true at the beginning of the Precond Soak state. The condition remains true until the Rise 1 or a subsequent non-zero state is entered, or until a STOP/RESET sequence is executed.

**NOTE:** This state, PRECOND RISE, RISE 1 and SOAK 1 are skipped if the same Material was used and has a non-zero Idle power.



#### **PRE-DEPOSIT**

Sets the logic condition to be true at the beginning of the Ready, Source Switch, Shutter Delay, PreCond, Rise 1, Rise 2, Soak 1, or Soak 2 state. The condition remains true until the Deposit, Manual, or any Post-Deposit state is entered.

#### **RATE < 0.1**

This condition will evaluate true when the actual deposition rate is less than 0.1 Å/s for more than 5 seconds while in Deposit or Manual. The condition remains true until the actual deposition rate is greater than 0.1 Å/s for 5 seconds or more, when the Material reaches Idle or on Stop/Reset.

#### **RATE DEV ERR**

This condition will evaluate true when the actual deposition rate differs from the rate setpoint by the larger of 5% or 0.1 Å/s for more than 60 seconds or 20 times the control loop time constant while in Deposit. The condition remains true until the Material leaves deposit.

#### **RATE RAMP 1**

Sets the logic condition to be true at the beginning of Rate Ramp 1. The condition remains true until the end of Rate Ramp 1. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### **RATE RAMP 2**

Sets the logic condition to be true at the beginning of Rate Ramp 2. The condition remains true until the end of Rate Ramp 2. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### **READY**

Sets the logic condition to be true as long as Cygnus 2 is in the READY state. The condition remains true until a START command is received or when entering Manual State.

#### RISE 1

Sets the logic condition to be true at the start of Rise Time 1. The condition remains true until the end of the Rise Time 1. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

**NOTE:** This state, PRECOND RISE, PRE-COND SOAK, and SOAK 1 are skipped if the same Material was used and has a non-zero Idle power.



#### RISE 2

Sets the logic condition to be true at the start of Rise Time 2. The condition remains true until the end of Rise Time 2. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### SHUTTER DELAY

Sets the logic condition to be true at the start of Shutter Delay. The condition remains true until the end of Shutter Delay. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### SHTTR DLY ERROR

Sets the logic condition to be true when a Shutter Delay Error condition occurs. The condition remains true until a START or a RESET command is received.

#### SOAK 1

Sets the logic condition to be true at the start of Soak Time 1. The condition remains true until the end of Soak Time 1. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### SOAK 2

Sets the logic condition to be true at the start of Soak Time 2. The condition remains true until the end of Soak Time 2. The condition is also cleared when entering the Manual state, and when a STOP/RESET or a STOP/START sequence is executed.

#### STATEMENT ###

This Event can be used to test a logic statement transition and the appropriate Action is taken when the statement designated becomes true. A true statement is indicated by three small asterisks below the statement number. Numeric inputs range from 1 through 100.

#### **STOP**

Sets the logic condition to be true as long as Cygnus 2 is in Stop. The condition remains true until a START or RESET command is received.

#### **TEST**

Sets the condition to be true when Cygnus 2 is in TEST.

#### THICK LIMIT

Sets the logic condition to be true once the Thickness Limit is achieved while in Deposit. The condition remains true until entering the IDLE state for that Material or until a Zero Thickness or a STOP/RESET sequence is executed.



#### THICK SUM # ###

Sets the logic condition to be true when the sum of thickness indicated by the designated Thickness Equation #, 1 to 3, reaches the thickness value ### (0-999.9) kÅ.

#### TIME LIMIT

Sets the logic condition to be true once the Time Limit is achieved. The condition remains true until the Material which has achieved Time Limit enters the IDLE state or until a STOP/RESET sequence is executed.

#### **TIME POWER**

Sets the logic condition to be true upon entering a Time Power state. The condition remains true until the end of the DEPOSIT state.

#### TIMER HH:MM # HH:MM

Sets the logic condition to be true when the designated timer # (1 to 20) reaches the specified number of hours and minutes HH:MM, 00:00 to 99:59.

#### TIMER SECONDS # ###

Sets the logic condition to be true when the designated Timer # (1 to 20) reaches the specified time expressed in seconds, sss.s, 0 to 999.9.

#### XTAL ACTIVITY < # ###

Sets the logic condition to be true whenever the Activity value ### on Sensor # is less than the value entered for ### for at least 5 seconds. The condition remains true until the Activity value is greater than ### for at least 5 seconds. The Activity value ### can be 1 to 999. Numeric inputs for Sensor # range from 0 through 6 (0 for any Sensor).

#### **XTAL FAIL #**

Sets the logic condition to be true as long as there is a Crystal Fail on Sensor #. In the case of a multi-position sensor, a Crystal Fail occurs when the last available crystal fails. The logic condition remains false if the XTL FL INHB Action is active (ON). The condition remains true until a working crystal is input to the appropriate Sensor. Numeric inputs for Sensor # range from 0 through 6 (0 for any Sensor).

#### **XTAL SWITCHING #**

Sets the logic condition to be true while a crystal switch is taking place on Sensor #. The condition remains true until the crystal switch is completed. Numeric inputs for Sensor # range from 0 through 6 (0 for any Sensor).



#### 8.4 THEN Action Definitions

**NOTE:** The following are level outputs that once turned on will remain active until turned off. This is true even if the Logic string is cleared.

START INHBT (ON/OFF) RWS INHIBIT (ON/OFF) SOAK 1 HOLD (ON/OFF) ## EXTERN OUT (ON/OFF) ## CLOCK HOLD (ON/OFF) XTL FL INHB (ON/OFF) RWS INITIATE (ON/OFF) SOAK 2 HOLD (ON/OFF) ## MESSAGE (ON/OFF) ## PRE COND S/H (ON/OFF)

Deactivates the designated timer ## and resets it to zero.

Clears the designated counter ##.

**CLOCK HOLD (ON/OFF) ##** . . . . . 0 (any Material) to 6

This feature controls the state timer during any non-rate control state. These states include the pre-deposit states—Ready, Crucible Switch, PreCond Rise, PreCond Soak, Rise 1, Soak 1, Rise 2, Soak 2—and the post-deposit state Idle Ramp.

For the feature to be activated the state's timer must be non-zero. If the Cygnus 2 is in the Ready state and a Start command is executed while CLOCK HOLD is active, Cygnus 2 will progress to the first pre-deposit state with a non-zero state time. If Cygnus 2 is in the Crucible Switch state, waiting for Turret Feedback Input, and CLOCK HOLD is activated, when the turret positioned input is activated, Cygnus 2 will progress to the next pre-deposit state having a non-zero state time. Cygnus 2 is prevented from continuing state processing until the CLOCK HOLD action is turned OFF.

CONTINUE DEP ##...... 0 (any Material) to 6

Maintains the designated Material ## in the Deposit state but does not zero the thickness. This action cannot be done from a Ready, Idle, Stop, Crystal Switching, or Crucible Switch state. If the crystal is failed, this action will put the associated Source into the Time Power state if the previous state was Non-Deposit Hold, otherwise it is not allowed.

**EXTERN OUT (ON/OFF)** ## . . . . . 1 to 38

Designates a hardware output ## and places it into its ON or OFF state. Outputs can be given names up to 15 characters long. Outputs are named in the I/O Map display.



GO TO NON-DEP ## . . . . . . . . 0 (any Material) to 6

Places the designated Material ## into the Non-Deposit Control state. This cannot be done from the Ready, Idle, Stop, or Crucible Switch states. If the crystal is failed, this action will place the Material into the Non-Deposit Hold state if the previous state was Time Power, otherwise it is not allowed.

GO TO POST-DEP ## . . . . . . . . . 0 (any Material) to 6

This action places the designated Material ## into the Feed Ramp state. This action cannot be done if in Crucible Switch, Ready or Stop.

**INCREMENT COUNT ##** . . . . . . . 1 to 20

Increases the count by one in the designated counter ##.

MESSAGE (ON/OFF) ## . . . . . . . 1 to 10

Designates the user-defined message ## and displays the message on the screen (or removes it from being displayed). The message is displayed in the message section of the display. Messages are defined in the General/ Message page.

PRECOND S/H (ON/OFF) ## ..... 0 (any Material) to 6

If active (ON), the designated Material ## will pause execution and maintain PreCondition power until Pre Cond S/H (Soak Hold) is turned OFF. Commands from Remote Comm and Logic will be independent.

RESET ##......0 (any Material) to 6

This action is identical to pressing the RESET button on the front panel.

RWS INHIBIT (ON/OFF) ##..... 0 (Any Material) to 6

When active (ON), this will prevent the designated Material ## from entering the RateWatcher Sample state. If Sample is already active, remains in Sample until Accuracy requirement is met. When OFF, RateWatcher Sample will be enabled. Commands from Remote Comm and Logic will be independent.

RWS INITIATE (ON) ## . . . . . . . . 0 (any Material) to 6

RWS INIT (OFF) ## . . . . . . . . . 0 (any Material) to 6

When active (ON), this will start the RateWatcher sampling interval for the designated Material ##. When OFF, RateWatcher sampling will take place at the programmed interval based on the RateWatcher time unless RWS INHIBIT is on. Commands from Remote Comm and Logic will be independent.

SOAK 1 HOLD (ON/OFF) ## . . . . . 0 (any Material) to 6

If active (ON), the designated Material ## will pause execution and maintain Soak Power 1 until Soak Hold 1 is turned OFF. Commands from Remote Comm and Logic will be independent.



SOAK 2 HOLD (ON/OFF) # . . . . . 0 (any Material) to 6

If active (ON), the designated Material # will pause execution and maintain Soak Power 2 until Soak Hold 2 is turned OFF. Commands from Remote Comm and Logic will be independent.

**START** ##......0(any Material) to 6

This action is identical to pressing the START button on the front panel.

START DEPOSIT ## . . . . . . . . . 0 (any Material) to 6

This function is used to place the designated Material ## into Deposit from the NONDEP CNTL state and zero the thickness. If the crystal is failed, this command will make the Material go into Time Power if the previous state was Non-Deposit Hold, otherwise the action is not allowed. Cannot be done from Ready, Idle, Stop, Crystal Switch, or Crucible Switch. When in Ready or Stop, use the Start action.

START INHBT (ON/OFF) ..... ON/OFF

This feature, when active, prohibits the START of a Material. It does not inhibit the START DEPOSIT function. Once START INHIBIT is ON, a Material cannot be started until the START INHIBIT is deactivated (set to OFF). Commands from Remote Comm and Logic will be independent. START INHIBIT will carry through a power cycle

Starts the designated timer ##.

**STOP ##** ..... 0 (all Materials) to 6

Sets Source power for the designated Material ## to zero and freezes its rate and thickness values until a Start is received.

**SWITCH XTAL ##** . . . . . . . . . . 1 to 6

This action activates the Crystal Switch output for the Sensor number # indicated. It indexes to the next crystal position listed when using a multi-position sensor. This function is available only if a multi-position sensor type is chosen in Sensor Set Up.

TRIG FNL THICK ## . . . . . . . . . 0 (any Material) to 6

This action triggers Final Thickness for the designated Material ## and the Material proceeds to the Feed Ramp or Idle Ramp state. This action is ignored if not in the Deposit state.

XTL FL INHB (ON/OFF) ## . . . . . 0 (any Sensor) to 6

When set to On, this action prohibits the Crystal Fail logic event from becoming active for the designated Sensor number, but has no effect on crystal switching or Sensor failure action. This is useful when changing crystals. Commands from Remote Comm and Logic will be independent.



#### **ZERO DEP TIME ##** ..... 0 (any Material) to 6

This action will zero the Material Deposit time for the designated Material ## being deposited. If two or more Materials are in deposit simultaneously, the time will zero for all Materials. If an output is triggered on a Time Limit, the output will remain triggered even after resetting the Material Time

ZERO THICKNESS ##.....0 (any Material) to 6

This action is identical to selecting the ZERO THICKNESS panel function key in the OPERATE display. The Action will zero the thickness accumulated on the display for the designated Material # being deposited, provided it is not in Stop.

# 8.5 Logic Statement Example

The logic statement capability of Cygnus 2 allows for automation of a thin film process. For example, it is possible to start any Material without manually pressing START. One way to accomplish this is:

IF: External Input 1 and Stop on Material 1

THEN: Start 1

To enter this statement follow this procedure:

- 1 On the MAIN MENU screen, make sure the Material state is READY. If it is not, press STOP, then press RESET.
- 2 Move the cursor to Logic, then press the MENU key.
- **3** Using the down arrow, move to one of the Logic x-y pages.
- **4** From the Logic x -y page, press the right arrow key to move to the statements.
- 5 Place the cursor on any blank logic statement, using the up and down cursor keys.
- 6 Press F1 EDIT.
- **7** Press F1 EVENT/ACTION.
- **8** Cursor to External Input. Press F3 INSERT. In the upper left of the screen, External Input ### will appear after IF. Press F1 IF/THEN.
- **9** Cursor to ### and enter 1 (the input to use). Press ENTER
- **10** Press F1 EVENT/ACTION. Move the cursor to Stop.
- 11 Press F3 Insert. ccc Stop will appear in the IF line. Press F4 Negate. Then insert Material, specify #1 and insert "On" connector.
- 12 Press F1 IF/THEN and cursor back to ccc. Press the TOGL key until "and" appears, then press ENTER.
- 13 Cursor to the THEN line, press F1 EVENT/ACTION.



- 14 Cursor down to START. Press F3 INSERT. Start ### will appear.
- **15** Press F1 IF/THEN.Cursor to ### behind Start and enter 1(the Material to start). Press ENTER.
- **16** Press F4 SAVE & EXIT to return to the Logic page. At this point the Logic Statement is entered into memory.
- **17** To return to the OPERATE display, press Menu.

This example allows starting Material 1 only if it is in Ready or Idle but not when Material 1 is in Stop.



# Chapter 9 Remote Communications

# 9.1 Remote Communication Configuration Overview

Cygnus 2 may be remotely controlled, programmed or interrogated. This is accomplished through remote communications and the use of a remote command set. Cygnus 2 will respond to messages that contain these commands. It will accept and operate on messages one at a time. It will respond to each command by carrying out valid operations and/or returning a message to the sender. A host/server relationship is established in remote communications. Cygnus 2, as server, responds to the remote host's commands.

# 9.2 Physical Connections

You may choose to use one of two types of data communications hardware ports.

- Standard equipment includes a bit serial RS-232C port.
- Optionally, a TCP/IP port may be added.

Both RS-232C and TCP/IP ports can be used simultaneously.

Both the host and server must have the same form of communications equipment and complementary set up. For serial communications, baud rates must match and so must the data word format.

The word format for bit serial lines (RS-232C) is comprised of ten signal bits: eight data bits, one start bit, one stop bit and no parity. The eight data bits comprise a byte of information or character whose ASCII value ranges from 0 to 255.

#### 9.2.1 RS-232C Serial Port

RS-232C serial communications are accomplished through an industry standard 9-pin female connector found on the rear panel of Cygnus 2. A mating male connector is required for attachment of a host interface. The host and Cygnus 2 can be separated by up to fifty feet using multiconductor shielded data cable.

Cygnus 2 is configured as DCE (Data Communication Equipment).

**NOTE:** Unpredictable RS-232 hardware/software combinations may occasionally cause a command to not be recognized by Cygnus 2. Consequently, all communications should include an automatic retry procedure. If a command sent via RS-232 does not produce a response from the Cygnus 2 within three seconds, the command should be sent again.



#### 9.2.2 TCP/IP Ethernet Port

The optional TCP/IP interface supports only the Standard Ethernet TCP/IP protocol. Cygnus 2 will communicate via TCP/IP on TCP port number 2101. The interface supports static addressing, DHCP is not supported. Ethernet parameters allowed to be set are the IP address and the net mask.

#### 9.2.2.1 Network Connection

If Cygnus 2 is connected through a network or hub connection, a standard "straight" Ethernet cable is required.

#### 9.2.2.2 How to Set Up the Network Protocol on the PC

Most personal computers (PC) are configured to obtain the IP address, an address which defines the computer on the Internet, automatically from a server.

To communicate directly with Cygnus 2, the Internet protocol (IP) on the PC must be configured manually and an Ethernet crossover cable (for example, IPN 600-1211-P5) must be connected between the PC and Cygnus 2. Some PC's will auto-configure and work with either straight or crossover cable. Instructions are provided here for manually configuring the Internet protocol.

**NOTE:** If the PC only has one Ethernet port (that is, one network connection) then setting the PC for direct communications will prohibit it from accessing the Internet until that setting is reversed.

**NOTE:** These instructions will set two values, the IP address and the Subnet mask, which will most likely prohibit access to the Internet. If these values already contain information then this information should be recorded somewhere for use in restoring the Internet connection.

To access the Network Connection on the PC, select **Network Connections** from the Windows<sup>®</sup> **Start** menu or from the **Control Panel**. See Figure 9-1.


Figure 9-1 Accessing network connections






Select the **Local Area Connection** to be changed, right-click and select **Properties**. See Figure 9-2.

Figure 9-2 Local area connection properties



On the **General** tab, select **Internet Protocol (TCP/IP)** and select the **Properties** button. See Figure 9-3.


Figure 9-3 Internet protocol (TCP/IP) properties





Select the button for **Use the following IP address**, enter the **IP address** and **Subnet mask** shown in Figure 9-4, and select **OK**. With this selection, the PC is assigned an IP address to use when communicating with Cygnus 2. Cygnus 2 is shipped from INFICON with a pre-assigned address of 10.211.72.203. To communicate directly with Cygnus 2 from a PC, the PC must also be assigned an address that starts with 10.211.72 but <u>cannot</u> be set to 10.211.72.203. The example in Figure 9-4 uses the address 10.211.72.100 for the PC.

Figure 9-4 Entering the IP address and subnet mask



Click **OK** to all open dialogs to close out the Internet Protocol setup for the Local Area Connection.



# 9.3 Message Format

The Standard message protocol serves as a structure for the contained command or response information. It also can provide a level of acknowledgment between the host and server and a mechanism for verifying the information content. Cygnus 2 supports the following RS-232 protocols: Standard, Dlog Comma and Dlog Page. The Dlog protocols only provide for one-way transmission of layer data from Cygnus 2.

Hardware handshaking is not supported.

Remote Communications parameters are set up in the General screen Comm page.

**NOTE:** Communication returns "can not do now", Response Error "F", 0x46, when Source Maintenance mode is enabled.

TCP/IP will always operate using the Standard protocol command set. It is not affected by the RS-232 Protocol selection.

#### 9.3.1 Protocol

# Key: <> . . . . Enclosed element further defined below (or above, if repeated use) () . . . . . Optional Element I . . . . . . Or

## 9.3.1.1 Command Packet (Host to Cygnus 2 Message)

<length><message><checksum>

x...x. . . . . One or more of x included

Length	2 bytes Low / High (not including checksum or length bytes). Numeric value from 0 to 57,800 (two bytes) representing the number of characters in the command. In order of transmission, the low byte will precede the high byte. For most commands, the number for characters will be less than 256. In this situation the low byte will contain the character count while the high byte will have
	zero value.



**Command** = <Command Group> (<Command Sub-group>) (<Command ID>) (<Parameter>...<Parameter>)

**Command Group** = 1 ASCII byte, specifying category of command:

- H Hello
- Q Query
- R Remote action
- S Status
- U Update

**Command Sub-group** = 1 ASCII byte, used with some command groups to further specify commands.

#### Command Sub-groups for command Q and U:

- C Source
- G General
- I Input Name.
- L Logic
- M Material
- N Material Name
- O Output Name
- P Process
- S Sensor
- T Type of Output
- V User Message

## Command Sub-groups for command R and S:

- G General
- L Material
- S Sensor

**Command ID** = 1 binary byte. Defines specific command within some command groups and sub-groups.

**Parameter** = <Byte>|<Integer>|<Float>|<String>|

Byte = 1 byte

Integer = 4 byte, low to high

Float = 4 byte, ANSII standard, single precision, low to high

String = Null terminated series of ASCII characters



## 9.3.1.2 Data Type Codes

All parameters are stored internally as four byte words. The data type codes indicate how individual parameters are represented in the four bytes (and how they need to be passed via remote communications).

Table 9-1 Data type codes

Format Code	Displays the value as
REAL_3F20	X.XX or XX.X or XXX
REAL_3X1	XX.X
REAL_4F21	XX.XX or XXX.X
REAL_4F31	X.XXX or XX.XX or XXX.X
REAL_4X1	XXX.X
REAL_4X2	XX.XX
REAL_4X3	X.XXX
REAL_5F32	XX.XXX or XXX.XX
REAL_5X2	XXX.XX
REAL_5X3	XX.XXX
REAL_6F32	XXX.XXX or XXXX.XX
TIME	MM:SS (Minutes:Seconds)
ENCODE	Displays text from a Toggle list
INTEGER	Whole number (no decimal point)
LOCKCODE	XXXX

## REAL\_xXx, REAL\_xFx

Real numbers contain a decimal point.

The resolution (or decimal precision) of the real number displayed depends on the format code.

The stored value is a floating-point number.

#### TIME

Time format is used for times with minutes and seconds.

Time parameters are displayed as MM:SS.

They are stored in memory as integer seconds.



## **ENCODE**

Encode parameters have a defined list of acceptable values.

Usually two to five values are allowed.

As the user toggles through the list the encoded text is displayed on the screen.

The value stored is an integer.

#### **INTEGER**

Integers are 32-bit words.

Although they are stored as signed integers, all current parameters have a lower limit greater than or equal to 0.

## **LOCKCODE**

The lock code parameter is displayed as "XXXX".

The value is stored as an integer.

Unlock code is 0.

# 9.3.1.3 Response Packet (Cygnus 2 to Host Message)

<Length><CCB><Timer><Response Message><Checksum>

Length	Number of bytes including CCB, Timer, and Response Message. Length bytes and Checksum are not included in Length Count. Numeric value from 0 to 65,500 (two bytes) representing the number of characters in the response. Two byte values, high and low order, are required to represent this number. In order of transmission, the low byte will precede the high byte.
CCB	(Condition Code Byte) = 1 byte binary. MSB set indicates command packet error.
Timer	1 byte binary, number between 0 and 255, increments every tenth second.



**Response Message** . . . . . . . . < Command Response>... < Command Response>|< Packet Error Code>

**NOTE:** Number of command responses equals number of commands sent.

If CCB MSB is set, indicating a command packet error, the response message will be a single packet response error.

If the CCB MSB is clear, the command packet was parsed and a valid command packet format was detected.

Checksum . . . . . . . . . . . . . . . . 1 byte, sum, modulo 256, of all bytes,

including CCB, Timer, and Response Message but not including length. Modulo 256 is the numeric value from 0 to 255 representing the modulo 256 remainder of the sum of the values of the ASCII codes that

comprise the response.

Command Response = <ACK><response>|<response error code>

**NOTE:** ACK is the ASCII code with decimal or hex value 6 indicating Positive Acknowledgment of a command. It is not sent when a Response Error Code is returned.

#### Response =

(<integer>|<float>|<string>|<other>.....<integer>|<float>|<string>|<other>)

#### Response Error Code = 1 byte ASCII

A = Illegal Command

B = Illegal parameter value

D = Illegal ID

E = Data not available

F = Cannot do now (some commands require Cygnus 2 to be in Ready/Stop).

L = Length Error, must be greater than 0 and equal to or less than 65,500 bytes.

P = Prior command failed (if one command of a multiple command packet fails, none of the following commands will be done, and this error code will be returned).

#### Packet Error Code = 1 byte ASCII.

C = invalid checksum

F = illegal format (The command could not be processed because a byte in the command packet did not fit the recognized format)

I = invalid message (Unrecognized command in the packet)

M = too many commands (Only 100 allowed)

O = Response length is larger than response buffer



#### 9.3.1.4 Timeouts

If more than 3 seconds pass between characters of a command packet, Cygnus 2 will time out. No response packet is sent, Cygnus 2 will clear its buffers and assume any future characters are the beginning of a new packet.

## 9.4 Communication Commands

The following only include the command portion of the command packet and the response portion of the response packet. The headers/trailers are assumed. (See section 9.3.1, Protocol, on page 9-5 for their definition.)

#### **General definitions**

<Float> = 4 byte, single precision ANSII standard floating point, low end first

<Integer> = 4 byte, signed integer, low end first

<String> = variable length, null terminated ASCII characters.

## 9.4.1 Query and Update Commands

Query commands are used to request established parameter values. There is a specific query command for each parameter group. Depending on the actual hardware configuration, the response to some Query commands may be an E error code indicating there is no data available. Each command has one to three arguments.

Update commands are used to change a specified parameter to a new value or condition. Some parameters are order dependent in that they cannot be updated prior to certain other parameters. There is a specific update command for each parameter group.

The command variations include:

Table 9-2 QUERY and UPDATE commands

QUERY command	Parameter	<b>UPDATE Command</b>
QC	Source Parameters	UC
QG	General Parameters	UG
QI	Input Name	UI
QL	Logic Statements	UL
QM	Material Parameters	UM
QN	Material Name	UN
QO	Output Name	UO
QP	Process-Layer Parameters	UP
QS	Process Sensor Parameters	US
QT	Output Type	UT
QV	User Message	UV



## 9.4.2 Status Commands

Status commands return pertinent information based on a specific request made. Commands are provided to determine global information which is system level, Material or Sensor information. A status code is required for each command. See Status General on page 9-37 to Status Sensor on page 9-42.

The command variations include:

Table 9-3 Status commands

Status command	Parameter
SG	General System Level
SL	Material Information
SS	Sensor Information

Remote commands perform an action based on the specific command given. Commands are provided to affect global features which are system level oriented (RG commands, see Remote General Action on page 9-44) or Material oriented (RL commands see Remote Material Action on page 9-47). Every command requires a remote code and may require a value.

Command variations include:

**RG** = Affects system or Cygnus 2 level conditions.

RL = Affects conditions for a specified Material

## 9.4.3 HELLO Command

H < Command ID > given in hex format

Hex form example for H1 including length and checksum: 0200480149,

#### Response:

Table 9-4 Hello command response

Command ID	Meaning	Response
(0x01)	ASCII name and version	<string> = Cygnus 2 Version x.xx</string>
(0x02)	Version numbers Structure Version Compatibility Version, Range Version	<integer><integer></integer></integer>
(0x03)	Firmware version number	<float></float>

# 9.4.4 Query General Parameter

Command = QG < Command ID>

Command ID = <Byte> See Cmnd ID in Table 9-5

Response = <Integer> | <Float>

**Description** = Type of response depends on command ID, see Data Type column in Table 9-5.



# 9.4.5 Update General Parameter

Command = UG < Command ID > < Parameter Value >

Command ID = <Byte> See Table 9-5

**Parameter Value** = <Integer> | <Float> Type of value depends on command ID, see "Data Type" column in Table 9-5.

**Response** = None (Just header and trailer)

**General Parameters** 

Table 9-5 General parameters

QG & UG Cmnd ID	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes		
9 (0x09)	Thickness Eq 1						
10 (0x0a)	Thickness Eq 2	0/ 654321/ 0	Integer	Values are the Sources whose thicknesses are	No duplicate numbers allowed		
11 (0x0b)	Thickness Eq 3					summed	3.1.0 1.00
12 (0x0c)	Test	0/ 1/ 0	Encode	0 = Off 1 = On			
13 (0x0d)	Time Compressed (10x time acceleration)	0/ 1/ 0	Encode	0 = No 1 = Yes			
14 (0x0e)	Advanced Test (Crystal Fails active)	0/ 1/ 0	Encode	0 = Off 1 = On	Gray font when Test = Off		
15 (0x0f)	Audio Feedback	0/ 1/ 0	Encode	0 = No 1 = Yes			
16 (0x10)	LCD Dimmer Time (Minutes)	0/ 99/ 0	Integer	0 = Always On Non 0 = Minutes till off			
17 (0x11)	Date Format	0/ 1/ 0	Encode	0 = mm/dd/yyyy 1 = dd/mm/yyyy			
18 (0x12)	USB Datalog Format	0/ 2/ 0	Encode	0 = Log Off 1 = Page 2 = Comma			



Table 9-5 General parameters (continued)

QG & UG Cmnd	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes
19 (0x13)	Datalog Xtal Info	0/ 1/ 0	Encode	0 = No 1 = Yes	
20 (0x14)	Graph Scale	0/ 2/ 2	Encode	$0 = Power$ $1 = \pm 10 \text{ Å/s}$ $2 = \pm 20 \text{ Å/s}$	Update will change all Material graphs (Materials 1 to 6) to the Graph Scale choices 0 = Power, 1 = ±10 Å/s, or 2 = ±20 Å/s, only.
21 (0x15)	Graph Scan Rate	0/ 3/ 0	Encode	0 = Auto 1 = Slow 2 = Med 3 = Fast	
22 (0x16)	RS-232 Baud Rate	0/4/4	Encode	0 = 9600	Cannot update via RS-232 communications
23 (0x17)	RS-232 Protocol	0/ 2/ 0	Encode	0 = Standard 2 = Dlog Page 1= Dlog Comma	



Table 9-5 General parameters (continued)

QG & UG Cmnd ID	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes
24 (0x18)	DAC 1 Scale	0.1/ 10.0/ 10.0	REAL_3X1		Update not allowed if Material using DAC is
25 (0x19)	DAC 2 Scale	10.0			running.
26 (0x1a)	DAC 3 Scale				
27 (0x1b)	DAC 4 Scale				
28 (0x1c)	DAC 5 Scale				
29 (0x1d	DAC 6 Scale				
30 (0x1e)	DAC 7 Scale				
31 (0x1f)	DAC 8 Scale				
32 (0x20)	DAC 9 Scale				
33 (0x21)	DAC 10 Scale				
34 (0x22)	DAC 11 Scale				
35 (0x23)	DAC 12 Scale				



Table 9-5 General parameters (continued)

QG & UG Cmnd ID	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes
36 (0x24)	DAC 1 Polarity	0/ 1/ 1	Encode	0 = Negative 1 = Positive	Update not allowed if Material using DAC is
37 (0x25)	DAC 2 Polarity				running.
38 (0x26)	DAC 3 Polarity				
39 (0x27)	DAC 4 Polarity				
40 (0x28)	DAC 5 Polarity				
41 (0x29)	DAC 6 Polarity				
42 (0x2a)	DAC 7 Polarity				
43 (0x2b)	DAC 8 Polarity				
44 (0x2c)	DAC 9 Polarity				
45 (0x2d)	DAC 10 Polarity				
46 (0x2e)	DAC 11 Polarity				
47 (0x2f)	DAC 12 Polarity				



Table 9-5 General parameters (continued)

QG & UG Cmnd ID	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes
49 (0x31)	Channel 1 Graph Scale	0/ 9/ 8	Encode	0 = Power 1 = $\pm 0.1 \text{ Å/s}$ 2 = $\pm 0.5 \text{ Å/s}$ 3 = $\pm 1 \text{ Å/s}$ 4 = $\pm 2 \text{ Å/s}$ 5 = $\pm 3 \text{ Å/s}$ 6 = $\pm 5 \text{ Å/s}$ 7 = $\pm 10 \text{ Å/s}$ 8 = $\pm 20 \text{ Å/s}$ 9 = $\pm 50 \text{ Å/s}$	
50 (0x32)	Channel 2 Graph Scale	0/ 9/ 8	Encode	0 = Power 1 = $\pm 0.1 \text{ Å/s}$ 2 = $\pm 0.5 \text{ Å/s}$ 3 = $\pm 1 \text{ Å/s}$ 4 = $\pm 2 \text{ Å/s}$ 5 = $\pm 3 \text{ Å/s}$ 6 = $\pm 5 \text{ Å/s}$ 7 = $\pm 10 \text{ Å/s}$ 8 = $\pm 20 \text{ Å/s}$ 9 = $\pm 50 \text{ Å/s}$	
51 (0x33)	Channel 3 Graph Scale	0/ 9/ 8	Encode	0 = Power 1 = $\pm 0.1 \text{ Å/s}$ 2 = $\pm 0.5 \text{ Å/s}$ 3 = $\pm 1 \text{ Å/s}$ 4 = $\pm 2 \text{ Å/s}$ 5 = $\pm 3 \text{ Å/s}$ 6 = $\pm 5 \text{ Å/s}$ 7 = $\pm 10 \text{ Å/s}$ 8 = $\pm 20 \text{ Å/s}$ 9 = $\pm 50 \text{ Å/s}$	
52 (0x34)	Channel 4 Graph Scale	0/ 9/ 8	Encode	0 = Power 1 = $\pm 0.1 \text{ Å/s}$ 2 = $\pm 0.5 \text{ Å/s}$ 3 = $\pm 1 \text{ Å/s}$ 4 = $\pm 2 \text{ Å/s}$ 5 = $\pm 3 \text{ Å/s}$ 6 = $\pm 5 \text{ Å/s}$ 7 = $\pm 10 \text{ Å/s}$ 8 = $\pm 20 \text{ Å/s}$ 9 = $\pm 50 \text{ Å/s}$	
53 (0x35)	Channel 5 Graph Scale	0/ 9/ 8	Encode	0 = Power 1 = $\pm 0.1 \text{ Å/s}$ 2 = $\pm 0.5 \text{ Å/s}$ 3 = $\pm 1 \text{ Å/s}$ 4 = $\pm 2 \text{ Å/s}$ 5 = $\pm 3 \text{ Å/s}$ 6 = $\pm 5 \text{ Å/s}$ 7 = $\pm 10 \text{ Å/s}$ 8 = $\pm 20 \text{ Å/s}$ 9 = $\pm 50 \text{ Å/s}$	
54 (0x36)	Channel 6 Graph Scale	0/ 9/ 8	Encode	0 = Power 1 = $\pm 0.1 \text{ Å/s}$ 2 = $\pm 0.5 \text{ Å/s}$ 3 = $\pm 1 \text{ Å/s}$ 4 = $\pm 2 \text{ Å/s}$ 5 = $\pm 3 \text{ Å/s}$ 6 = $\pm 5 \text{ Å/s}$ 7 = $\pm 10 \text{ Å/s}$ 8 = $\pm 20 \text{ Å/s}$ 9 = $\pm 50 \text{ Å/s}$	



# 9.4.6 Query Material Parameter

Command = QM < Command ID> < Material Number>

Command ID = <Byte> See Table 9-6

Material Number = <Byte> 1- 6

Response = <Integer> | <Float>

Type of response depends on command ID, see Data Type column in Table 9-6.

# 9.4.7 Update Material Parameter

Command = UM <Command ID> <Material Number> <Parameter Value>

Command ID = <Byte> See Table 9-6.

Material Number = <Byte> 1-6

**Parameter Value** = <Integer> | <Float> Type of value depends on command ID, see Data Type column in Table 9-6.

Table 9-6 Material parameters

QM & UM Cmnd	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes
1 (0x01)	Density (g/cc)	0.1/ 99.999/ 1.0	REAL_5X3		
2 (0x02)	Z-Ratio	0.1/ 15.0/ 1.0			
3 (0x03)	Master Tooling (%)	1.0/ 999.9/ 100.0	REAL_4X1		
4 (0x04)	Control Loop	0/ 2/ 0	Encode	0 = NonPID 1 = PI 2 = PID	
5 (0x05)	Process Gain (Å/s/%)	0.01/ 999.99/ 10.0	REAL_ 5F32		
6 (0x06)	Time Constant (seconds)	0.01/ 9999.99/ 1.0	REAL_ 6F32	Gray font if Control Loop = NonPID	
7 (0x07)	Dead Time (seconds)	0.01/ 9999.99/ 1.0	REAL_ 6F32	Gray font if Control Loop = NonPID	



Table 9-6 Material parameters (continued)

QM & UM Cmnd	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes
9 (0x09)	Maximum Power (%)	0.01/ 99.99/ 90.0	REAL_4X2		
10 (0x0a)	Minimum Power (%)	0.00/ 99.98/ 0.0	REAL_4X2		
11 (0x0b)	Max Power Option	0/3/3	Encode	0 = Continue 1 = Post-Dep 2 = Stop All 3 = Stop Matl	
12 (0x0c)	PreCond Soak Power (%)	0.0/ 99.99/	REAL_4X2		
13 (0x0d)	PreCond Rise Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time		
14 (0x0e)	PreCond Soak Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	Time Note: Times are displayed as mm:ss. Times are stored as seconds. The maximum number of seconds is 5999. This would be displayed as 99:59.	
15 (0x0f)	Soak Power 1 %	0.0/ 99.99/	REAL_4X2		
16 (0x10)	Rise Time 1 (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note	
17 (0x11)	Soak Time 1 (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note	
18 (0x12)	Soak Power 2 %	0.0/ 99.99/	REAL_4X2		



Table 9-6 Material parameters (continued)

QM & UM Cmnd	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes
19 (0x13)	Rise Time 2 (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time		
20 (0x14)	Soak Time 2 (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note	
21 (0x15)	Auto Soak 2	0/ 1/ 0	Encode	0 = No 1 = Yes	
22 (0x16)	Dep After Pre-Dep	0/ 1/ 1	Encode	0 = No 1 = Yes	
23 (0x17)	Delay Option	0/ 3/ 0	Encode	0 = None, 1 = Shutter 2 = Control, 3 = Both	
24 (0x18)	Control Delay Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note	Gray font unless Delay option is set to control or both.
25 (0x19)	Shutter Delay Accur (%)	1/ 99/ 5	Integer		Gray font unless Delay option is set to shutter or both.
28 (0x1c)	Feed Power (%)	0.0/ 99.99/	REAL_4X2		
29 (0x1d	Feed Ramp Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note	
30 (0x1e)	Feed Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note	
31 (0x1f)	Idle Power (%)	0.0/ 99.99/	REAL_4X2		
32 (0x20)	Idle Ramp Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note	
33 (0x21)	Rate (Å/s)	0/ 999.9/ 0	REAL_ 4F31		



Table 9-6 Material parameters (continued)

QM & UM Cmnd ID	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes	
34 (0x22)	Time Limit (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note		
35 (0x23)	Rate Filter Time (seconds)	0/ 6/ 0	Encode	0 = 0.1 $1 = 0.4$ $2 = 1.03 = 4.0$ $4 = 10.05 = 20.0$ $6 = 30.0$		
36 (0x24)	Time Power Avg Time (Minutes)	0/ 30/ 0	Integer			
37 (0x25)	Ion Assist Deposit	0/ 1/ 0	Encode	0 = No, 1 = Yes	Update not allowed if Material is running.	
38 (0x26)	On Final Thickness	0/ 2/ 1	Encode	0 = Continue, 1 = Post-Dep 2 = NonDepCont		
39 (0x27)	Ramp 1 Rate (Å/s)	0/ 999.9/ 0	REAL_ 4F31			
40 (0x28)	Start Ramp 1 (KÅ)	0/999.999/	REAL_ 4F31	Value must be less than Start Ramp 2 thickne value if Start Ramp 2 thickness value is non-ze		
41 (0x29)	Ramp 1 Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note		
42 (0x2a)	Ramp 2 Rate (Å/s)	0/ 999.9/ 0	REAL_ 4F31			
43 (0x2b)	Start Ramp 2 (KÅ)	0/999.999/	REAL_ 4F31	Value must be of Start Ramp 1 thick		
44 (0x2c)	Ramp 2 Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note		
45 (0x2d)	RateWatcher Option	0/ 1/ 0	Encode	0 = No, 1 = Yes		
46 (0x2e)	RateWatcher Time (seconds) (mm:ss)	0/ 5999/ 0 0/ 99:59/ 0	Time	See Time Note	Grey font unless RateWatcher option set to Yes.	
47 (0x2f)	RateWatcher Accuracy (%)	1/ 99/ 5	Integer			



Table 9-6 Material parameters (continued)

QM & UM Cmnd	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes			
115 (0x73)	Failure Action	1/ 4/ 3	Encode	1 = PostDp 2 = Stop All 3 = Stop Matl 4 = TimePw				
116 (0x74)	CrystalTwo Tooling (%)	1.0/ 999.9/ 100.0	REAL_4X1	Gray font if Sensor Typ	e is not CrystalTwo			
117 (0x75	Xtal Position First	0/ 12/ 0	Integer	Gray font if Sensor Type is Single, CrystalTwo or Generic				
118 (0x76)	Xtal Position Last	0/ 12/ 0	Integer	Gray font if Sensor Type is Single, CrystalTwo, or Generic				
121 (0x79)	Quality Percent (%)	0/ 99/ 0	Integer					
122 (0x7a)	Quality Counts	0/ 99/ 0	Integer					
123 (0x7b)	Stability Single (Hz)	0/ 9999/ 0	Integer		1-24 are excluded			
124 (0x7c)	Stability Total (Hz)	0/ 9999/ 0	Integer		1-24 are excluded			
125 (0x7d)	Recorder Output	0/ 12/ 0	Integer	0 = No recorder	Not allowed to be the same as a Source DAC			
126 (0x7e)	Recorder Function	0/ 3/ 0	Encode	0 = Filtered Rate 1 = Thick 2 = RateDev 3 = Power	Gray font if recorder output set to 0			
127 (0x7f)	Recorder Range	0/ 99999/ 100	Integer	Gray font if recorder output is set to 0 or Recorder Function is Power or Rate Deviation				

**Time Note:** Times are displayed as mm:ss. Times are stored as seconds. The maximum number of seconds is 5999. This would be displayed as 99:59.



# 9.4.8 Query Sensor Parameter

Command = QS < Command ID> < Sensor Number>

Command ID = <Byte> See Table 9-7.

**Sensor Number** = <Byte> Sensor number 1 - 6

Response = <Integer> | <Float>

Type of response depends on command ID, see "Data Type" column in Table 9-7.

# 9.4.9 Update Sensor Parameter

Command: = US < Command ID> < Sensor Number> < Parameter Value>

Command ID = <Byte> See Table 9-7

**Sensor Number** = <Byte> Sensor number 1 - 6

**Parameter Value** = <Integer> | <Float> Type of value depends on command ID, see Data Type column in Table 9-7.

Table 9-7 Sensor parameters

QS & US Cmnd ID	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes	
1 (0x01)	(Sensor) Shutter Out(put)	0/ 38/ 0	Integer	0 = not d Update not allowed if the accepted if output in us	Sensor is running. Not	
2 (0x02)	Sensor Type	0/ 4/ 0	Encode	0 = Single 1 = XtalTwo 2 = XtalSix 3 = Xtal12 4 = Generic	Update not allowed if the Sensor is running.	
3 (0x03)	(Sensor) Switch Out(put)	0/ 38/ 0	Integer	0 = not defined  Gray font if Sensor Type =  Single	Update not allowed if the Sensor is running. Not accepted if output in use by other hardware.	
4 (0x04)	Auto-Z	0/ 1/ 0	Encode	0 = No, 1 = Yes		



Table 9-7 Sensor parameters (continued)

QS & US Cmnd	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes	
5 (0x05)	# of Positions	1/ 12/ 1	Integer			
6 (0x06)	# of Pulses	1/ 10/ 1	Integer	Visible only when Sensor	Update not allowed if the Sensor is running.	
7 (0x07)	Pulse On (Time) (Seconds)	0.1/ 9.9 /1	REAL_3X1	Type = 4		
8 (0x08)	Pulse Off (Time) (Seconds)	0.1/ 9.9 /1	REAL_3X1			
9 (0x09)	Recorder Output	0/ 12/ 0	Integer	0 = not defined	Not allowed to be the same as a Source DAC	
10 (0x0a)	Recorder Function	0/ 2/ 0	Encode	0 = Unfiltered Rate 1 = Thick 2 = RateDev	Note: Rate is not affected by Rate Filter Time	
11 (0x0b)	Recorder Range	0/ 99999/ 100	Integer		Gray font when Recorder Function = Rate Deviation	

# 9.4.10 Query Source Parameter

Command = QC < Command ID> < Source number>

**Command ID** = <Byte> See Table 9-8.

**Source Number** = <Byte> Source number 1 - 6

Response = <Integer> | <Float>

Type of response depends on command ID, see Data Type column in Table 9-8.

# 9.4.11 Update Source Parameter

Command = UC <Command ID> <Source number> <Parameter Value>

Command ID = <Byte> See Table 9-8.

**Source Number** = <Byte> Source number 1 - 6

Parameter Value = <Integer> | <Float>

Type of value depends on command ID, see Data Type column in Table 9-8.



Table 9-8 Source parameters

QC & UC Cmnd ID	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes		
1 (0x01)	DAC Output	0/ 12/ #	Integer	0 = not defined.  Default for Source 1 is 1,  Source 2 is 2, etc.	Update not allowed if Source is running. Not allowed to set if the DAC is set as a recorder output.		
2 (0x02)	(Source) Shutter Output	0/ 38/ 0	Integer	0 = not defined.Upd Source is r			
3 (0x03)	Number of Crucibles	0/ 5/ 0	Encode	0 = 1 1 = 4 2 = 8 3 = 16 4 = 32 5 = 64			
4 (0x04)	Crucible Output	0/ 38 /0	Integer	0 = not defined Gray font if Number of Crucibles = 0			
5 (0x05)	Turret Feedback	0/ 1/ 0	Encode	0 = No 1 = Yes Gray font if Number of Crucibles = 0	Update not allowed if Source is running.		
6 (0x06)	Turret Input	0/ 28/ 0	Integer	0 = not defined Gray font if Turret Feedback = No or if Number of Crucibles = 1			
7 (0x07)	Turret Delay (Seconds)	2/ 180/ 5	Integer	Time out interval with feedback.Delay interval without feedback. Gray font if Number of Crucibles = 0 or if Number of Crucibles = 1			



# 9.4.12 Query Process Material Parameter

Command: QP <Command ID> <Process Number> <Material Number>

Command ID = <Byte> See Table 9-9.

Process Number = <Byte> 1

Material Number = <Byte> 1 - 6

Response = <Integer> | <Float>

Type of response depends on command ID, see Data Type column in Table 9-9.

# 9.4.13 Update Process Material Parameter

**Command** = UP < Command ID> < Process Number> < Material Number> < Parameter Value>

**Command ID** = <Byte> See Table 9-9.

Process Number = <Byte> 1

Material Number = <Byte> 1 to 6

**Parameter Value** = <Integer> | <Float> Type of value depends on command ID, see Data Type column in Table 9-9.

Table 9-9 Process material parameters

QP & UP Cmnd	Name (Units)	Range: Low Limit/ High Limit/ Default	Data Type	Notes	Update Restrictions and Display Notes
2 (0x02)	(Final Thickness) Final Thick (KÅ)	0.0/ 999.999/ 0.0	REAL_5F32		
3 (0x03)	(Thickness Limit) Thick Limit (KÅ)	0.0/ 999.999/ 0.0	REAL_5F32		
4 (0x04)	(Crucible) Cruc	1/ 64/ 1	Integer		Update not allowed if Material is running



## 9.4.14 Query Material Name

Command = QN <Material Number>

Material Number = <Byte> 1-6

Response = < Material Name>

**Material Name** = <String> Up to 15 characters, null terminated. The string returned will be a blank if the default Material # name has not been changed.

# 9.4.15 Update Material Name

Command = UN < Material Number> < Material Name>

Material Number = <Byte> 1 - 6

**Material Name** = <String> Up to 15 characters, null terminated

**Response** = None (Just header and trailer)

## 9.4.16 Query Input Name

Command = QI <Input Number>

Input Number = <Byte> 1 - 28

Response = <Input Name>

Input Name = <String> Up to 15 characters, null terminated

## 9.4.17 Update Input Name

Command = UI <Input Number> <Input Name>

Input Number = <Byte> 1 - 28

**Input Name** = <String> Up to 15 characters, null terminated

**Response** = None (Just header and trailer)

Input Names may only be updated if Cygnus 2 is in Ready or Stop.

**NOTE:** UI changes are not allowed while a Material is running. The UI command will not allow updating a name set by hardware designation, unless it is identical to the defined hardware name.

# 9.4.18 Query Output Name

Command = QO <Output Number>

Output Number = <Byte> 1 - 38

Response = <Output Name>

Output Name = <String> Up to 15 characters, null terminated



## 9.4.19 Update Output Name

Command = UO <Output Number> <Output Name>

Output Number = <Byte> 1 - 38

Output Name = <String> Up to 15 characters, null terminated

**Response** = None (Just header and trailer)

Output Names may only be updated if Cygnus 2 is in Ready or Stop.

**NOTE:** UO changes are not allowed while a Material is running. The UO command will not allow updating a name set by hardware designation, unless it is identical to the defined hardware name

# 9.4.20 Query Output Type

Command = QT <Output Number>

Output Number = <Byte> 1 - 38

Response = <Output Type>

Output Type =  $\langle Byte \rangle 0$  or 1 (0 = NO, 1 = NC)

# 9.4.21 Update Output Type

Command = UT <Output Number> <Output Type>

Output Number = <Byte> 1 - 38

Output Type =  $\langle Byte \rangle 0$  or 1 (0 = NO, 1 = NC)

**Response:** None (Just header and trailer)

**NOTE:** UT changes are not allowed while a Material is running.

# 9.4.22 Query User Message

Command = QV < User Message Number>

User Message Number = <Byte> 1 - 10

Response = < User Message>

**User Message** = <String> Up to 19 characters, null terminated



## 9.4.23 Update User Message

Command = UV < User Message Number> < User Message Name>

**User Message Number = <Byte> 1 - 10** 

**User Message # Name = <String>** Up to 19 characters, null terminated

**Response** = None (Just header and trailer)

**NOTE:** A user message that is currently displayed will not be changed on the screen until the message area is refreshed.

# 9.4.24 Query Logic Statement

Command = QL <Statement Number>

Statement Number = <Byte> 1 - 100

Response = <Length of logic elements> <Set of elements>

**NOTE:** This length is NOT the same as the length of the packet. It tells how many bytes follow in the "event/action" <set of elements>.

Response can be made up of the following elements. All elements except Numeric 2 are one byte. Numeric 2 is a 4-byte integer.

 AND connector
 0x26

 Or connector
 0x7C

On connector . . . . . . . . . . . . . . . . 0x40

Event code . . . . . . . . . . . . <byte> (See note 1)

Negated Event code. . . . . . . . <byte> (See note 1)

Numeric 2..... <integer> (See note 3)

Space . . . . . . . . . . . . . . . . . 0x20 separates "if" and "then"

Terminator . . . . . . . . . . . . . . (ETX) 0x03 Indicates end of "then"



**Note 1:** For definition of event and action codes see section 9.4.26 on page 9-31 for the Event list and section 9.4.27 on page 9-35 for the Action list. The codes sent via communications would be the number listed there. If the event is to be negated, the event code will be negated as well. For example, the code for external input is 0x41. To indicate not external input (that is, input not set) the code is 0xBF. Action codes may not be negated.

**Note 2:** Numeric 1 is present if the event code requires a numeric. The range is dependent on the specific code.

**Note 3:** Numeric 2 is present if the event code requires a second numeric. It is a 4-byte integer. The range is dependent on the specific code.

**Note 4:** The Action Numeric is present if the action code requires a numeric. The range is dependent on the specific code.

The ordering of the logic elements is as follows: (The term Event Code includes Negated Event Code)

#### **Event Terms**

- 1 First element of term can be '(', a space, or an Event code
- 2 If space, there are no events, go straight to Action Terms. (see below)
- 3 if '(', next element must be event code
- 4 If event code, if numerals are required for specific code, they must be next
- 5 After event code, with its numerals, there may or may not be a ')'
- 6 Next must be either a connector or a space.
- 7 If a space, move on to Action Terms.
- **8** If connector, start next event (go to point 3. above).

**NOTE:** The last term cannot have a connector

#### **Action Terms**

Up to five action codes make up the action terms. Each code will be followed by a numeric if it is required. There are no connectors passed with the actions, as all actions are anded together.

The logic statement ends with a 0x03 (ETX).



## 9.4.25 Update Logic Statement

**Command** = UL<Statement Number><Length of logic elements> <Set of elements>

Statement Number = <Byte> 1 - 100

**Length of logic elements** = <Byte> number of bytes of the Logic element for each statement, including the 0x03 (ETX) terminator.

**Set of elements** = See description in QL above.

**Example**: IF External Input 21 and External Input 2 and External Input 18 and External Input 8

THEN Start Timer 1 and Extern Out On 10

Hex code for above including length and checksum: 1500554C01114115264102264112264108205101410A031A

**Response** = None (Just header and trailer)

Logic changes are not allowed while a process is running or if Cygnus 2 is in a stop.

## 9.4.26 Cygnus 2 Event List

Events used in the Logic Statement IF section. Logic codes are used in the remote communication query and update commands. The Logic codes start at 0x41 because there are formatting codes (for connectors, parentheses, etc.) used in the logic statements that are ASCII codes below 0x41. See Table 9-10.

Table 9-10 Event list

Events	1st numeric (1 Byte) (XXX)	Min	Max	2nd numeric (Integer) (YYY)	Min	Max	Logic Code	Logic Code Negated
Parenthesis								
External Input	Input #	1	28				0x41	0xBF
Pre-Deposit							0x42	0xBE
In Deposit							0x43	0xBD
Post-Deposit							0x44	0xBC
Non Deposit							0x45	0xBB
Ready							0x46	0xBA
Crucible Switch							0x47	0xB9
PreCond Rise							0x48	0xB8
PreCond Soak							0x49	0xB7



Table 9-10 Event list (continued)

Events	1st numeric (1 Byte) (XXX)	Min	Max	2nd numeric (Integer) (YYY)	Min	Max	Logic Code	Logic Code Negated
Rise 1							0x4A	0xB6
Soak 1							0X4B	0xB5
Rise 2							0x4C	0xB4
Soak 2							0x4D	0xB3
Shutter Delay							0x4E	0xB2
Deposit							0x4F	0xB1
Rate Ramp 1							0x50	0xB0
Rate Ramp 2							0x51	0xAF
Manual							0x52	0xAE
Time Power							0x53	0xAD
Non-Dep Control							0x54	0xAC
Non-Dep Hold							0x55	0xAB
Feed Ramp							0x56	0xAA
Feed							0x57	0xA9
Idle Ramp							0x58	0xA8
Idle							0x59	0xA7
Stop							0x5A	0xA6
Final Thick							0x5C	0xA4
Thick Limit							0x5D	0xA3
Thick Sum XXX See Note 4	Equation #	1	3	Thickness xxx.xxx	0	999.9	0x5E	0xA2
Time Limit							0x5F	0xA1
Material XXX	Material #	1	6				0x64	0x9C
Material End XXX	Material # 0 = Any	0	6				0x66	0x9A
Timer Minutes (See Notes 2 & 3)	Timer #	1	20	Number of minutes	00:00	99:59	0x69	0x97



Table 9-10 Event list (continued)

Events	1st numeric (1 Byte) (XXX)	Min	Max	2nd numeric (Integer) (YYY)	Min	Max	Logic Code	Logic Code Negated
Timer Seconds (See Note 1)	Timer #	1	20	Time in Tenths of Seconds	0	999.9	0x6A	0x96
Count limit	Counter #	1	20	Counter value	0	999	0x6B	0x95
Statement	Logic Statement #	1	100				0x6C	0x94
Xtal Fail	Sensor # 0 = any	0	6				0x6D	0x93
Xtal Switching	Sensor # 0 = any	0	6				0x6E	0x92
Max Power							0x6F	0x91
Min Power							0x70	0x90
Not Used							0x71	0x8F
Not Used							0x72	0x8E
Ion Assist Dep							0x73	0x8D
Auto-Z Fail	Sensor # 0 = any	0	6				0x74	0x8C
Cruc Sw Fail							0x75	0x8B
Rate < 0.1							0x76	0x8A
Shutter Dly Error							0x77	0x89
Not Used							0x78	0x88
Not Used							0x79	0x87
Xtal Life > xxx	Sensor # 0 = any	0	6	% Life	1	99	0x7A	0x86
Xtal Activity < xxx	Sensor # 0 = any	0	8	Activity	1	999	0x7B	0x85
Computer Cntrl							0x7C	0x84
Test							0x7D	0x83



Table 9-10 Event list (continued)

Events	1st numeric (1 Byte) (XXX)	Min	Max	2nd numeric (Integer) (YYY)	Min	Max	Logic Code	Logic Code Negated
Not Used							0x7E	0x82
Rate Dev(iation) Err(or)							0x7F	0x81

**Note 1:** Seconds are entered via remote communications as tenths of seconds. Seconds are entered by keyboard as whole numbers.

**Note 2:** The time is entered via remote communications as whole minutes. 99 hours = 5940 minutes, so 99 hours + 59 minutes = 5999 minutes maximum. The time entered by keyboard is in hours and minutes.

**Note 3:** Maximum number of minutes is 59. The entry of '00:65' is invalid. That time can be entered as '01:05'.

Note 4: Thick Sum will be sent as an integer Angstroms (the number multiplied by 1000).



# 9.4.27 Cygnus 2 Action List

Actions are triggered in the Logic Statement THEN section. Logic codes are used in the remote communication query and update commands. Some actions that require a numeric may act on all items by entering a zero, as noted in Table 9-11.

Table 9-11 Action list

Actions	Numeric (Byte)	Min	Max	Logic Code
Extern Out On XXX			38	0x41
Extern Out Off XXX	Output #	1		0x42
Not Used				0x43
Not Used	-		6	0x44
Start XXX	-	0		0x45
Reset XXX	-			0x46
Stop XXX	Natorial #			0x47
Zero Deposit Time XXX	- Material #			0x48
Zero Thick XXX	-			0x49
Trig Fnl Thick XXX	-			0x4A
Continue Dep XXX	-			0X4B
Start Deposit XXX	-			0x4C
Go to NonDep XXX	-			0x4D
Go to PostDep XXX	-			0x4E
Increment Count XXX				0x4F
Clear Counter XXX	Counter #	1	20	0x50
Start Timer XXX				0x51
Cancel Timer XXX	Timer #	1	20	0x52
Switch Xtal XXX	Sensor#	1	6	0x53



Table 9-11 Action list (continued)

Actions	Numeric (Byte)	Min	Max	Logic Code
* PreCond S/H Off XXX			6	0x54
* PreCond S/H On XXX				0x55
* Soak 1 Hold Off XXX				0x56
* Soak 1 Hold On XXX		0		0x57
* Soak 2 Hold Off XXX	Material #			0x58
* Soak 2 Hold On XXX	Materiai #			0x59
* Clock Hold Off				0x5A
* Clock Hold On				0x5B
* Start Inhbt Off **				0x5C
* Start Inhbt On **				0x5D
* Xtl Fl Inhbt Off				0x5E
* Xtl Fl Inhibt On	Sensor#	0	6	0x5F
* RWS Inhibit Off XXX (RWS = RateWatcher Sample)		0	6	0x60
* RWS Inhibit On XXX	Material #			0x61
* RWS Init(iate) Off XXX				0x62
* RWS Initiate On XXX				0x63
Message On XXX See Note		1	10	0x64
Message Off XXX See Note	Message #			0x65

**Note:** There are ten User Messages available for the user to construct. These messages can be displayed and cleared via logic actions. User Messages are constructed on the General page Message screen.

**Note:** \* = Remote Comm and Logic will be independent. Methods used to set action must be used to clear action.

\*\* = Start Inhibit will carry through a power cycle



## 9.4.28 Status General

Command = SG < Command ID > < Option >

**Command ID** = <Byte> See "Description" in Table 9-12.

Option = <Byte> |< Integer > | <32 Bit Word> | <48 Bit Word>

**Response** = <Byte>... <Byte> | <Integer>...<Integer

Table 9-12 Status general commands

SG Comm and ID	Description	Option	Number of bytes in the response	Data Returned	Notes
0 (0x00)	N/A				
3 (0x03)	Output status		5	<byte><byte><byte> <byte><byte> Each bit represents an output, bit set means output active.</byte></byte></byte></byte></byte>	MSB of first byte is output 1.MSB of the fifth byte is output 33.
4 (0x04)	Input status		4	<byte><byte><byte> <byte> Each bit represents an input. Bit set means input active.</byte></byte></byte></byte>	MSB of first byte is input 1. MSB of the fourth byte is input 25.
5 (0x05)	Logic statement status		13	<byte><byte><byte> <byte><byte><byte> <byte><byte><byte> <byte><byte> <byte><byte> <byte> <byte> Each bit represents a logic statement, bit set means logic statement is true.</byte></byte></byte></byte></byte></byte></byte></byte></byte></byte></byte></byte></byte></byte></byte>	MSB of first byte is logic statement 1.MSB of the thirteenth byte is logic statement 97.
6 (0x06)	Status Messages		8	<byte><byte><byte> <byte><byte> <byte><byte></byte></byte></byte></byte></byte></byte></byte>	See encodes in section 13.1 on page 13-1. One bit is set for each error. Multiple bits may be set.



Table 9-12 Status general commands (continued)

SG Comm and ID	Description	Option	Number of bytes in the response	Data Returned	Notes	
7 (0x07)	Status Message Designators	<status Message Word&gt; 8 bytes</status 	1-13 (Can have 12 DAC recorders)	<byte>  <byte><byte></byte></byte></byte>	Status Message Word corresponding to one of the status messages, as encoded in the SG 6 command.	
	This indicates which status message designators are to be returned. Note that only one bit may be set, that is, only the designators for one error can be requested per command.Returns a string of bytes. First byte is the number of bytes following. The following bytes indicate the designators for the requested status message.If there are no designators, the first byte returned will be zero.					
9 (0x09)	Transient Messages		1	<byte></byte>	See encodes in section 13.4 on page 13-6.	
10 (0x0a)	Sensor Status		6	<byte><byte><byte> <byte><byte></byte></byte></byte></byte></byte>	One byte for each Sensor Range between 0 and 5.	
	0 = Good Crystal and active. 1 = Failed Crystal and active. 2 = Invalid Measurement on Crystal and active. 3 = Good Crystal and inactive. 4 = Failed Crystal and inactive. 5 = Invalid Measurement on Crystal and inactive.					
11 (0x0b)	Timer Status	Timer Number <integer> 1 - 20</integer>	1	<byte></byte>	Response:0 = Timer inactive1 = Timer active	
12 (0x0c)	Timer Value	Timer Number <integer> 1 - 20</integer>	4	<integer></integer>	Response is in tenths of seconds. Max Time = 99:59:59.0 (3599990 tenths of seconds)	
13 (0x0d)	Counter Value	Counter Number <integer> 1 - 20</integer>	4	<integer></integer>		
14 (0x0e)	Thickness Sum	Equation number <integer> 0 - 3</integer>	4 or 12	<float> or <float><float> <float></float></float></float></float>	0 = All thickness equations 1 - 3 = the number of the equation to return.	
15 (0x0f)	Get date		12	<integer><integer> <integer></integer></integer></integer>	Integers for month, day, year or day, month year, depending on date format general parameter.	



Table 9-12 Status general commands (continued)

SG Comm and ID	Description	Option	Number of bytes in the response	Data Returned	Notes	
16 (0x10)	Get time		12	<integer><integer> <integer></integer></integer></integer>	Integers for the hour, minute and the seconds.	
17 (0x11)	System Configuration (What boards are present.)		2	<byte><byte></byte></byte>	Bit	
	0x0001 = Measurement Bd 1 0x0002 = Measurement Bd 2 0x0004 = Measurement Bd 3, 0x0010 = I/O Board 1, 0x0020 = I/O Board 2, 0x0040 = I/O Board 3, 0x0080 = Optional DAC Board,					
	0x0100 = Temperature Control Board 1, 0x0200 = Temperature Control Board 2, 0x0400 = Ethernet Board, 0x0800 = {Reserved}, 0x1000 = {Reserved}, 0x2000 = {Reserved}, 0x4000 = {Reserved}, 0x8000 = {Reserved}					



## 9.4.29 Status Material

Command = SL < Command ID > < Material >

**Command ID** = <Byte> See "Description" in Table 9-13.

**Material** =  $\langle Byte \rangle Material number (0 - 6)$ 

◆ Material = 0 will return the status of six Materials. The response will include all active Materials.

**Response** = See Data Returned in Table 9-13.

Table 9-13 Status material

SL Command ID	Description	Number of bytes in the response	Data Returned	Notes	
0 (0x00)	N/A				
1 (0x01)	Filtered Rate	4 or 24	<float></float>	Å/S	
2 (0x02)	Displayed Rate	4 or 24	<float></float>	Å/S Averaged over one second	
3 (0x03)	Source Power Output	4 or 24	<float></float>	%	
4 (0x04)	Thickness	4 or 24	<float></float>	incremented while the source or substrate shutter is open as in Deposit, KÅ	
5 (0x05)	State	1 or 6	<byte>or <byte><byte> <byte><byte></byte></byte></byte></byte></byte>	See encodes in section 3.4 on page 3-23	
6 (0x06)	State Time	4 or 24	<integer></integer>	Seconds in the current state	
7 (0x07)	Active Sensors	1 or 6	<byte> or <byte><byte> <byte><byte></byte></byte></byte></byte></byte>	Active Sensors Byte is a six-bit word where each bit represents a Sensor	
	Any bit set indicates a Sensor is active for the requested Material.  Bit 0 = Sensor 1, bit 1 = Sensor 2, thru bit 5 = Sensor 6.				
8 (0x08)	Power Source Number	1 or 6	<byte> or <byte><byte> <byte><byte></byte></byte></byte></byte></byte>	Source number for the requested Material.	
9 (0x09)	Accumulated Layer Time	4 or 24	<integer></integer>	Seconds since "Ready"	



Table 9-13 Status material (continued)

SL Command ID	Description	Number of bytes in the response	Data Returned	Notes
10 (0x0a)	Deposit Average Rate	4 or 24	<float></float>	KÅ Based on Averaging Time parameter. Only available when in a control state.
11 (0x0b)	Deposit Average Power	4 or 24	<float></float>	% Based on Averaging Time parameter. Only available when in a control state.
12 (0x0c)	Raw Rate	4 or 24	<float></float>	Å/S
13 (0x0d)	One Minute Averages for Rate & Power	8 or 48	<float><float></float></float>	Returns a 'No Data Error' if not enough data to do a one minute average of the rate or the power
14 (0x0e)	Rate Deviation / power output trend	Varies with # of data points	<integer><float> <float></float></float></integer>	Number of bytes in the response. Average values from the operate screen graph. Format of each data point.
15 (0x0f)	State before Stop	1 or 6	<byte> or <byte><byte><byte> <byte><byte></byte></byte></byte></byte></byte></byte>	See encodes in section 3.4 on page 3-23. If not currently in Suspend, will return "No Data Error"
16 (0x10)	Data Log	64 or 384	Multiple pieces of information	See section 3.5.9 on page 3-35 for order of data.
17 (0x11)	Data Log with Xtal History	448 or 2,688	<data +="" crystal<br="" log="">data for 12 crystals per Sensor&gt;.</data>	See section 3.5.9 on page 3-35 for order of data. Length of response = 64 bytes Data Log + 384 bytes Xtal History Xtal History = 32 bytes per crystal, 12 crystals in 6 Sensors = 32*12*6=2304 bytes
18 (0x12)	Cause of Stop	1 or 6	<byte> or <byte><byte> <byte><byte></byte></byte></byte></byte></byte>	See encodes in section 13.3 on page 13-5. If not currently in Stop, "Data not available" error will be returned.



#### 9.4.30 Status Sensor

Command = SS < Command ID > < Sensor >

**Command ID** = <Byte> See "Description" in Table 9-14.

**Sensor** = <Byte> Sensor number (0 - 6)

If the Sensor number is zero the response will give the value for all six Sensors.

**Response** = See Data Returned in Table 9-14.

Table 9-14 Status sensor

SS Command ID	Description	Number of bytes in the response	Data Returned	Notes	
0 (0x00)	Crystal Life	1 or 6	<byte> or <byte><byte><byte> <byte><byte></byte></byte></byte></byte></byte></byte>	One byte for each Sensor. Range will be 0 - 100	
1 (0x01)	Crystals Remaining	1 or 6	<byte> or <byte><byte> <byte><byte></byte></byte></byte></byte></byte>	One byte for each Sensor. Range between 0 and 12. Number of good crystals on a CrystalTwo, Crystal6 or Crystal12 Sensor. Returns either a 0 (current crystal failed) or a 1 (current crystal good) for a Single sensor. The command is not intended to be used for Generic sensor - returns NO_DATA.	
2 (0x02)	Crystal Position	1 or 6	<byte> or <byte><byte><byte> <byte><byte></byte></byte></byte></byte></byte></byte>	One byte for each Sensor. Range between and 12. The current crystal position on a CrystalTwo, Crystal6 or Crystal12.	
3 (0x03)	Sensor Status	1 or 6	<byte> or <byte><byte> <byte><byte></byte></byte></byte></byte></byte>	One byte for each Sensor.  Bit1 Bit 0 0 0 Good Crystal 0 1 Failed Crystal 1 0 Invalid Measurement	
4 (0x04)	Fundamental Frequency	8 or 48	<long> or <long><long><long> <long><long></long></long></long></long></long></long>	One long integer for each Sensor. Unconverted. To convert to Hz, multiply by 0.000873114913702011	



Table 9-14 Status sensor (continued)

SS Command ID	Description	Number of bytes in the response	Data Returned	Notes
5 (0x05)	Fundamental Activity	4 or 24	<integer> or <integer><integer> <integer><integer> <integer><integer></integer></integer></integer></integer></integer></integer></integer>	One integer for each Sensor Range 0 - 999
6 (0x06)	Current Z-Ratio	4 or 24	<float> or <float><float> <float><float></float></float></float></float></float>	Z-Ratio currently in use.
7 (0x07)	Anharmonic Frequency	8 or 48	<long> or <long><long> <long><long></long></long></long></long></long>	One long integer for each Sensor. Unconverted, to convert to Hz, multiply by 0.000873114913702011
8 (0x08)	Anharmonic Activity	4 or 24	<integer> or <integer><integer> <integer><integer> <integer><integer></integer></integer></integer></integer></integer></integer></integer>	One Integer for each Sensor Range 0 - 999
9 (0x09)	New crystal Frequency	16 or 96	<long><long> or &lt; Long&gt;x12</long></long>	Returns the Fundamental and Anharmonic "NEW" crystal frequencies
10 (0x1a)	LCQ value	4 or 24	<float> or <float><float> <float><float></float></float></float></float></float>	Returns the LCQ running value (for factory diagnostic use only)
11 (0x0b)	N/A			
12 (0x0c	Sensor Thickness	4 or 24	<float> or <float><float> <float><float><float></float></float></float></float></float></float>	kÅ Returns Sensor thickness, increments in all states including Ready & Stop. Reset zeros it.



#### 9.4.31 Remote General Action

**Command** = RG < Command ID> (< Action Value>)

**Command ID** = <Byte> See Table 9-15.

Action Value = <Byte>... <Byte> | <Integer>...<Integer>|<Float>...<Float>

See Table 9-15 for commands that require an action value.

**Response** = None (Just header and trailer)

Table 9-15 Remote general

RG Command ID	Meaning	Action Value	Notes
1 (0x01)	Stop All		Duplicates the equivalent front panel action
2 (0x02)	Reset All		Duplicates the equivalent front panel action
3 (0x03)	Remote Lock On		No parameters can be updated from the front panel "R Lock" displayed
4 (0x04)	Remote Lock Off		Cancel RG 3 command
5 (0x05)	Set Logic Statement <statement Number&gt; to True</statement 	<byte></byte>	Range is 1-100. Only does something if logic statement event "Computer Control" set. Otherwise, ignored.
6 (0x06)	Clear Logic Statement <statement Number&gt; to False.</statement 	<byte></byte>	Range is 1-100. Only does something if logic statement event "Computer Control" set. Otherwise, ignored.
7 (0x07)	Crystal Fail Inhibit On	<byte></byte>	Range is 0-6 (0 = All) "Crystal Fail" output always set to FALSE, even during crystal fail
8 (0x08)	Crystal Fail Inhibit Off	<byte></byte>	Range is 0-6 (0 = All) "Crystal Fail" output has normal meaning
9 (0x09)	Set date (Month, Day, Year) or (Day, Month, Year) Depending on General parameter 17 (Date Format).	<integer> <integer> <integer></integer></integer></integer>	Range as follows:Month = 1 to 12  Day = 1 to 31  Year = 2000 to 2099
10 (0x0a)	Set time (Hour, Minute, Second)	<integer> <integer> <integer></integer></integer></integer>	Range as follows Hour = 0 to 23  Minute = 0 to 59  Second = 0 to 59



Table 9-15 Remote general (continued)

RG Command ID	Meaning	Action Value	Notes
11	Zero Counter	<byte></byte>	Counter Range is 0-20
(0x0b)	<counter></counter>		0 = All
12	Zero Timer	<byte></byte>	Timer Range is 0-20
(0x0c)	<timer></timer>		0 = All
13 (0x0d)	Start Timer <timer></timer>	<byte></byte>	Timer Range is 1-20
14	Cancel Timer	<byte></byte>	Timer Range is 0-20
(0x0e)	<timer></timer>		0 = All
15 (0x0f)	Clock Hold On <material></material>	<byte></byte>	Stops timer in Pre-Deposit or Post-Deposit. Keeps in current state at current power setting.  Material Range 0-6 (0 = all Materials)
16	Clock Hold Off	<byte></byte>	Restarts timer in Pre-Deposit or Post-Deposit
(0x10)	<material></material>		Material Range 0-6 (0 = all Materials)
17 (0x11)	User message on <message #=""></message>	<byte></byte>	Message Range is 1-10
18 (0x12)	User message off <message #=""></message>	<byte></byte>	Message Range is 1-10
19	Soak Hold 1 on	<byte></byte>	Material Range is 0-6
(0x13)	<material></material>		(0 = all Materials)
20	Soak Hold 1 off	<byte></byte>	Material Range is 0-6
(0x14)	<material></material>		(0 = all Materials)
21	Soak Hold 2 on	<byte></byte>	Material Range is 0-6
(0x15)	<material></material>		(0 = all Materials)
22 (0x16)	Soak Hold 2 off <material></material>	,	
23 (0x17)	Switch Sensor Sensor to <crystal #=""></crystal>	<byte><byte></byte></byte>	Sensor Range = 1 - 6 Crystal Range = 0 to maximum allowed crystals for the requested Sensor. If Crystal # = 0, will switch to the "next" crystal. If the Sensor is not used in a Material currently running, the next crystal will be the next one in the sequence. If the Sensor is used in a Material that is running, the next crystal will be the next one from the XL Position parameters sequence. If a Sensor is used in a Material that is running, the value of "Crystal #" must be zero, otherwise, an error will occur.



Table 9-15 Remote general (continued)

RG Command ID	Meaning	Action Value	Notes	
24 (0x18)	Clear Failed Crystals X	<byte></byte>	Clears all failed crystals except the current crystal for the requested Sensor. X = Sensor (1-6)	
25 (0x19)			Reserved for future use.	
26 (0x1a)	Rotate head X	<byte></byte>	If the requested Sensor is a multi crystal sensor and the Material for that Sensor is in Ready, Stop or all active Materials are in Idle, the sensor head will rotate.  X = Sensor (1 - 6)	
27 (0x1b)	Default all Parameters		Sets all parameters except the communication parameters to default values.	
29 (0x1d)	Soak Hold Pre Con on <material></material>	<byte></byte>		
30 (0x1e)	Soak Hold Pre Con off <material></material>	<byte></byte>	Material Range is 0 - 6 (0 = All Materials)	
31 (0x1f)	Start Inhibit On		Disallows a Start command to be executed.	
32 (0x20	Start Inhibit Off		Allows a Start command to be executed.	
33 (0x21)	RateWatcher Sampling Inhibit On <material></material>	<byte></byte>	Will immediately cause the Deposit state to leave sampling and not return until turned off.	
34 (0x22)	RateWatcher Sampling Inhibit Off <material></material>	<byte></byte>	Allows the Deposit state to go into the RateWatcher algorithm.	
35 (0x23)	RateWatcher Sample Initiate On <material></material>	<byte></byte>	Allows the Deposit state to enter RateWatcher sampling	
36 (0x24)	RateWatcher Sample Initiate Off <material></material>	<byte></byte>	Turns RateWatcher sampling off.	
37 (0x25)	Clear Q and S counts for Sensor X	<byte></byte>	Clear Q and S counts for specified Sensor X	
38 (0x26)	Name Material <material><library Entry&gt;</library </material>	<byte><byte></byte></byte>	Give Material number <material> (1-6) the name corresponding to Material entry <library entry=""> (0-254). Library entries range from 0 (Ag) to 254 (ZrO<sub>2</sub>), with numbers corresponding to the alphabetical listing in the library. The density and Z-Ratio will be changed accordingly.</library></material>	



#### 9.4.32 Remote Material Action

**Command** = RL <Command ID> <Material Number> (<Action Value>)

Command ID = <Byte>.

**Material Number** = <Byte> 1-6

Action Value = <Byte> | <Integer> | <Float>

See Table 9-16 for commands that require an action value.

**Response** = None (Just header and trailer)

Table 9-16 Remote material

RL Command ID	Meaning	Action Value	Notes
0 (0x00)	Stop Material		
1 (0x01)	Zero Thickness		Cannot do from Stop
2 (0x02)	Start Deposit		Will always zero thickness on entry. This cannot be done from Ready, Idle, Stop, Crystal Switching or Crucible Switch. When there is no good crystal, this command will go to "Time Power" if previous state was Non-Deposit Hold, otherwise, is not allowed.
3 (0x03)	Go to Non-Deposit Control		This cannot be done from Ready, Stop, or Crucible Switch. When there is no good crystal, this command will go to "Non-Deposit Hold" if the previous state was Time Power, otherwise, is not allowed.
4 (0x04)	Go to Post-Deposit (Feed Ramp)		Cannot be done if in Crucible Switch
5 (0x05)	Continue Deposit		Go to Deposit, but don't zero thickness. This cannot be done from Ready, Idle, Stop, Crystal Switching or Crucible Switch. When there is no good crystal, this command will go to "Time Power" if the previous state was Non-Deposit Hold, otherwise, is not allowed.
6 (0x06)	Go to Manual.		(Source shutter does not change position) Cannot be done if in STOP, Non-Dep Hold or Crucible Switch, or there is not a good crystal.
7 (0x07)	Set Power Level	<float></float>	Range is 0-99.99. Only allowed if in Manual, Time Power, or Non-Deposit Hold State. If the value is greater than the Max Power or less than the Min Power, a value error is returned.
8 (0x08)	Open Source shutter		Only allowed if in Manual
9 (0x09)	Close Source shutter		Only allowed if in Manual



#### Table 9-16 Remote material (continued)

RL Command ID	Meaning	Action Value	Notes
10 (0x0a)	Set Averaged Rate	<float></float>	Range is 0-999.9. Only in Time power or Non Deposit Hold - the estimated rate used.
11 (0x0b)	Start		
12 (0x0c)	Reset Material		



#### 9.4.33 Cygnus 2 Communications Examples

#### 9.4.33.1 General Command Packet Format

<Length(low/high, 2 byte)><Message(command)><Checksum(1 byte Hex)>

#### 9.4.33.2 General Response Packet Format

<Length(low/high, 2 byte)><CCB(1 byte, no errors returns 00)><Timer(1 byte
binary)><Response Message(Command Response)><Checksum(1 byte Hex)>

#### 9.4.33.3 HELLO Command, ASCII name and version

Command Format: H < Command ID>

H1


Command H1: 0200480149


Response:

19000017064379676E757320322056657273696F6E20302E303600D2

#### Example: H1 command

HELLO Command, ASCII name and version







#### 9.4.33.4 Query Material Parameter, Z-Ratio (2), Material 1

Command Format: QM < Command ID> < Material Number>

QM2 1

Command QM2 1: 0400514D0201A1 Response: 070000F10648E1BA3E18

#### 9.4.33.5 Update Material Parameter, Control Loop (4), Material 1, PID (2)

Command Format: UM <Command ID> <Material Number> <Parameter Value>

UM4 1 2

Command UM4 1 2: 0800554D040102000000A9

Response: 0300000D0613

#### 9.4.33.6 Query Sensor Parameter, Shutter Output (1), Sensor 1

Command Format: QS < Command ID> < Sensor Number>

QS1 1

Command QS1 1: 040051530101A6

Response: 0700008706000000008D

#### 9.4.33.7 Update Sensor Parameter, Sensor Type (2), Sensor 1, CrystalTwo (1)

Command Format: US < Command ID> < Sensor Number> < Parameter Value>

US2 1 1

Command US2 1: 08005553020101000000AC

Response: 0300002F0635

#### 9.4.33.8 Query Source Parameter, Shutter Output (2), Source 1

Command Format: QC < Command ID> < Source Number>

QC2 1

Command QC2 1: 04005143020197

Response: 0700003F060000000045

#### 9.4.33.9 Update Source Parameter, Number of crucibles (3), Source 1, 4 crucibles (1)

Command Format: UC < Command ID > < Source Number > < Parameter Value >

UC3 1 1

Command UC3 1 1: 080055430301010000009D

Response: 03000054065A



#### 9.4.33.10 Query Material Name, Material 1

Command Format: QN <Material Number>

QN 1

Command QN 1: 0300514E01A0

Response: 0A0000470653494C5645520022

#### 9.4.33.11 Update Material Name, Material 1, "SILVER"

Command Format: UN <Material Number> <Material Name>

**UN 1 SILVER** 

Command UN 1 SILVER: 0A00554E0153494C5645520079

Response: 030000E806EE

#### 9.4.33.12 Query Input Name, Input 1

Command Format: QI < Input Number>

QI1

Command QI 1: 03005149019B

Response: 060000BB0650310042

#### 9.4.33.13 Update Input Name, Input 1, "P1"

Command Format: UI <Input Number> <Input Name>

UI 1 P1

Command: 060055490150310020

Response: 030000A306A9

#### 9.4.33.14 Query Output Name, Output 1

Command Format: QO <Output Number>

QO 1

Command Q0 1: 0300514F01A1

Response: 0B0000E206534855545445520017

#### 9.4.33.15 Update Output Name, Output 1, "SHUTTER"

Command Format: UO < Output Number > < Output Name >

**UO 1 SHUTTER** 

Command U0 1: 0B00554F015348555454455200D4

Response: 030000E306E9



#### 9.4.33.16 Query Output Type, Output 1

Command Format: QT <Output Number>

QT 1

Command QT 1: 0300515401A6

Response: 040000BF0600C5

#### 9.4.33.17 Update Output Type, Output 1, Normally Closed (1)

Command Format: UT <Output Number> <Output Type>

UT 11

Command UT 1 1: 040055540101AB

Response: 030000FA0600

#### 9.4.33.18 Query User Message, Message 1

Command Format: QV <User Message Number>

QV 1

Command QV 1: 0300515601A8

Response: 0A0000C80648454C4C4F210063

#### 9.4.33.19 Update User Message, Message 1, "HELLO!"

Command Format: UV < User Message Number > < User Message Name >

UV 1 HELLO!

Command UV 1 HELLO!: 0A0055560148454C4C4F210041

Response: 030000CD06D3

#### 9.4.33.20 Query Logic Statement, Statement 1

Command Format: QL <Statement Number>

QL 1

Command QL 1: 0300514C019E

Response: 090000B00605410120450365



#### 9.4.33.21 Update Logic statement, Statement 1, "IF External Input 1 THEN Start 1"

Command Format: UL <Statement Number> <Length of logic elements> <set of elements>


UL 1 IF EXTERNAL INPUT 1 THEN START 1


Command UL 1 IF EXTERNAL INPUT 1 THEN START 1: 0A00554C010641012045010358

Response: 03000075067B

#### Example: UL 1 IF EXTERNAL INPUT 1 THEN START 1 command

Update Logic statement, Statement 1, "IF External Input 1 THEN Start 1"







#### 9.4.33.22 Status Material, Thickness (4), Material 1

Command Format: SL < Command ID > < Material >

SL4 1

Command SL4 1: 0400534C0401A4
Response: 070000980689418C4236

#### 9.4.33.23 Status Sensor, Crystal Life (0), Sensor 1

Command Format: SS < Command ID> < Sensor>

SS0 1

Command SS0 1: 040053530001A7

Response: 040000C10600C7

#### 9.4.33.24 Remote General Action, Stop All

Command Format: RG < Command ID > (< Action Value >)

RG1

Command RG1: 03005247019A

Response: 030000D706DD

#### 9.4.33.25 Remote Material Action, Open Source Shutter (8)

Command Format: RL < Command ID> < Material Number> (< Action Value>)

**RL8 1** 

Command RL8 1: 0400524C0801A7

Response: 0300004B0651



#### 9.4.33.26 Example for Interpreting Float Responses

Command used: SS 6 1, Status Sensor, Z-Ratio, Sensor 1

**NOTE:** Data is shown in Hex format for convenience. Actual data transmission is

in binary. Commas have been inserted for clarity.


Sent to IC6: 04,00,53,53,06,01,AD

Response from IC6: 07,00,00,AA,06,1F,85,45,41,DA

Float portion of response from IC6 (low to high): 1F,85,45,41

Reverse the float response, so it is now high to low: 41,45,85,1F

Convert each byte to its binary equivalent (you can do this using a scientific calculator) to produce the 32 bit float response:



Rearrange the 32 bits making up the float response into packets of 1, 8, and 23 bits, representing the Sign, Exponent, and Mantissa, respectively:


Sign	Exponent	Mantissa
0	10000010	10001011000010100011111

Rewrite the current value in binary scientific notation.

The Sign "0" means that the sign of the decimal number is positive.

Using a scientific calculator, convert the Exponent value to decimal. In this case, the decimal value will be 130. Now, subtract 127 from 130 and you get 3, the actual exponent value (You must always subtract 127 from the exponent decimal value).

Insert the Mantissa to the right of the decimal point.





Rewrite each individual "1" in the value above in exponent form:

 $1.100010110000101000111111 \times 2^{3}$ 

= 
$$(2^{0} + 2^{-1} + 2^{-5} + 2^{-7} + 2^{-8} + 2^{-13} + 2^{-15} + 2^{-19} + 2^{-20} + 2^{-21} + 2^{-22} + 2^{-23}) \times 2^{3}$$

Distribute the  $2^3$  (Add the exponents, so for example,  $2^{-2} \times 2^3 = 2^1$  etc):

$$= 2^{3} + 2^{2} + 2^{-2} + 2^{-4} + 2^{-5} + 2^{-10} + 2^{-12} + 2^{-16} + 2^{-17} + 2^{-18} + 2^{-19} + 2^{-20}$$

Expand the exponents in their decimal form:

$$= 8 + 4 + 0.25 + 0.0625 + 0.03125 + 0.0009765625$$

- + 0.000003814697265625 + 0.0000019073486328125
- + 0.00000095367431640625

Compute the sum and round appropriately.

In this case, this is the Z-Ratio of sensor 1.

- = 12.34500026702880859375
- = 12.345



# Chapter 10 Maintenance and Calibration Procedures

## 10.1 Importance of Density, Tooling and Z-Ratio

The quartz crystal microbalance is capable of precisely measuring the mass added to the face of the oscillating quartz crystal sensor. Cygnus 2's knowledge of the density of this added material (specified in the density parameter in Material Set-Up) allows conversion of the mass information into thickness. In some instances, where highest accuracy is required, it is necessary to make a density calibration as outlined in section 10.2.

Because the flow of material from a deposition is not uniform, it is necessary to account for the different amount of material flow onto the sensor compared to the substrates. This factor is accounted for in the tooling parameter in Material Set-Up. The tooling factor can be experimentally established by following the guidelines in section 10.3 on page 10-2.

In Cygnus 2, if the Z-Ratio is not known it could be estimated from the procedures outlined in section 10.4 on page 10-3, or, typically, the Auto-Z function can be used to determine the Z-Ratio.

## 10.2 Determining Density

**NOTE:** The bulk density values retrieved from the Material Library are sufficiently accurate for most applications.

Follow the steps below to determine density value.

- Place a substrate (with proper masking for film thickness measurement) adjacent to the sensor, so that the same thickness will be accumulated on the crystal and substrate.
- **2** Set density to the bulk value of the film material or to an approximate value.
- **3** Set Z-Ratio to 1.000 and tooling to 100%.
- **4** Place a new crystal in the sensor and make a short deposition (1000-5000 Å) using manual control.
- **5** After deposition, remove the test substrate and measure the film thickness with either a multiple beam interferometer or a stylus-type profilometer.



**6** Determine the new density value with equation [1]:

Density(g/cm<sup>3</sup>) = 
$$D_1 \left(\frac{T_x}{T_m}\right)$$
 [1]

where:

 $D_1$  = Initial density setting

 $T_x$  = Thickness reading on Cygnus 2

T<sub>m</sub> = Measured thickness

7 A quick check of the calculated density may be made by programming Cygnus 2 with the new density value and observing that the displayed thickness is equal to the measured thickness, provided that Cygnus 2's thickness has not been zeroed between the test deposition and entering the calculated density.

**NOTE:** Slight adjustment of density may be necessary in order to achieve  $T_x = T_m$ .

## 10.3 Determining Tooling

- 1 Place a test substrate in the system's substrate holder.
- 2 Make a short deposition and determine actual thickness.
- 3 Calculate tooling from the relationship shown in equation [2]:

Tooling (%) = 
$$TF_i \left( \frac{T_m}{T_x} \right)$$
 [2]

where

T<sub>m</sub> = Actual thickness at substrate holder

T<sub>x</sub> = Thickness reading in Cygnus 2

TF<sub>i</sub> = Initial tooling factor

- **4** Round off percent tooling to the nearest 0.1%.
- When entering this new value for tooling into the program, T<sub>m</sub> will equal T<sub>x</sub> if calculations are done properly.

**NOTE:** It is recommended that a minimum of three separate evaporations be made when calibrating tooling. Variations in source distribution and other system factors will contribute to slight thickness variations. An average value tooling factor should be used for final calibrations.



## 10.4 Laboratory Determination of Z-Ratio

**NOTE:** On Cygnus 2, the Auto-Z function is available to automatically calculate the Z-Ratio. Especially when precise Z-Ratio values are significant, Auto-Z is recommended. See section 14.1.6 on page 14-9 for a description of Auto-Z theory.

A list of Z-values for materials commonly used is available in the Material Library. For other materials, Z can be calculated from the following formula:

$$Z = \left(\frac{d_{q}\mu_{q}}{d_{f}\mu_{f}}\right)^{\frac{1}{2}}$$
[3]

$$Z = 9.378 \times 10^{5} (d_{f} \mu_{f})^{-\frac{1}{2}}$$
 [4]

where:

 $d_f$  = density (g/cm<sup>3</sup>) of deposited film

 $\mu_f$  = shear modulus (dynes/cm2) of deposited film

 $d_q$  = density of quartz (crystal) (2.649 gm/cm<sup>3</sup>)

 $\mu_q$  = shear modulus of quartz (crystal) (3.32 x 10<sup>11</sup> dynes/cm<sup>2</sup>)

The densities and shear moduli of many materials can be found in a number of handbooks.

Laboratory results indicate that Z-values of materials in thin-film form are very close to the bulk values. However, for high stress producing materials, Z-values of thin films are slightly smaller than those of the bulk materials. For applications that require more precise calibration, the following direct method is suggested:

- **1** Establish the correct density value as described in section 10.2 on page 10-1.
- Install a new crystal and record its starting frequency F<sub>co</sub>. It will be necessary to send the SS 4 n command to get this information (refer to section 9.4.30, Status Sensor, on page 9-42).
- 3 Make a deposition on a test substrate such that the percent crystal life display will read approximately 50%, or near the end of crystal life for the particular material, whichever is smaller.
- **4** Stop the deposition and record the ending crystal frequency F<sub>c</sub> using the SS 4 n command.
- **5** Remove the test substrate and measure the film thickness with either a multiple beam interferometer or a stylus-type profilometer.



6 Using the density value from step 1 and the recorded values for F<sub>co</sub> and F<sub>c</sub>, adjust the Z-Ratio value in thickness equation [5] to bring the calculated thickness value into agreement with the actual thickness. If the calculated value of thickness is greater than the actual thickness, increase the Z-Ratio value. If the calculated value of thickness is less than the actual thickness, decrease the Z-Ratio value.

$$T_{f} = \frac{Z_{q} \times 10^{4}}{2\pi zp} \left\{ \left(\frac{1}{F_{co}}\right) A Tan\left(z Tan\left(\frac{\pi F_{co}}{F_{q}}\right)\right) - \left(\frac{1}{F_{c}}\right) A Tan\left(z Tan\left(\frac{\pi F_{c}}{F_{q}}\right)\right) \right\}$$
 [5]

where:

 $T_f$  = thickness of deposited film (kÅ)

F<sub>co</sub> = starting frequency of the sensor crystal (Hz)

 $F_c$  = Final frequency of the sensor crystal (Hz)

 $F_q$  = Nominal blank frequency = 6045000 (Hz)

z = Z-Ratio of deposited film material

 $Z_{\rm q}$  = Specific acoustic impedance of quartz = 8765000 (MKS units)

p = density of deposited film (g/cc)

For multiple Material deposition (for example, two Materials), the Z-value used for the second Material is determined by the relative thickness of the two Materials. For most applications the following three rules will provide reasonable accuracies:

- If the thickness of Material 1 is large compared to Material 2, use material 1
   Z-value for both Materials.
- If the thickness of Material 1 is thin compared to Material 2, use material 2 Z-value for both Materials.
- If the thickness of both Materials is similar, use a value for Z-Ratio which is the weighted average of the two Z values for deposition of Material 2 and subsequent Materials.




#### 10.5 Source Maintenance

The Source Maintenance page allows toggling Source and Sensor shutters and rotating the crucible indexer associated with a selected Material. Source power may be manually adjusted using the hand-held controller.

Cygnus 2 must be in Ready or Idle mode to Enable Source Maintenance and it must be Disabled to exit back to normal operation. If in Manual mode, Stop must be activated to Enable Source Maintenance.

Figure 10-1 Source maintenance page





#### 10.5.1 Source Maintenance Parameters

**NOTE:** Remote Comm is not allowed while in Source Maintenance.

**SOURCE MAINTENANCE** ..... Enabled/Disabled

Cygnus 2 must be in Ready to Enable and must be Disabled to return to normal operation. Default is Disabled.

MATERIAL NUMBER ..... 1 to 6

While in Maint Stop, select the Material associated with the Source or Sensor to be checked. Material cannot be changed while in Manual.

#### 10.5.1.1 Crucible Rotation

If Cygnus 2 has been configured for a multi-position crucible indexer, pressing the F1 key will advance it to the next position. Setting the "Switch to Crucible" parameter to one of the positions before pressing F1 will activate the programmed crucible indexer outputs to rotate to the specified position.

The F1 key is grayed out for a single position crucible to indicate it is not active.

#### 10.5.1.2 Toggle Sensor and Source Shutter

Press the F2 key to toggle Sensor shutter associated with this Material.

Press the F3 key to toggle the Source shutter for this Material's Source.


#### 10.5.1.3 Start/Stop Manual Power

Press the F4 key to start Manual mode. Once in manual mode, use the optional hand-held controller to increase or decrease the power.



## 10.6 System Status

Figure 10-2 System status display



The System Status display shows installed option boards and firmware versions. There are no user parameters.



# Chapter 11 Counters and Timers

### 11.1 Introduction

Cygnus 2 has twenty counters and twenty timers. These counters and timers enable you to customize logic statements. Timers and counters are "up/increasing" value variables. You can increment a counter or start a timer on any event via a logic statement. These counters and timers can then be checked via other logic statements to initiate one or more actions at a given count or when an elapsed amount of time has passed. On the counter/timer screen, see Figure 11-1, you can monitor all the counters and timers and by positioning the cursor on the counter or timer number, manually zero a timer/counter (F1) or start timer (F2) or cancel a timer (F3) using the function keys.

Figure 11-1 Counter/Timer screen

	Coi	unter	s		Ti	ners	
1	000	11	000	1	00:00.0	11	00:00.0
2	000	12	000	2	00:00.0	12	00:00.0
3	000	13	000	3	00:00.0	13	00:00.0
4	000	14	000	4	00:00.0	14	00:00.0
5	000	15	000	5	00:00.0	15	00:00.0
6	000	16	000	6	00:00.0	16	00:00.0
7	000	17	000	7	00:00.0	17	00:00.0
8	000	18	000	8	00:00.0	18	00:00.0
9	000	19	000	9	00:00.0	19	00:00.0
10	000	20	000	10	00:00.0	20	00:00.0
unt	er/Ti	mer					
	o Timer/		Start		Cance 1		
	ounter		Timer		Timer		



## Chapter 12 USB Storage

## 12.1 File Handling (USB)

File handling is achieved via a USB port. Three types of files are used, configuration files which contain all user programmed parameters, screen capture files and data log files. Configuration files can be written to and retrieved from the USB port storage device. Data log files and bitmap files of screen captures can only be written to the USB port storage device. To prevent loss of data, no more than 500 data log files should be written to the USB device. Cygnus 2 will only display the first 120 files (15 per page) and a message "More Files on the USB". All files will be displayed on a computer.

The USB port is not set up for any other use. USB file handling allows for only eight characters in a file name with an optional three-character extension.

#### 12.1.1 USB Storage Devices

The following USB 2.0 storage devices have been tested for use with Cygnus 2:

- Memorex<sup>®</sup> TravelDrive 512 MB Flash Drive
- SanDisk® SDCZ2-1024-A10 1 GB Cruzer Mini Flash Drive
- Lexar® 1 GB Sport Flash Drive
- Lexar 4 GB Lightning Flash Drive
- Kingston® 32 GB DataTraveler 150 Flash Drive

**NOTE:** The USB storage device is to be plugged directly into the Cygnus 2 front panel USB port. Use of USB extension cables is **not** supported.

## 12.2 Directory Structure

All files will be written to and read from pre-defined directories. Three directories will be defined for the three types of files written by Cygnus 2.

- CYG2conf will hold configuration files
- CYG2scrn will hold screen capture files
- CYG2dlog will hold data log files


If the directories don't exist on the storage device attached to the USB port, Cygnus 2 will create them at the first attempt to access the directory.



## 12.3 Configuration Files

With all Materials in the READY or STOP state, the configuration of Cygnus 2 may be sent to a storage device attached to the USB port. Configuration files will be written with the default name CYGNUS2.ISC. The configuration file can be named within the eight-character limitation that exists in the USB file handling firmware. File names cannot contain the space character. Cygnus 2 will use the .ISC extension to identify configuration files. Cygnus 2 will ignore or reject IC/5 IC6, and Cygnus.ISC configuration files—these files are not compatible with Cygnus 2.

Figure 12-1 Configuration files



**NOTE:** All Materials must be in Stop, READY or Idle mode to save a configuration file.



### 12.4 Data Logs


**NOTE:** To prevent loss of data, do not allow the number of files on the USB storage device to exceed 500.

Data log files will be sent to the USB port storage device when the USB Datalog Format parameter located on the datalog page of the USB STORAGE screen is set to either Page or Comma by using the TOGL key. The error message "USB Disk Error" appears if datalogging is turned on and a USB flash drive is not present.

As the Materials create the datalog file, they will be sent to the CYG2dlog directory on the storage device attached to the USB port. The files will be named DDMMYYC#.IDL or MMDDYYC#.IDL depending on the date format setting. DD = day of month, MM = month, YY = year, C# represents the Material# where # is from 1 to 6. If a file with the same name exists, the new data log information will be appended to the existing file. Cygnus 2 will use the .IDL extension to identify Datalog files. See Figure 12-2.

See section 3.5.9, Datalog, on page 3-35 for the details of the data log data.

Figure 12-2 Datalog files



**USB DATALOG FORMAT** . . . . . . Logoff (0), Page (1), Comma (2)

The LogOff setting turns off datalogging, Use the TOGL key to enable "Page" or "Comma" delimited datalogging or disable it with the "Logoff" setting. Default setting is Logoff (0).




## 12.5 Screen Captures

A BMP file of the screen can be sent to the USB port storage device. Pressing the Print key will send a BMP file of the screen to the CYG2scrn directory on the storage device attached to the USB port. The Screen captures will be named as either DDMMYYxx.BMP or MMDDYYxx.BMP depending on the date format setting. DD = day of month, MM = month, YY = year, xx is a number that increments from 0 to 99, resetting to 0 every day. Cygnus 2 will use the .BMP extension to identify screen capture files. The +++ indicates that additional files exist on the USB device beyond those displayed. Use the Up/Down arrows keys to navigate.

Individual screen shots can be deleted by cursoring to the specific file and selecting the F3 function key.

Figure 12-3 Screen capture files





# Chapter 13 Troubleshooting, Status and Error Messages

## 13.1 Status Messages

Some Cygnus 2 status messages will have designators to indicate the Material, Source or Sensor the status refers. Table 13-1 indicates designators and to what they refer. If there is a message that has multiple occurrences, it will display on one line with multiple designators after it.

There are a few status messages that have a designated area in the status message area. These messages are noted in Table 13-1.

Table 13-1 Status messages

Status Message	Set	Cleared	Screen	Remote Comm. Encode
Crystal Fail XX	One or more of the Sensors that are called out in currently active Materials fails to measure a crystal.  X = Sensor	When all Sensors in use are good. When any Sensor in use is good the Sensor number clears from the numeric list.	All Designated area	0x8000,0000 0000,0000
Max Power XX	Whenever the Source power reaches the maximum power programmed for an active Material. X = Material number	Whenever the Source power is reduced from the maximum power for an active Material.	All Note: This message will display in the cause of stop area whenever it is TRUE. Designated area	0x4000,0000 0000,0000
Test	The general parameter Test has been set to Yes	The general parameter Test has been set to No	All. Designated area	0x2000,0000 0000,0000
A TEST	The general parameter Advanced Test has been set to yes.	The general parameter Advanced Test has been set to No.	All. Designated area	0x1000,0000 0000,0000
R Lock	A command was received via remote communications to lock Cygnus 2. NOTE: R Lock supersedes L Lock)	A command was received via remote communications to unlock Cygnus 2.	All Designated area	0x0800,0000 0000,0000
L Lock	A lock code has been programmed via the keyboard and the lock has been set.  NOTE: R Lock supersedes L Lock)	The lock code has been entered via the keyboard to unlock Cygnus 2.	All Designated area	0x0400,0000 0000,0000



Table 13-1 Status messages (continued)

Status Message	Set	Cleared	Screen	Remote Comm. Encode
Min Power XX	While in a rate control state, whenever the Source power reaches the programmed minimum power. This message doesn't appear if the Minimum power is programmed for 0.0%. X = Material	When the Source power is greater then the programmed minimum power or when Cygnus 2 leaves rate control.	All	0x0200,0000 0000,0000
Crystal Switch(ing) XX	A multi crystal sensor is switching to a new crystal. X = Sensor	The Sensor switching has reached its next position. When replaced with Switcher Error message	All	0x0100,0000 0000,0000
Crystal Sw(itcher) Fail XX	A crystal position was not reached in the time allotted for a crystal switch. X = Sensor	The Sensor switching has reached its next position. When replaced with switcher error message	All	0x0080,0000 0000,0000
Carousel Open XX	The Crystal12 carousel is not detected as in place. X = Sensor	When the carousel is detected or when the Sensor type is set to something other than Crystal12.	All	0x0040,0000 0000,0000
Control Delay XX	When the Delay option is set to Control and a Material enters the control delay. X = Material	The control delay is complete.	All	0x0020,0000 0000,0000
RateWatcher Delay XX	When RateWatcher is turned on, the active state is	When RateWatcher is inactive or as the RateWatcher state changes.	All	0x0008,0000 0000,0000
RateWatcher Hold XX	displayed. Only one state per Material can be active at a time.			0x0004,0000 0000,0000
RateWatcherSample XX	X= Material			0x0002,0000 0000,0000
Soak Hold Pre Con YY	A Cooled label and this is a fi	The Cook Held and the co	All	0x0001,0000 0000,0000
Soak Hold 1 YY	A Soak Hold condition is active  Y = Material	The Soak Hold condition is no longer active		0x0000,8000 0000,0000
Soak Hold 2 YY				0x0000,4000 0000,0000



Table 13-1 Status messages (continued)

Status Message	Set	Cleared	Screen	Remote Comm. Encode
Abbr(eviated) Average XX	During a rate control state, a crystal failure occurred after more then one minute but before the number of minutes specified in the parameter Time Power Averaging Time. The time to average the rate and power is less then requested.  X = Material	When a new Material is started. Stop/Reset	All	0x0000,2000 0000,0000
No or Neg. Average X X	Then entering time power of non deposit control and there is not enough data to calculate and average rate or power.  X = Material	As the Material is unloaded	All	0x0000,1000 0000,0000
Time Pwr (Power) Complete X	Time Power was active when the Material completed. X = Material	Another Material overloads the Material that completed in Time Power	All	0x0000,0800 0000,0000
Clock Hold	A clock hold has been set via a Digital Input, Logic Action or remote communication command.	A clock hold has been cleared via a Digital Input, Logic Action or remote communication command.	All	0x0000,0400 0000,0000
Recoder Conflict	A DAC output is set as a Recorder output on two or more loaded Materials or Sensors.	Conflict has been removed.	All	0x0000,0008 0000,0000
Unable to Auto-Z X X	An active Sensor is unable to Auto-Z. X = Sensor	A Sensor is no longer active or is able to Auto-Z. Sensor Parameter Auto-Z is set to No.	All	0x0000,0004 0000,0000
DAC Error X	DAC monitoring has detected an error in a DAC used for a recorder. X = DAC	On Reset	All	0x0000,0002 0000,0000
Testing XIU X	When XIU test begun. X = Sensor Number	When XIU test finished	Sensor Info	0x0000,0001 0000,0000



## 13.2 User Messages

Table 13-2 messages are a subgroup of status messages. The user defines these messages. They are displayed and cleared via logic actions. The messages will display in the same screen area as other status messages.

Table 13-2 User messages

Status Message	Set	Cleared	Screen	Remote Comm. Encode
User Message 1	Logic event "Message On 1"	Logic event "Message Off 1"	All	0x0000,0000,0000,0200
User Message 2	Logic event "Message On 2"	Logic event "Message Off 2"	All	0x0000,0000,0000,0100
User Message 3	Logic event "Message On 3"	Logic event "Message Off 3"	All	0x0000,0000,0000,0080
User Message 4	Logic event "Message On 4"	Logic event "Message Off 4"	All	0x0000,0000,0000,0040
User Message 5	Logic event "Message On 5"	Logic event "Message Off 5"	All	0x0000,0000,0000,0020
User Message 6	Logic event "Message On 6"	Logic event "Message Off 6"	All	0x0000,0000,0000,0010
User Message 7	Logic event "Message On 7"	Logic event "Message Off 7"	All	0x0000,0000,0000,0008
User Message 8	Logic event "Message On 8"	Logic event "Message Off 8"	All	0x0000,0000,0000,0004
User Message 9	Logic event "Message On 9"	Logic event "Message Off 9"	All	0x0000,0000,0000,0002
User Message 10	Logic event "Message On 10"	Logic event "Message Off 10"	All	0x0000,0000,0000,0001



# 13.3 STOP messages

When a Cygnus 2 Material goes into STOP, a cause of stop message appears on the line above STOP if the "Show Graph" Operate screen is selected. Some of these messages will have designators to indicate the Material, Source or Sensor that caused the Stop. Table 13-3 indicates which messages have designators and what the designator indicates.

Table 13-3 Stop messages

Cause of STOP Message	Set	Clear	Screen	Remote Comm. Encodes	
Max Power X	Maximum power was reached and held there for more then 5 seconds and the Material parameter Max Power Option is set to Stop on Max Power.  X = Material	A RESET command received from the keyboard, digital input, remote communications or a Logic action. A Start, if the condition causing the stop has been cleared and the Material layer can resume.		1	
Crystal Fail X	There was a crystal failure and the Material parameter Failure Action is set to stop on fail. X = Sensor.		meter Failure		2
Hand Controller	STOP command was received from the handheld controller.			3	
Front Panel	Keyboard STOP key was pressed.		All -	4	
Communication	A STOP command was received from remote communications.			5	
Crucible Fail X	Cygnus 2 failed to detect a good crucible in the time allowed. X = Source			6	
Switcher Fail X	A crystal switch failed. X = Sensor			7	
Logic Eqn #N	A STOP command was received from logic statement number #.			8	
Power Loss	Cygnus 2 lost power.			10	
Shutter Fail X	The desired Rate Accuracy has not been achieved in the allotted time in Shutter Delay. X = Material.			13	
DAC Failure	Monitoring of the DAC output via an ADC determined that the output voltage is incorrect.			15	



## 13.4 Transient Messages

Transient messages, see Table 13-4, are displayed as the condition happens. The messages are removed from the screen on any key press or if another transient message appears. Only one transient message will be displayed at a time. These messages will appear on all screens. A single line is assigned in the message box.

Table 13-4 Transient messages

Transient Message	Set	Clear	Screen	Remote Comm. Encodes							
Locks Cleared	Local Lock, Remote lock cleared on power up.	The message is removed from the screen on any key press or if another transient message	removed from	removed from	removed from	removed from	removed from	removed from	removed from	All	1
Already Switching	Crystal is already switching when a request to switch the crystal is received.			2							
Parameter Default	All parameters were set to their default values on power- up.				4						
Process Variables Default	All process variables were set to their default values on power- up. Process variables include current rates, thicknesses, Materials, crystals, states and other information needed to continue a process after a power loss.			5							
Manual Not Allowed	Cannot enter manual state while in idle, stop or suspend states, or while crystal failed.			6							
No Good Xtal to switch	There are no good crystals left in the crystal list. Only when trying to switch while the Sensor is in use on an active Material.			8							
No Switch Output	No switch output defined for a crystal switch.			9							
No Switch Single	Cannot switch a single sensor.			10							



Table 13-4 Transient messages (continued)

Transient Message	Set	Clear	Screen	Remote Comm. Encodes
Datalog Failure	Cygnus 2 is sending the Datalog information faster then the receiving device can accept the data. The data is lost.	The message is removed from the screen on any key press or if another transient message appears	All	11
Ethernet In Use	Ethernet port is active and the Ethernet parameters can't be changed. The command sent to the Ethernet card did not go through or the Ethernet card did not send a valid message indicating the update of values was completed.		General	12
No Rotate: CrystalTwo	Cannot rotate a CrystalTwo.		Sensor Info	13
No Rotate: Layer Running	Cannot rotate a Sensor while a Material is running.	_	Sensor Info	14
Invalid Equation	An attempt was made to save an invalid logic statement. Logic statements must have connectors and any required numeric before exiting Logic editing.		Logic edit	15
Power Not Zero	A Source maintenance crucible switch was requested when the Source power is not zero.		Maintenance	16
RS232 Test Failed	RS-232 loop back test failed.		General/Comm	17
RS232 Test Passed	RS-232 loop back test passed.		General/Comm	18
XIU Test Failed	XIU test failed		Sensor Info/Type	19
XIU Test Passed	XIU test passed.		Sensor Info/Type	20
No XIU Test: Switching	Cannot test an XIU while a crystal switch is in process.		Maintenance	21
Edit In Process	When an edit is process and the menu key is pressed.		All	22
USB Disk Error	Fault Conditions: No Disk, Folder/File Read Only, Firmware Invalid, Firmware No Upgrade, Exceeded max. file count		Storage	23
USB error: Disk Full	Disk is Full		Storage	24



Table 13-4 Transient messages (continued)

Transient Message	Set	Clear	Screen	Remote Comm. Encodes
USB (File Check Sum) Error: Data Corrupt		The message is removed from	Storage	25
USB error: Bad Conf. File		the screen on any key press or if another	Storage	26
USB DataLog Fast Out Error		transient message appears		27
USB Error (generic)	USB Interface system error		All	28
(USB: Conf. file:) Structure Version Change	Structure version updated because of the new configuration.		Storage	29
(USB:) Parameter Value Changed	Parameter value has been adjusted during the Range Check verification procedure.		Storage	30
USB Busy	Any key is pressed while the USB is busy.		All	31
(USB:) No Such File (Available)	Attempt to access non- existing or folder non-specific file.		Storage	32
(USB: Too many files) Archive Old Files	Too many files in a directory		All	33
Logic Edit In Progress	Key press (STOP,RESET,START, MENU) while in logic edit mode:		Logic Edit	53
No Paren on Empty Term	Parentheses are not allowed on an empty term.		Logic Edit	54
No Left Paren on Last Term.	Cannot insert Left (opening) parenthesis on the last term.		Logic Edit	55
Select an Event to Edit	Attempt to edit a non-event assigned label.		Logic Edit	56
Select an Action to Edit	Attempt to edit a non-action assigned label.		Logic Edit	57
Select an Event to Delete	Attempt to delete a non-event assigned label.		Logic Edit	58
Select an Action to Delete	Attempt to delete a non-action assigned label.		Logic Edit	59
Max Terms: Cannot Insert	An attempt was made to enter an equation with more then the allowed event or action terms.		Logic Edit	60
Cannot Negate Empty Term	Attempt to negate an empty term.		Logic Edit	61
Meas. Board Comm Error	Bad communications with the measurement card.		All	62
No Switch: No XIU	No XIU attached, cannot do a switch.		All	63



Table 13-4 Transient messages (continued)

Transient Message	Set	Clear	Screen	Remote Comm. Encodes
In Crucible Switch	An attempt was made to navigate or change a parameter in the Source Maintenance screen while a crucible switch was in process.	The message is removed from the screen on any key press or if another transient message appears	Source Maintenance	* Not available
Maintenance Enabled	An attempt was made to leave a Maintenance screen while Source Maintenance was enabled		Source Maintenance	Not available from Remote Comm
Crucible Switch Fail	Crucible switch fail while in Source Maintenance.		Source Maintenance	Not available from Remote Comm
* Remote communications are not permitted while in Source Maintenance.				
Power Loss	Post Power cycle		Operate	69



## 13.5 Input Error Messages

Keyboard Input Error Messages come up on the entry of invalid parameters. These messages will appear on the transient error message line in the message box. The font color of the parameter value being updated will change to a different color to denote an input error has been made. They will clear when the clear key is pressed. The original stored value will then be re-displayed. See Table 13-5.

Table 13-5 Input error messages

Input Error Message	Set	Cleared	Screen
Value Too High	The value entered is larger than the maximum value allowed.	Each input error message is taken down by pressing the clear key.	Any Parameter edit
Value Too Low	The value entered is lower than the minimum value allowed.		Any Parameter edit
Duplicate Source	Can use each Source number only once for thickness sum.		General
Invalid Mask	An attempt was made to enter an incorrect Ethernet net mask.		General
Incorrect Time	An attempt was made to enter more then 59 seconds or 99 minutes into a time parameter.		Material
Ramp 1 > Ramp 2	Invalid Material parameter 'Ramp', values were entered. Start Ramp 1 thickness value must be less then Start Ramp 2 value when the Start Ramp 2 value is non-zero.		Material
Ramp 2 < Ramp 1	Invalid Material parameter 'Ramp', values were entered. Start Ramp 2 thickness value must be greater then Start Ramp 1 value.		Material
DAC Used Material ## Or DAC Used Sensor ##	The DAC number has been previously defined as a recorder output in the Material or the Sensor set up.		Source parameter
DAC Used Source XX	The DAC number has been previously defined as a Source DAC output in one of the Source set ups		Material, Sensor and Source parameter
Input in use	An attempt was made to enter an input that is already reserved for use in Source setup or one of the logic statements.		Source parameter
Output in use	An attempt was made to enter an output that is already reserved for use. The output is already reserved for use in Sensor or Source set up or in one of the logic statements.		Sensor, Source parameter and Logic Edit
Invalid Lock Code	An incorrect lock code was used to attempt to unlock Cygnus 2.		Menu



Table 13-5 Input error messages (continued)

Input Error Message	Set	Cleared	Screen
	An attempt was made to use an Output that is programmed in Logic Statement #.	Each input error message is	Source Sensor General
•	An attempt was made in Source Maintenance to enable a Material that is running.	taken down by pressing the clear key.	Source Maintenance
Material(s) Running	An attempt was made to save a Config file while a Material is running.		USB Storage

## 13.6 Troubleshooting Guide

If Cygnus 2 fails to work, or appears to have diminished performance, the following Symptom/Cause/Remedy charts may be helpful.



#### **WARNING - Risk Of Electric Shock**

There are no user serviceable components within the Cygnus 2 case.

Potentially lethal voltages are present when the line cord, Inputs or Outputs are connected.

Refer all maintenance to qualified personnel.

This Cygnus 2 contains delicate circuitry which is susceptible to transients. Disconnect the line cord whenever making any interface connections. Refer all maintenance to qualified personnel.



## 13.6.1 Troubleshooting Cygnus 2

Table 13-6 Troubleshooting Cygnus 2

SYMPTOM	CAUSE	REMEDY
Power on LED not illuminated	a. Blown fuse/circuit breaker tripped	a.Have qualified personnel replace fuse/reset circuit breaker
	b. Electrical cord unplugged from wall or back of Cygnus 2	b. Reconnect power cord
	c. Incorrect line voltage	c. Have qualified personnel verify line voltage, verify Cygnus 2 is configured for the correct voltage
2. Cygnus 2 "locks" up	a. Cover or back panels not attached to Cygnus 2	a. Ensure all covers and panels are in place and securely fastened
	b. High electrical noise environment	b. Reroute cables to reduce noise pickup (1 ft [30 cm] away from high power conducting lines makes a sizable reduction in the amount of noise entering Cygnus 2), keep all ground wires short with large surface area to minimize ground impedance (solid copper strap with 5 to 1 length to width ratio is recommended)
	c. Poor grounds or poor grounding practice	c. Verify proper earth ground, use appropriate ground strap, (solid copper strap with 5 to 1 length to width ratio is recommended), eliminate ground loops by establishing the correct system grounding, verify proper Cygnus 2 grounding
3. Cygnus 2 does not retain parameters on power down (loss of parameters on power up)	a. Lithium battery is dead	a. Lithium battery has a normal life expectancy of seven years, contact INFICON service department
	b. Power supply or Processor board problem	b. Contact INFICON service department



Table 13-6 Troubleshooting Cygnus 2 (continued)

SYMPTOM	CAUSE	REMEDY
4. Some keys on front panel function while others do not	a. Faulty keypad or faulty keypad ribbon cable	a. Contact INFICON service department
5. All keys on the front panel fail to function	a. Cygnus 2 is "locked" up	a. Turn power OFF and then ON using the power switch on the back of Cygnus 2, see item 2 above
6. Control voltage output does not function properly	a. DAC board damaged from applying voltage to the control voltage output	a. Ensure cable connection to the DAC board does not have a potential across the contacts, contact INFICON service department
	b. Reversed polarity of control voltage relative to that accepted by the Source power supply	b. Verify Source output polarity of the DAC and the required input polarity of the Source power supply, refer to the instruction manual to reconfigure Cygnus 2 if necessary
	c. Improper control cable fabrication	c.Check for correct cable wiring in the appropriate section of the manual
7. LCD display dull or blank	a. LCD or LCD Interface board problem.	a. Contact INFICON service department
	b. LCD Dimmer Time not 0 and expired, see section 6.9	b. Press cursor key to activate display
8. Poor rate control	a. Control loop parameters improperly selected	a. Refer to the instruction manual section on tuning control loop parameters
	b. Electron beam sweep frequency "beating" with the Cygnus 2's measurement frequency	b. Adjust the sweep frequency so it is not a multiple of the Cygnus 2's measurement frequency



Table 13-6 Troubleshooting Cygnus 2 (continued)

SYMPTOM	CAUSE	REMEDY
9 Crystal fail message is always on	a. XIU/oscillator not connected	a. Verify proper sensor/oscillator connections. See items c, d, e, f, g, h below.
	b. XIU/oscillator malfunctioning	b. Use Test XIU diagnostic function to determine if cause is Cygnus 2 / XIU / XIU cables or if cause is Feedthrough / Sensor / Crystal. If available, insert a known working XIU/oscillator in place of suspect one; if XIU/oscillator is confirmed bad, contact INFICON service department
	c. Defective cable from feedthrough to XIU/oscillator or from Cygnus 2 to XIU/oscillator	c. Use an ohm meter or DVM to check electrical continuity or isolation as appropriate
	d. Poor electrical contact in the transducer, feedthroughs, or in-vacuum cable	d. Use an ohm meter or DVM to check electrical continuity or isolation as appropriate
	e. Failed crystal/no crystal	e. Replace crystal/insert crystal
	f. Two crystals placed into the crystal holder	f. Remove one of the crystals
	g. Frequency of crystal out of range	g. Verify that the crystal frequency is within the required range, use INFICON crystals.
	h. S & Q values exceed programmed values	h. Clear S & Q via Remote Comm or Function Key F3 on Sensor Information page, see



#### 13.6.2 Troubleshooting Transducers/Sensors

NOTE: Many sensor head problems may be diagnosed with a DVM (Digital Volt Meter). Disconnect the short oscillator cable from the feedthrough and measure the resistance from the center pin to ground. If the reading is less than 1-2 megohms, the source of the leakage should be found and corrected. Likewise, with the vacuum system open check for center conductor continuity, a reading of more than 1 ohm from the feedthrough to the transducer contact indicates a problem. Cleaning contacts or replacing the in-vacuum cable may be required.

A somewhat more thorough diagnosis may be performed with the optional Crystal Sensor Emulator, 760-601-G1. See section 13.8 on page 13-26 for a discussion of its use and diagnostic capabilities.

**NOTE:** A more detailed troubleshooting guide is shipped with the sensor. Refer to that manual for more detailed information in some cases.

Table 13-7 Troubleshooting transducers/sensors

SYMPTOM	CAUSE	REMEDY
Large jumps of thickness reading during deposition	a. Stress causes film to peel from crystal surface	a. Replace crystal or use Alloy crystal; consult factory
	b. Particulate or "spatter" from molten source striking crystal	b. Thermally condition the source thoroughly before deposition, use a shutter to protect the crystal during source conditioning
	c. Scratches or foreign particles on the crystal holder seating surface (improper crystal seating)	c. Clean and polish the crystal seating surface on the crystal holder; refer to appropriate sensor manual
	d. Small pieces of material fell on crystal (for crystal facing up sputtering situation)	d. Check the crystal surface and blow it off with clean air
	e. Small pieces of magnetic material being attracted by the sensor magnet and contacting the crystal (sputtering sensor head)	e. Check the sensor cover's aperture and remove any foreign material that may be restricting full crystal coverage; refer to appropriate sensor manual



Table 13-7 Troubleshooting transducers/sensors (continued)

SYMPTOM	CAUSE	REMEDY
2. Crystal ceases to oscillate during deposition before it reaches the end its normal life	a. Crystal struck by particulate or spatter from molten source	a. Thermally condition the source thoroughly before deposition, use a shutter to protect the crystal during source conditioning
	b. Material on crystal holder partially masking crystal cover aperture	b. Clean crystal holder; refer to appropriate sensor manual
	c. Existence of electrical short or open condition	c.Using an ohm meter or DVM, check for electrical continuity in the sensor cable, connector, contact springs, connecting wire inside sensor, and feedthroughs
	d. Check for thermally induced electrical short or open condition	d. See C above
NOTE: Crystal life is highly de source, location, material, and	ependent on process condition dresidual gas composition.	s of rate, power radiated from
3. Crystal does not oscillate or oscillates intermittently (both in vacuum and in air)	a. Intermittent or poor electrical contact (contacts oxidized)	a. Use an ohm meter or DVM to check electrical continuity, replace Ceramic Retainer
	b. Leaf springs have lost retentivity (ceramic retainer, center insulator)	b. Bend leaves to approx. 45°; refer to appropriate sensor manual
	c. RF interference from sputtering power supply	c. Verify earth ground, use ground strap adequate for RF ground, (solid copper strap with 5 to 1 length to width ratio is recommended), change location of Cygnus 2 and oscillator cabling away from RF power lines, connect Cygnus 2 to a different power line
	d. Cables/oscillator not connected, or connected to wrong sensor input	d. Verify proper connections, and inputs relative to programmed sensor parameter



Table 13-7 Troubleshooting transducers/sensors (continued)

SYMPTOM	CAUSE	REMEDY
Crystal oscillates in vacuum but stops oscillation after open to air	a. Crystal was near the end of its life; opening to air causes film oxidation which increases film stress	a. Replace crystal
	b. Excessive moisture accumulates on the crystal	b. Turn off cooling water to sensor prior to venting, flow warm water through sensor while chamber is open
5. Thermal instability: large changes in thickness reading during source warm-up (usually causes thickness reading to decrease) and after the termination of deposition (usually causes thickness reading to increase)	a. Inadequate cooling water/cooling water temperature too high	a. Check cooling water flow rate, be certain that cooling water temperature is less than 30 °C; refer to appropriate sensor manual
	b. Excessive heat input to the crystal	b. If heat is due to radiation from the evaporation source, move sensor further away from source and use sputtering crystals for better thermal stability; install radiation shield
	c. Crystal not seated properly in holder	c. Clean or polish the crystal seating surface on the crystal holder; refer to appropriate sensor manual
	d. Crystal heating caused by high energy electron flux (often found in RF sputtering)	d. Use a sputtering sensor head
	e. Poor thermal transfer from water tube to body (XtalSix sensor)	e. Use a new water tube whenever the clamping assembly has been removed from the body; if a new water tube is not available, use a single layer of aluminum foil between the cooling tube and sensor body, if your process allows
	f. Poor thermal transfer (Bakeable)	f. Use Al or Au foil washer between crystal holder and sensor body



Table 13-7 Troubleshooting transducers/sensors (continued)

SYMPTOM	CAUSE	REMEDY
6. Poor thickness reproducibility	a. Variable source flux distribution	a. Move sensor to a more central location to reliably sample evaporant, ensure constant relative pool height of melt, avoid tunneling into the melt
	b. Sweep, dither, or position where the electron beam strikes the melt has been changed since the last deposition	b. Maintain consistent source distribution by maintaining consistent sweep frequencies, sweep amplitude and electron beam position settings
	c. Material does not adhere to the crystal	c. Make certain the crystal surface is clean; avoid touching crystal with fingers, make use of an intermediate adhesion layer
	d. Cyclic change in rate	d. Make certain source's sweep frequency is not "beating" with the Cygnus 2's measurement frequency
7. Large drift in thickness (greater than 200 Å for a density of 5.00 g/cc) after termination of sputtering	a. Crystal heating due to poor thermal contact	a. Clean or polish the crystal seating surface on the crystal holder; refer to appropriate sensor manual
	b. External magnetic field interfering with the sensor's magnetic field (sputtering sensor)	b. Rotate sensor magnet to proper orientation with external magnetic field, refer to the sputtering sensor manual IPN 074-157
	c. Sensor magnet cracked or demagnetized (sputtering sensor)	c. Check sensor magnetic field strength, the maximum field at the center of the aperture should be 700 gauss or greater



Table 13-7 Troubleshooting transducers/sensors (continued)

SYMPTOM	CAUSE	REMEDY
8. XtalSix, Xtal12, or Generic crystal switch problem (does not advance or not centered in aperture)	a. No relay or incorrect relay output programmed	Program relay
	b. Loss of pneumatic supply, or pressure is insufficient for proper operation	b. Ensure air supply is regulated at 80-90 psi
	c. Operation has been impaired as a result of material accumulation on cover	c. Clean material accumulation as needed, refer to XtalSix manual IPN 074-155 or Crystal12 manual IPN 074-398-P1 for maintenance
	d. Improper alignment	d. Realign as per instructions in XtalSix manual IPN 074-155 or Crystal12 manual IPN 074-398-P1
	e. 0.0225" diameter orifice not installed on the supply side of solenoid valve assembly	e. Install orifice as shown in the XtalSix manual IPN 074-155 or Crystal12 manual IPN 074-398-P1

## 13.6.3 Troubleshooting Computer Communications

Table 13-8 Troubleshooting computer communications

SYMPTOM	CAUSE	REMEDY
Communications cannot be established between the host computer and Cygnus 2	a. Use RS-232 loopback and Test RS-232 diagnostic function to determine if cause is Cygnus 2 or if cause is RS-232 cable / host computer.	a. If cause is RS-232 cable / host computer see Cause/Remedy b and c. If cause is Cygnus 2 contact INFICON service department
	b. Improper cable connection	b. Verify for correct cable wiring as described in section 2.3.2.5 on page 2-11.
	c. BAUD rate in host computer not the same as Cygnus 2	c. Verify BAUD rate in the host's applications program, verify BAUD rate in Cygnus 2
	d. Incompatible protocols being used	d. Verify that the Cygnus 2 protocol: RS232, DATALOG, matches host
2. Error code returned	See section 9.3.1.3	See section 9.3.1.3



#### 13.7 Replacing the Crystal

The procedure for replacing the crystal is basically the same with all transducers, except the XtalSix.



#### **CAUTION**

Always use clean nylon lab gloves and plastic tweezers for handling the crystal (to avoid contamination which may lead to poor adhesion of the film to the electrode).

Do not rotate the ceramic retainer assembly after it is seated (as this will scratch the crystal electrode and cause poor contact).

Do not use excessive force when handling the ceramic retainer assembly since breakage may occur.

**NOTE:** Certain materials, especially dielectrics, may not adhere strongly to the crystal surface and may cause erratic readings.

**NOTE:** Thick deposits of some materials, such as SiO, Si, and Ni will normally peel off the crystal when it is exposed to air, as a result of changes in film stress caused by gas absorption. When you observe peeling, replace the crystals.

#### 13.7.1 Front Load

Follow the procedure below to replace the crystal in the Front Load sensor: (see Figure 13-1)

- **1** Gripping the crystal holder with your fingers, pull it straight out of the sensor body.
- **2** Gently pry the crystal retainer from the holder (or use the Crystal Snatcher; see Figure 13-6 on page 13-25).
- **3** Turn the retainer over and the crystal will drop out.
- 4 Install a new crystal, with the patterned electrode face up.
- **5** Push the retainer back into the holder and replace the holder in the sensor body.






Figure 13-1 Front load crystal sensor (exploded)


#### 13.7.2 Cool Drawer

Follow the procedure below to replace the crystal in a Next Generation Cool Drawer™ sensor:

- 1 Using your thumb and index fingers, gently squeeze the sides of the retainer at the mid section then lift it up, away from the drawer, as shown in Figure 13-2.
- **2** Hold the drawer by the handle and turn it upside down to remove the spent crystal.
- **3** Install a new crystal in the drawer. Observe its orientation. The pattern electrode should face upward as shown in Figure 13-3.



- 4 Hold the retainer by its sides. Align its orientation notch with the drawer then gently and evenly push the retainer down until it snaps firmly into the drawer. see Figure 13-3. Never push down (or pull up) on the contact spring, doing so may permanently damage it.
- 5 Inspect the whole assembly. The retainer should be even and engage the drawer at all four corners.







Figure 13-3 Cool drawer - replacing the crystal






#### 13.7.3 Shuttered and Dual Sensors

There is no difference in the crystal replacement procedure between shuttered and non-shuttered Front Load sensors, since the shutter pivots away from the crystal opening when the shutter is in the relaxed state. This is also the case for Cool Drawer Sensors as the shutter assembly does not obstruct the drawer from being inserted into the sensor body.

#### 13.7.4 Bakeable Sensor

For the Bakeable sensor, the procedure is the same as the Front Load sensor except that you must first unlock the cam assembly by flipping it up. Once the crystal has been replaced, place a flat edge of the holder flush with the cam mechanism and lock it in place with the cam. See Figure 13-4.

Figure 13-4 Bakeable crystal sensor






#### 13.7.5 Sputtering Sensor

Observe the general precautions for replacing crystals and follow the instructions below to replace the crystal in a sputtering sensor.

- **1** Grip the body assembly with your fingers and pull it straight out to separate it from the water-cooled front cover. (You may have to disconnect the sensor cable in order to separate the parts.) See Figure 13-5.
- **2** Pull the crystal holder straight out from the front of the body assembly.
- **3** Remove the ceramic retainer from the crystal holder by pulling it straight out with the crystal snatcher (see section 13.7.6 on page 13-25).
- 4 Turn the crystal holder over so that the crystal drops out.
- **5** Install a new crystal into the crystal holder with the patterned electrode facing the back and contacting the leaf springs on the ceramic retainer.
- **6** Put the ceramic retainer back into the crystal holder and put the holder into the body assembly of the sensor.
- 7 Align the position of the body assembly so that the connector matches with the notch on the front cover of the sensor. Snap the two parts together. Reconnect the sensor cable if it has been disconnected.

Figure 13-5 Sputtering crystal sensor






#### 13.7.6 Crystal Snatcher

Use the crystal snatcher, supplied with the sensor, as follows:

- 1 Insert crystal snatcher into ceramic retainer (1) and apply a small amount of pressure. This locks the retainer to the snatcher and allows the retainer to be pulled straight out (2). See Figure 13-6.
- 2 Reinsert the retainer into the holder after the crystal has been replaced.
- **3** Release the crystal snatcher with a slight side-to-side motion.

Figure 13-6 Use of the crystal snatcher



#### 13.7.7 CrystalSix (XtalSix)

Refer to the Crystal Six Operating Manual (IPN 074-155) for specific instructions for this device.




# 13.8 Crystal Sensor Emulator IPN 760-601-G1 or 760-601-G2

**NOTE:** Crystal Sensor Emulator 760-601-G1 (obsolete) is not compatible for use with a Cygnus 2, IC6, IC/5 and IC/4. 760-601-G2 is fully compatible with all Thin Film Deposition Controllers.


The Crystal Sensor Emulator option is used in conjunction with the Thin Film Deposition Controller to rapidly diagnose problems with the Deposition Controller's measurement system. See Figure 13-7.

Figure 13-7 Crystal sensor emulator



The Crystal Sensor Emulator may be attached at various points in the measurement system, from the oscillator to the sensor head. It provides a known good monitor crystal with known good electrical connections. Using the emulator and the controller in a systematic manner provides a fast means of isolating measurement system, cable, or sensor problems. See Figure 13-8.

Figure 13-8 Crystal sensor emulator attachment points





#### **CAUTION**

This product is designed as a diagnostic tool, and is not intended for use in vacuum. Do not leave the Crystal Sensor Emulator installed in the vacuum system during processing.



#### 13.8.1 Diagnostic Procedures

The following diagnostic procedures employ the Crystal Sensor Emulator to analyze a constant Crystal Fail message. The symptom is a Crystal Fail message that is displayed by the Deposition Controller even after the monitor crystal has been replaced with a new good monitor crystal.

**NOTE:** The Unable To Auto-Z message will be displayed if the Crystal Sensor Emulator is attached to a deposition controller and you are attempting to use the Auto-Z feature. This is to be expected and is normal.

#### 13.8.1.1 Measurement System Diagnostic Procedure

- **1** Refer to Figure 13-8 on page 13-26. Remove the six-inch BNC cable from the feedthrough at point A.
- **2** Connect the Crystal Sensor Emulator to the 6 inch BNC cable at Point A.
  - If the Crystal Fail message disappears after approximately five seconds, the measurement system is working properly. Re-install the six-inch BNC cable to the feedthrough. Go to section 13.8.1.2.
  - If the Crystal Fail message remains, continue at step 3.
- **3** Disconnect the six-inch BNC cable from the Oscillator and from the Emulator.
- **4** Visually inspect the six-inch BNC cable to verify that the center pins are seated properly.
- **5** Use an Ohm meter to verify the electrical connections on the six-inch BNC cable.
  - There must be continuity (<0.2 ohms, after accounting for resistance of ohmmeter leads) between the center pins.
  - There must be isolation (>10 megohms) between the center pins and the connector shield.
  - There must be continuity between the connector shields.

Replace the six-inch BNC cable if it is found to be defective and repeat Step 2 of this procedure.

**6** If the six-inch BNC cable is not defective, re-connect the six-inch cable to the oscillator and to the Crystal Sensor Emulator. If the Crystal Fail message remains, contact INFICON—refer to section 1.3 on page 1-5.



# 13.8.1.2 Feedthrough Or In-Vacuum Cable Diagnostic Procedure

- **1** Refer to Figure 13-8 on page 13-26. Remove the in-vacuum cable from the Sensor Head at point B.
- **2** Connect the Crystal Sensor Emulator to the in-vacuum cable.
  - If the Crystal Fail message disappears after approximately five seconds, the feedthrough and in-vacuum cable are working properly. Re-install the in-vacuum cable to the Sensor Head. Go to section section 13.8.1.3 on page 13-29.
  - If the Crystal Fail message remains, continue at step 3.
- **3** Disconnect the in-vacuum cable from the feedthrough and the Emulator. Disconnect the six-inch BNC cable from the feedthrough.
- **4** Using an Ohm Meter, verify electrical continuity from the BNC center pin on the feedthrough to the Microdot center pin on the feedthrough. A typical value would be less than 0.2 ohms.
- **5** Verify electrical isolation of the center pin on the feedthrough from the electrical ground (feedthrough body). A typical value would be in excess of 10 megohms.

If the feedthrough is found to be defective, replace the feedthrough, re-attach the BNC and in-vacuum cables, and repeat this procedure starting at Step 2, otherwise continue at step 6.

- 6 Verify electrical continuity from center pin to center pin on the in-vacuum cable.
- 7 Verify that the center pin of the in-vacuum cable is electrically isolated from the in-vacuum cable shield.

If the in-vacuum cable is found to be defective, replace the in-vacuum cable. Re-attach the BNC and in-vacuum cables, and repeat this procedure starting at Step 2, otherwise continue at step 8.

- 8 Connect the in-vacuum cable to the feedthrough.
- **9** Verify electrical continuity from the center pin on the BNC connector of the feedthrough to the center pin on the un-terminated end of the in-vacuum cable.
- 10 Verify electrical isolation from the center pin to electrical ground (feedthrough body).

If the feedthrough/in-vacuum cable system is found to be defective, look for defective electrical contacts at the feedthrough to in-vacuum cable connection. Repair or replace the feedthrough as necessary. Re-attach the BNC and in-vacuum cables and repeat this procedure starting at step 2. Otherwise, continue at step 11.

11 Connect the six-inch BNC cable to the feedthrough and disconnect it from the Crystal Interface Unit (or Oscillator)



- 12 Verify electrical continuity from the center pin of the Microdot connector on the feedthrough to the un-terminated end of the six-inch BNC cable.
- **13** Verify electrical isolation from the center pin to electrical ground (feedthrough body).

If the feedthrough/six-inch BNC cable system is found to be defective, look for defective contacts at the feedthrough to BNC cable connection. Repair or replace the feedthrough as necessary, re-attach the BNC cable to the XIU and in-vacuum cable to the Crystal head and repeat this procedure starting at step 2.

# 13.8.1.3 Sensor Head Or Monitor Crystal Diagnostic Procedure

**NOTE:** The procedure is for use with front load style sensor heads.

- **1** Remove the Crystal Cover from the Sensor Head.
- **2** Refer to Figure 13-7 on page 13-26. Connect the Crystal Sensor Emulator to the Sensor Head at Point C.
  - If the Crystal Fail message disappears after approximately 5 seconds the Sensor Head is operating properly. Remove the Crystal Sensor Emulator and re-insert the Crystal Cover into the Sensor Head.
  - If the Crystal Fail message remains, continue at step 3.
- **3** Disconnect the in-vacuum cable from the Sensor Head and the feedthrough. Remove the Crystal Sensor Emulator from the Sensor Head.
- 4 Using an Ohm meter, verify the electrical connections on the Sensor Head.
  - Verify there is electrical continuity from the center pin contact on the Microdot connector on the Sensor Head to the leaf spring contact in the Sensor Head. Take care not to apply to much pressure on the center pin of the microdot connector as it may become damaged.
  - There must be electrical isolation between the center pin of the Microdot connector and the Sensor Head body.

If the Sensor Head is found to be defective, contact INFICON to have the Sensor Head repaired—refer to section 1.3 on page 1-5.



- **5** Connect the in-vacuum cable to the Sensor Head.
  - Verify there is continuity (<0.2 ohm) from the leaf spring contact in the Sensor Head to the center pin on the un-terminated end of the in-vacuum cable.
  - Verify there is isolation (>10 megohm) between the leaf spring contact and the in-vacuum cable shield.

If the Sensor Head or the in-vacuum cable system is found to be defective, look for defective contacts at the in-vacuum cable to Sensor Head connection, repair or replace the Sensor Head as necessary. Re-attach the in-vacuum cable to the feedthrough and repeat this procedure starting at step 2.

**6** Ensure that the leaf springs in the Sensor Head and those in the ceramic retainer are bent to an angle of approximately 60° and 45° from flat, respectively.

#### 13.8.1.4 System Diagnostics Pass But Crystal Fail Message Remains

If the system is operating properly yet the Crystal Fail message is still displayed, perform the following tasks.

- 1 On the ceramic retainer verify that the center rivet is secure. Repair or replace the Ceramic Retainer as necessary.
- 2 Inspect the inside of the Crystal Holder for build-up of material. Clean or replace the Crystal Holder as necessary.

After verifying the Sensor Head contacts, the Sensor Head/in-vacuum cable connection and the ceramic retainer contacts, re-assemble the system. If the Crystal Fail message remains, replace the monitor crystal with a new monitor crystal. Verify that the monitor crystal works properly by inserting it into a known good measurement system. If you continue to experience problems, contact INFICON.

#### 13.8.2 % XTAL Life

The Crystal Sensor Emulator contains a quartz crystal having a fundamental frequency at 5.5 MHz. With the Crystal Sensor Emulator connected, the % XTAL Life display should read approximately 30% for Cygnus 2 deposition controllers which allow a 1.5 MHz frequency shift.



#### 13.8.3 Sensor Cover Connection

The Crystal Sensor Emulator can be used to verify the measurement system for INFICON Thin Film Deposition Controllers and Monitors.

**NOTE:** The Crystal Sensor Emulator 760-601-G1 is not compatible for use with an Cygnus 2. Use 760-601-G2 for all thin film deposition controllers.

However, the Crystal Sensor Emulator's Sensor Cover Connector is compatible with some sensor heads, and is incompatible with others. This is discussed in the following sections.

#### 13.8.3.1 Compatible Sensor Heads

The Sensor Cover Connection will fit the sensor heads shown in Table 13-9.

Table 13-9 Compatible sensor heads

Sensor Head	Part Number
Front Load Single Sensor Head	SL-XXXXX
Front Load Dual Sensor Head	DL-AEXX

#### 13.8.3.2 Incompatible Sensor Heads

The Sensor Heads for which the Crystal Sensor Emulator's Sensor Cover Connector will not fit are shown in Table 13-10.

Table 13-10 Incompatible sensor heads

Sensor Head	Part Number
Front Load UHV Bakeable Sensor Head	BK-AXX
Cool Drawer Single Sensor Head	CDS-XXXXX
Sputtering Sensor Head	750-618-G1
CrystalSix Sensor Head	750-446-G1
Cool Drawer Dual Sensor Head	CDD-XXXX
Crystal12 Sensor Head	XL12-XXXXXX
RSH-600 Sensor Head	15320X-XX

**NOTE:** The Crystal Sensor Emulator's Sensor Cover will not fit the crystal holder opening of the older style INFICON transducers that have the soldered finger springs.



#### 13.8.4 Specifications

#### **Dimensions**

1.58 in. diameter x 1.79 in. (40.13 mm diameter x 45.47 mm)

#### **Temperature Range**

0 to 50°C

#### **Frequency**

760-601-G1: 5.5 MHz  $\pm$  30 ppm at room temperature 760-601-G2: 5.5 MHz  $\pm$  1 ppm at room temperature

#### **Materials**

304 Stainless Steel, Nylon, Teflon, brass. Some internal components contain zinc, tin, and lead.



# Chapter 14 Measurement and Control Theory

#### 14.1 Basics

The Quartz Crystal deposition Monitor, or QCM, utilizes the piezoelectric sensitivity of a quartz monitor crystal to added mass. The QCM uses this mass sensitivity to control the deposition rate and final thickness of a vacuum deposition. When a voltage is applied across the faces of a properly shaped piezoelectric crystal, the crystal is distorted and changes shape in proportion to the applied voltage. At certain discrete frequencies of applied voltage, a condition of very sharp electro-mechanical resonance is encountered. When mass is added to the face of a resonating quartz crystal, the frequency of these resonances are reduced. This change in frequency is very repeatable and is precisely understood for specific oscillating modes of quartz. This heuristically easy to understand phenomenon is the basis of an indispensable measurement and process control tool that can easily detect the addition of less than an atomic layer of an adhered foreign material.

In the late 1950's it was noted by Sauerbrey<sup>1,2</sup> and Lostis<sup>3</sup> that the change in frequency, DF =  $F_q$ - $F_c$ , of a quartz crystal with coated (or composite) and uncoated frequencies,  $F_c$  and  $F_q$  respectively, is related to the change in mass from the added material,  $M_f$ , as follows:

$$\frac{M_{f}}{M_{q}} = \frac{(\Delta F)}{F_{q}}$$
 [1]

where  ${\rm M_q}$  is the mass of the uncoated quartz crystal. Simple substitutions lead to the equation that was used with the first "frequency measurement" instruments:

$$T_{f} = \frac{K(\Delta F)}{d_{f}}$$
 [2]

where the film thickness,  $T_f$ , is proportional (through K) to the frequency change, DF, and inversely proportional to the density of the film,  $d_f$ . The constant,  $K = N_{at}d_q/F_q^2$ ; where  $d_q$  (= 2.649 gm/cm³) is the density of single crystal quartz and  $N_{at}$  (=166100 Hz cm) is the frequency constant of AT cut quartz. A crystal with a starting frequency of 6.0 MHz will display a reduction of its frequency by 2.27 Hz when 1 angstrom of Aluminum (density of 2.77 gm/cm³) is added to its surface. In this manner the thickness of a rigid adlayer is inferred from the precise measurement of the crystal's frequency shift. The quantitative knowledge of this

<sup>1.</sup>G. Z. Sauerbrey, Phys. Verhand .8, 193 (1957)

<sup>2.</sup>G. Z. Sauerbrey, Z. Phys. <u>155</u>,206 (1959)

<sup>3.</sup>P. Lostis, Rev. Opt. 38,1 (1959)




effect provides a means of determining how much material is being deposited on a substrate in a vacuum system, a measurement that was not convenient or practical prior to this understanding.

#### 14.1.1 Monitor Crystals

No matter how sophisticated the electronics surrounding it, the essential device of the deposition monitor is the quartz crystal. The quartz crystal shown in Figure 14-1 has a frequency response spectrum that is schematically shown in Figure 14-2. The ordinate represents the magnitude of response, or current flow of the crystal, at the specified frequency.

Figure 14-1 Quartz resonator



The lowest frequency response is primarily a "thickness shear" mode that is called the fundamental. The characteristic movement of the thickness shear mode is for displacement to take place parallel to the major monitor crystal faces. In other words, the faces are displacement antinodes as shown in Figure 14-3. The responses located slightly higher in frequency are called anharmonics; they are a combination of the thickness shear and thickness twist modes. The response at about three times the frequency of the fundamental is called the third quasiharmonic. There are also a series of anharmonics slightly higher in frequency associated with the quasiharmonic.

The monitor crystal design depicted in Figure 14-1 is the result of several significant improvements from the square crystals with fully electroded plane parallel faces that were first used. The first improvement was to use circular crystals. This increased symmetry greatly reduced the number of allowed vibrational modes. The second set of improvements was to contour one face of the crystal and to reduce the size of the exciting electrode. These improvements have the effect of trapping the acoustic energy. Reducing the electrode diameter limits the excitation to the central area. Contouring dissipates the energy of the traveling acoustic wave before it reaches the edge of the crystal. Energy is not reflected back to the center where it can interfere with other newly launched waves, essentially making a small crystal appear to behave as though it is infinite in extent. With the crystal's vibrations restricted to the center, it is practical to clamp the outer edges of the crystal to a holder and not produce any undesirable effects. Contouring also



reduces the intensity of response of the generally unwanted anharmonic modes; hence, the potential for an oscillator to sustain an unwanted oscillation is substantially reduced.




Figure 14-2 Frequency response spectrum

The use of an adhesion layer has improved the electrode-to-quartz bonding, reducing "rate spikes" caused by micro-tears between the electrode and the quartz as film stress rises. These micro-tears leave portions of the deposited film unattached and therefore unable to participate in the oscillation. These free portions are no longer detected and the wrong thickness consequently inferred.

The "AT" resonator is usually chosen for deposition monitoring because at room temperature it can be made to exhibit a very small frequency change due to temperature changes. Since there is presently no way to separate the frequency change caused by added mass (which is negative) or even the frequency changes caused by temperature gradients across the crystal or film induced stresses, it is essential to minimize these temperature-induced changes. It is only in this way that small changes in mass can be measured accurately.






Figure 14-3 Thickness shear displacement

#### 14.1.2 Period Measurement Technique

Although instruments using equation [2] were very useful, it was soon noted they had a very limited range of accuracy, typically holding accuracy for DF less than  $0.02 \; F_q$ . In 1961 it was recognized by Behrndt<sup>4</sup> that:

$$\frac{M_f}{M_q} = \frac{(T_c - T_q)}{T_q} = \frac{(\Delta F)}{F_c}$$
 [3]

where  $T_c$  and  $T_q$  are the periods of oscillation of the crystal with film (composite) and the bare crystal respectively. The period measurement technique was the outgrowth of two factors; first, the digital implementation of time measurement, and second, the recognition of the mathematically rigorous formulation of the proportionality between the crystal's thickness,  $I_q$ , and the period of oscillation,  $T_q = 1/F_q$ . Electronically the period measurement technique uses a second crystal oscillator, or reference oscillator, not affected by the deposition and usually much higher in frequency than the monitor crystal. This reference oscillator is used to generate small precision time intervals which are used to determine the oscillation period of the monitor crystal. This is done by using two pulse accumulators. The first is used to accumulate a fixed number of cycles, m, of the monitor crystal. The second is turned on at the same time and accumulates cycles from the reference oscillator until m counts are accumulated in the first. Since the frequency of the reference is stable and known, the time to accumulate the m counts is known to an accuracy equal to  $\pm 2/F_r$  where  $F_r$  is the reference oscillator's frequency. The

<sup>4.</sup>K. H. Behrndt, J. Vac. Sci. Technol. 8, 622 (1961)



monitor crystal's period is  $(n/F_r)/m$  where n is the number of counts in the second accumulator. The precision of the measurement is determined by the speed of the reference clock and the length of the gate time (which is set by the size of m). Increasing one or both of these leads to improved measurement precision.

Having a high frequency reference oscillator is important for rapid measurements (which require short gating times), low deposition rates and low density materials. All of these require high time precision to resolve the small, mass induced frequency shifts between measurements. When the change of a monitor crystal's frequency between measurements is small, that is, on the same order of size as the measurement precision, it is not possible to establish quality rate control. The uncertainty of the measurement injects more noise into the control loop, which can be counteracted only by longer time constants. Long time constants cause the correction of rate errors to be very slow, resulting in relatively long term deviations from the desired rate. These deviations may not be important for some simple films. but can cause unacceptable errors in the production of critical films such as optical filters or very thin layered superlattices grown at low rates. In many cases the desired properties of these films can be lost if the layer to layer reproducibility exceeds one, or two, percent. Ultimately, the practical stability and frequency of the reference oscillator limits the precision of measurement for conventional instrumentation.

#### 14.1.3 Z-match Technique

After learning of fundamental work by Miller and Bolef <sup>5</sup>, which rigorously treated the resonating quartz and deposited film system as a one-dimensional continuous acoustic resonator, Lu and Lewis<sup>6</sup> developed the simplifying Z-match™ equation in 1972. Advances in electronics taking place at the same time, namely the micro-processor, made it practical to solve the Z-match equation in "real-time". Most deposition process controllers sold today use this sophisticated equation that takes into account the acoustic properties of the resonating quartz and film system as shown in equation [4].

$$T_{f} = \left(\frac{N_{at}d_{q}}{\pi d_{f}F_{c}Z}\right)\arctan\left(Z\tan\left[\frac{\pi(F_{q}-F_{c})}{F_{q}}\right]\right)$$
 [4]

where  $Z=(d_qu_q/d_fu_f)^{1/2}$  is the acoustic impedance ratio and  $u_q$  and  $u_f$  are the shear moduli of the quartz and film, respectively. Finally, there was a fundamental understanding of the frequency-to-thickness conversion that could yield theoretically correct results in a time frame that was practical for process control. To achieve this new level of accuracy requires only that the user enter an additional material parameter, Z, for the film being deposited. This equation has been tested

<sup>5.</sup>J. G. Miller and D. I. Bolef, J. Appl. Phys. <u>39</u>, 5815, 4589 (1968)

<sup>6.</sup>C. Lu and O. Lewis, J Appl. Phys. 43, 4385 (1972)




for a number of materials, and has been found to be valid for frequency shifts equivalent to  $F_f$  = 0.4 $F_q$ . Keep in mind that equation [2] was valid to only 0.02 $F_q$  and equation [3] was valid only to ~0.05 $F_q$ .

#### 14.1.4 Active Oscillator

All of the instrumentation developed to date has relied on the use of an active oscillator circuit, generally the type schematically shown in Figure 14-4. This circuit actively keeps the crystal in resonance, so that any type of period or frequency measurement may be made. In this type of circuit, oscillation is sustained as long as the gain provided by the amplifiers is sufficient to offset losses in the crystal and circuit and the crystal can provide the required phase shift. The basic crystal oscillator's stability is derived from the rapid change of phase for a small change in the crystal's frequency near the series resonance point, as shown in Figure 14-5 on page 14-7.

Figure 14-4 Active oscillator circuit



The active oscillator circuit is designed so the crystal is required to produce a phase shift of 0 degrees, which allows it to operate at the series resonance point. Longand short-term frequency stabilities are a property of crystal oscillators because very small frequency changes are needed to sustain the phase shift required for oscillation. Frequency stability is provided by the quartz crystal even though there are long term changes in electrical component values caused by temperature or aging or short-term noise-induced phase jitter.

As mass is added to a crystal, its electrical characteristics change. Figure 14-6 on page 14-8 is the same plot as Figure 14-5 overlaid with the response of a heavily loaded crystal. The crystal has lost the steep slope displayed in Figure 14-5. Because the phase slope is less steep, any noise in the oscillator circuit translates



into a greater frequency shift than that which would be produced with a new crystal. In the extreme, the basic phase/frequency shape is not preserved and the crystal is not able to provide a full 90 degrees of phase shift.

The impedance, |Z|, is also noted to rise to an extremely high value. When this happens it is often more favorable for the oscillator to resonate at one of the anharmonic frequencies. This condition is sometimes short lived, with the oscillator switching between the fundamental and anharmonic modes, or it may continue to oscillate at the anharmonic. This condition is known as mode hopping and in addition to annoying rate noise can also lead to false termination of the film because of the apparent frequency change. It is important to note that the controller will frequently continue to operate under these conditions; in fact there is no way to tell this has happened except that the film's thickness is suddenly apparently thinner by an amount equivalent to the frequency difference between the fundamental and the anharmonic that is sustaining the oscillation.




Figure 14-5 Crystal frequency near series resonance point

#### 14.1.5 ModeLock Oscillator

INFICON created a new technology that eliminates the active oscillator and its limitations. This new system constantly tests the crystal's response to an applied frequency in order to not only determine the resonant frequency, but also to verify that the crystal is oscillating in the desired mode. This new system is essentially immune to mode hopping and the resulting inaccuracies. It is fast and accurate, determining the crystal's frequency to less than 0.005 Hz at a rate of 10 times per second. Because of the system's ability to identify and then measure particular crystal modes, it is now possible to offer new features that take advantage of the additional informational content of these modes. This new "intelligent"



measurement system uses the phase/frequency properties of the quartz crystal to determine the resonant frequency. It operates by applying a synthesized sine wave of specific frequency to the crystal and measuring the phase difference between the applied signal's voltage and the current passing through the crystal. At series resonance, this phase difference is exactly 0 degrees; that is, the crystal behaves like a pure resistance. By separating the applied voltage and the current returned from the crystal and monitoring the output of a phase comparator it is possible to establish whether the applied frequency is higher or lower than the crystal's resonance point. At frequencies well below the fundamental, the crystal's impedance is capacitive and at frequencies slightly higher than resonance it is inductive in nature. This information is useful if the resonance frequency of a crystal is unknown. A quick sweep of frequencies can be undertaken until the output of the phase comparator changes, marking the resonance event. For AT crystals we know that the lowest frequency event encountered is the fundamental. The events slightly higher in frequency are anharmonics. This information is useful not only for initialization, but also for the rare case when the instrument loses track of the fundamental. Once the frequency spectrum of the crystal is determined the instrument's task is to follow the changing resonance frequency and to periodically provide a measurement of the frequency for subsequent conversion to thickness.




Figure 14-6 Heavily loaded crystal

The use of the "intelligent" measurement system has a series of very apparent advantages when compared to the previous generation of active oscillators, namely immunity from mode hopping, speed of measurement and precision of measurement. The technique also allows the implementation of a sophisticated feature that cannot even be contemplated using the active oscillator approach. The same capability that allows the new technology to sweep and identify the fundamental can be used to identify other oscillation modes, such as the anharmonics and the quasiharmonic. Not only can the instrument track the



fundamental mode continuously, but also it can be implemented to alternate between one or more other modes. This interrogation of multiple modes can be performed as fast as 10 Hz for two modes of the same crystal.

#### 14.1.6 Auto-Z Theory

The one drawback in using equation [4] on page 14-5 is that the acoustic impedance must be known. There are several cases where accuracy has to be compromised because of incomplete or limited knowledge of the material constants of the deposited materials.

- Often the Z-Ratio for the bulk material is different from that of the deposited thin film. Thin films are especially sensitive to process parameters, particularly in a sputtering environment. Consequently, the values available for bulk materials may not be pertinent.
- For many exotic materials, including alloys, the Z-Ratio is not known nor easily available.
- There has always been a need to accurately measure layer thickness of multiple material films using the same crystal sensor. This is particularly true for multi-layer optical coatings and high-temperature superconductor fabrication. The effective Z-Ratio of the composite of multi-material layers is not known.

In such cases, the only recourse is to assume the Z-Ratio to be unity (that is, ignoring the reality of wave propagation in composite media). This false premise introduces error in the thickness and rate predictions. The magnitude of this error depends upon the film thickness and the amount of departure of the true Z-Ratio from unity.

In 1989, A. Wajid became aware of the ModeLock oscillator<sup>7</sup>. He speculated there might be a relationship between the fundamental and one of the anharmonics similar to the relationship noted by Benes<sup>8</sup> between the fundamental and the third quasiharmonic. The frequencies of the fundamental and the anharmonics are very similar, solving the problem of capacitance of long cables. He found the ideas needed for establishing the required connections in papers published by Wilson<sup>9</sup> in 1974 and Tiersten and Smythe<sup>10</sup> in 1979.

Contouring a crystal, that is, giving one face a spherical shape, has the effect of separating the various modes further apart and preventing the transfer of energy from one mode to another. For the sake of identification it is common to assign mode [100] to the fundamental, [102] to the lowest frequency anharmonic and [120] to the next lowest frequency anharmonic. The three indices of the mode

<sup>7.</sup>U.S. Patent No. 5,117,192 (May 26, 1992) International Patents Pending.

<sup>8.</sup>E. Benes, J. Appl. Phys. 56(3), 608-626 (1984)

<sup>9.</sup>C. J. Wilson, J. Phys. d7,2449 (1974)

<sup>10.</sup>H. F. Tiersten and R.C. Smythe, J. Acoust. Soc. Am., 65(6), 1455 (1979).



assignment refer to the number of phase reversals in the wave motion along the three axes of the crystal. The above-referenced papers by Wilson and Tiersten & Smythe are examinations of modal properties, relating the various properties of the radius of curvature to the placement of the anharmonics relative to the fundamental.

As material is deposited upon one face of a crystal, the entire spectrum of resonances shifts to lower frequencies. The three above mentioned modes are observed to have slightly different mass sensitivity and hence undergo slightly different frequency shifts. It is this difference that is used to estimate the Z-Ratio of the material. Using the modal equations and the observed frequencies of the modes [100] and [102], one can calculate the ratio of two elastic constants  $C_{66}$  and  $C_{55}$ . Both of these elastic constants relate to shear motion. The essential element of Wajid's theory is the following equation:

$$\frac{(C_{55}/C_{66})_{\text{coated}}}{(C_{55}/C_{66})_{\text{uncoated}}} \sim \frac{1}{(1+MZ)}$$
 [5]

where M is the aerial mass density (film mass to quartz mass ratio per unit area) and Z is the Z-Ratio. It is a fortunate coincidence that the combination MZ also appears in the Lu-Lewis equation [4], which can be used to extract an estimate of the effective Z-Ratio from the equations below:

$$\tan\left(MZ\pi\frac{F_c}{F_a}\right) + Z\tan\left(\pi\frac{F_c}{F_a}\right) = 0$$
 [6]

or

$$Z = -\frac{\tan\left(MZ\pi\frac{F_c}{F_q}\right)}{\tan\left(\pi\frac{F_c}{F_q}\right)}$$
 [7]

Where,  $F_q$  and  $F_c$  denote uncoated and coated crystal frequencies in the fundamental mode (mode [100]). Due to the multi-valued nature of the mathematical functions involved, the value of Z-Ratio extracted in this manner is not always a positive definite quantity. This is hardly of any consequence however, because M is uniquely determined with the estimated Z and the measured frequency shift. Thus, thickness and rate of deposition are subsequently calculated from the knowledge of M.<sup>11</sup>

One must be aware of the limitations of this technique. Since the estimate for Z-Ratio is dependent on the frequency shifts of the two modes, any spurious shift due to excessive mechanical or thermal stress on the crystal will lead to errors.

<sup>11.</sup>U.S. Patent No. 5,112,642 (May 12, 1992) International Patents Pending.



Needless to say, similar errors occur with the Z-match™ technique under similar circumstances. However, the automatic Z-Ratio estimate is somewhat more prone to error, because the amplitude distribution of the mode [102] is asymmetric, whereas that of the mode [100] is symmetric over the active area of the crystal.

In our experience, film-induced stress on the crystal has the most deleterious effect. This effect is most pronounced whenever there is a presence of gas in the environment, for example, in reactive evaporation or sputtering processes. In such cases, if the bulk Z-Ratio is already well known, it is better to use the bulk value instead of the automatically determined Auto-Z-Ratio. In cases of co-deposition and sequential layers, automatic Z-Ratio estimation is significantly superior.

#### 14.1.7 Control Loop Theory

The instrumental advances in measurement speed, precision and reliability would not be complete without a means of translating this improved information into improved process control. For a deposition process, this means keeping the deposition rate as close as possible to the desired rate. The purpose of a control loop is to take the information flow from the measurement system and to make power corrections that are appropriate to the characteristics of the particular evaporation source. When properly operating, the control system translates small errors in the controlled parameter, or rate, into the appropriate corrections in the manipulated parameter, power. The controller's ability to quickly and accurately measure and then react appropriately to the small changes keeps the process from deviating very far from the set point.

The controller model most commonly chosen for converting error into action is called PID. In the PID, P stands for proportional, I stands for integral and D stands for derivative action. Certain aspects of this model will be examined in detail a little further on. The responsiveness of an evaporation source can be found by repetitively observing the system response to a disturbance under a particular set of controller settings. After observing the response, improved controller parameters are estimated and then tried again until satisfactory control is obtained. Control, when it is finally optimized, essentially matches the parameters of the controller model to the characteristics of the evaporation source.

Techniques for calculating optimum source control parameters can be classified by the type of data used for tuning. They fall into basically three categories:

- Closed Loop Methods
- Open Loop Methods
- Frequency Response Methods

Of these categories, the open loop methods are considered superior. They are considered superior because of the ease with which the necessary experimental data can be obtained and because of the elimination (to a large extent) of trial and error when the technique is applied.




In general, it is not possible to characterize all processes exactly; some approximation must be applied. The most common is to assume that the dynamic characteristics of the process can be represented by a first-order lag plus a dead time. The Laplace transform for this model (conversion to the s domain) is approximated as:

$$\frac{\text{Output}}{\text{Input}} = \frac{K_p \exp(-Ls)}{T_1 s + 1}$$
 [8]

Three parameters are determined from the process reaction curve. They are the steady state gain,  $K_p$ , the dead time, L, and the time constant,  $T_1$ . Several methods have been proposed to extract the required parameters from the system response as graphed in Figure 14-7. These are: a one point fit at 63.2% of the transition (one time constant); a two point exponential fit; and a weighted least-square-exponential fit. From the above information a process is sufficiently characterized so that a controller algorithm may be customized.

Figure 14-7 Response of process to an open loop step change (At t=0 control signal is increased)



A controller model used extensively is the PID type, shown in Laplace form in equation [9].

$$M(s) = K_c \left(1 + \frac{1}{T_i s} + T_d s\right) Es$$
 [9]

Where


- ◆ M(s) = manipulated variable or power
- K<sub>c</sub> = controller gain (the proportional term)



- T<sub>i</sub> = integral time
- T<sub>d</sub> = derivative time
- ◆ E(s) = process error

Figure 14-8 represents the controller algorithm and a process with first order lag plus a dead time. The process block implicitly includes the dynamics of the measuring devices and the final control elements, in our case the evaporator power supply. R(s) represents the rate setpoint. The feedback mechanism is the error generated by the difference between the measured deposition rate, C(s), and the rate set point, R(s).

Figure 14-8 PID controller block diagram



The key to using any control system is to choose the proper values of  $K_c$ ,  $T_d$  and  $T_i$ . Optimum control is a somewhat subjective quantity as noted by the presence of several mathematical definitions as shown below.

The Integral of the Squared Error (ISE) is a commonly proposed criterion of performance for control systems.

It can be described as:

$$ISE = \int e^2(t)dt$$
 [10]

where error = e = setpoint minus the measured rate. The ISE measure is relatively insensitive to small errors, but large errors contribute heavily to the value of the integral. Consequently, using ISE as a criterion of performance will result in responses with small overshoots but long settling times, since small errors occurring late in time contribute little to the integral.

The Integral of the Absolute Value of the error (IAE) has been frequently proposed as a criterion of performance:

$$IAE = \int |e(t)|dt$$
 [11]

This criterion is more sensitive to small errors, but less sensitive to large errors, than ISE.



Graham and Lathrop<sup>12</sup> introduced the Integral of Time multiplied by the Absolute Error (ITAE) as an alternate criterion of performance:

$$ITAE = \int t|e(t)|dt$$
 [12]

ITAE is insensitive to the initial and somewhat unavoidable errors, but it will weight heavily any errors occurring late in time. Optimum responses defined by ITAE will consequently show short total response times and larger overshoots than with either of the other criteria. It has been found that this criteria is generally most useful for deposition process control.

The most satisfactory performance criterion for deposition controllers is the ITAE. There will be overshoot, but the response time is quick, and the settling time is short. For all of the above integral performance criteria, controller tuning relations have been developed to minimize the associated errors. Using manually entered or experimentally determined process response coefficients, ideal PID controller coefficients can be readily calculated for the ITAE criteria as shown below.

$$K_{c} = (1.36/K_{p})(L/T_{1})^{-0.947}$$
 [13]

$$T_i = (1.19T_1)(L/T_1)^{0.738}$$
 [14]

$$T_{\rm d} = (0.381T_1)(L/T_1)^{0.995}$$
 [15]

For slow systems, in order to help avoid controller windup (windup is the rapid increase in control signal before the system has the chance to respond to the changed signal), the time period between manipulated variable (control voltage) changes is lengthened. This allows the system to respond to the previous controller setting change, and aggressive controller settings can be used. A secondary advantage is that immunity to process noise is increased since the data used for control is now comprised of multiple readings instead of a single rate measurement, taking advantage of the mass integrating nature of the quartz crystal.

With process systems that respond quickly (short time constant) and with little to no measurable dead time, the PID controller often has difficulty with the deposition process noise (beam sweep, fast thermal shorts of melt to crucible, etc.). In these situations a control algorithm used successfully is an integral/reset type of controller. This type of controller will always integrate the error, driving the system towards zero error. This technique works well when there is little or no dead time. If this technique is used on a process with measurable lag or dead time, then the control loop will tend to be oscillatory due to the control loop over-compensating the control signal before the system has a chance to respond.

<sup>12.</sup> Graham, D., and Lanthrop, R.C., "The Synthesis of Optimum Transient Response: Criteria and Standard Forms, Transactions IEEE, vol. 72 pt. II, November 1953.



## Appendix A Material Table

## A.1 Introduction

The following Table A-1 represents the content of the Cygnus 2's Material library. The list is alphabetical by chemical formula.



## **CAUTION**

Some of these materials are toxic. Please consult the material safety data sheet and safety instructions before use.

Remote Communications Responses and Commands use the code value to represent a specific Material. An \* is used to indicate that a Z-ratio has not been established for a certain material. A value of 1.000 is defaulted in these situations.

Table A-1 Material Table

Code	Formula	Density	Z-Ratio	Material Name
0	Ag	10.500	0.529	Silver
1	AgBr	6.470	1.180	Silver Bromide
2	AgCl	5.560	1.320	Silver Chloride
3	Al	2.700	1.080	Aluminum
4	$Al_2O_3$	3.970	0.336	Aluminum Oxide
5	$Al_4C_3$	2.360	*1.000	Aluminum Carbide
6	$AIF_3$	3.070	*1.000	Aluminum Fluoride
7	AIN	3.260	*1.000	Aluminum Nitride
8	AlSb	4.360	0.743	Aluminum Antimonide
9	As	5.730	0.966	Arsenic
10	$As_2Se_3$	4.750	*1.000	Arsenic Selenide
11	Au	19.300	0.381	Gold
12	В	2.370	0.389	Boron
13	$B_2 O_3$	1.820	*1.000	Boron Oxide
14	B <sub>4</sub> C	2.370	*1.000	Boron Carbide
15	BN	1.860	*1.000	Boron Nitride
16	Ва	3.500	2.100	Barium



Table A-1 Material Table (continued)

		,		
Code	Formula	Density	Z-Ratio	Material Name
17	BaF <sub>2</sub>	4.886	0.793	Barium Fluoride
18	BaN <sub>2</sub> O <sub>6</sub>	3.244	1.261	Barium Nitrate
19	BaO	5.720	*1.000	Barium Oxide
20	BaTiO <sub>3</sub>	5.999	0.464	Barium Titanate (Tetr)
21	BaTiO <sub>3</sub>	6.035	0.412	Barium Titanate (Cubic)
22	Ве	1.850	0.543	Beryllium
23	BeF <sub>2</sub>	1.990	*1.000	Beryllium Fluoride
24	BeO	3.010	*1.000	Beryllium Oxide
25	Bi	9.800	0.790	Bismuth
26	$Bi_2O_3$	8.900	*1.000	Bismuth Oxide
27	$Bi_2S_3$	7.390	*1.000	Bismuth Trisulphide
28	Bi <sub>2</sub> Se <sub>3</sub>	6.820	*1.000	Bismuth Selenide
29	Bi <sub>2</sub> Te <sub>3</sub>	7.700	*1.000	Bismuth Telluride
30	$BiF_3$	5.320	*1.000	Bismuth Fluoride
31	С	2.250	3.260	Carbon (Graphite)
32	С	3.520	0.220	Carbon (Diamond)
33	C <sub>8</sub> H <sub>8</sub>	1.100	*1.000	Parlyene (Union Carbide)
34	Ca	1.550	2.620	Calcium
35	CaF <sub>2</sub>	3.180	0.775	Calcium Fluoride
36	CaO	3.350	*1.000	Calcium Oxide
37	CaO-SiO <sub>2</sub>	2.900	*1.000	Calcium Silicate (3)
38	CaSO <sub>4</sub>	2.962	0.955	Calcium Sulfate
39	CaTiO <sub>3</sub>	4.100	*1.000	Calcium Titanate
40	CaWO <sub>4</sub>	6.060	*1.000	Calcium Tungstate
41	Cd	8.640	0.682	Cadmium
42	$CdF_2$	6.640	*1.000	Cadmium Fluoride
43	CdO	8.150	*1.000	Cadmium Oxide
44	CdS	4.830	1.020	Cadmium Sulfide
45	CdSe	5.810	*1.000	Cadmium Selenide,
46	CdTe	6.200	0.980	Cadmium Telluride
47	Ce	6.780	*1.000	Cerium
48	CeF <sub>3</sub>	6.160	*1.000	Cerium (III) Fluoride
49	CeO <sub>2</sub>	7.130	*1.000	Cerium (IV) Dioxide



Table A-1 Material Table (continued)

Code	Formula	Density	Z-Ratio	Material Name
50	Со	8.900	0.343	Cobalt
51	CoO	6.440	0.412	Cobalt Oxide
52	Cr	7.200	0.305	Chromium
53	$Cr_2O_3$	5.210	*1.000	Chromium (III) Oxide
54	$Cr_3C_2$	6.680	*1.000	Chromium Carbide
55	CrB	6.170	*1.000	Chromium Boride
56	Cs	1.870	*1.000	Cesium
57	Cs <sub>2</sub> SO <sub>4</sub>	4.243	1.212	Cesium Sulfate
58	CsBr	4.456	1.410	Cesium Bromide
59	CsCl	3.988	1.399	Cesium Chloride
60	Csl	4.516	1.542	Cesium Iodide
61	Cu	8.930	0.437	Copper
62	Cu <sub>2</sub> O	6.000	*1.000	Copper Oxide
63	Cu <sub>2</sub> S	5.600	0.690	Copper (I) Sulfide (Alpha)
64	Cu <sub>2</sub> S	5.800	0.670	Copper (I) Sulfide (Beta)
65	CuS	4.600	0.820	Copper (II) Sulfide
66	Dy	8.550	0.600	Dysprosium
67	$DY_2O_3$	7.810	*1.000	Dysprosium Oxide
68	Er	9.050	0.740	Erbium
69	$Er_2O_3$	8.640	*1.000	Erbium Oxide
70	Eu	5.260	*1.000	Europium
71	EuF <sub>2</sub>	6.500	*1.000	Europium Fluoride
72	Fe	7.860	0.349	Iron
73	$Fe_2O_3$	5.240	*1.000	Iron Oxide
74	FeO	5.700	*1.000	Iron Oxide
75	FeS	4.840	*1.000	Iron Sulphide
76	Ga	5.930	0.593	Gallium
77	$Ga_2O_3$	5.880	*1.000	Gallium Oxide (B)
78	GaAs	5.310	1.590	Gallium Arsenide
79	GaN	6.100	*1.000	Gallium Nitride
80	GaP	4.100	*1.000	Gallium Phosphide
81	GaSb	5.600	*1.000	Gallium Antimonide
82	Gd	7.890	0.670	Gadolinium



Table A-1 Material Table (continued)

		,	7 D-41-	Material Name
Code	Formula	Density	Z-Ratio	Material Name
83	$Gd_2O_3$	7.410	*1.000	Gadolinium Oxide
84	Ge	5.350	0.516	Germanium
85	Ge <sub>3</sub> N <sub>2</sub>	5.200	*1.000	Germanium Nitride
86	GeO <sub>2</sub>	6.240	*1.000	Germanium Oxide
87	GeTe	6.200	*1.000	Germanium Telluride
88	Hf	13.090	0.360	Hafnium
89	HfB <sub>2</sub>	10.500	*1.000	Hafnium Boride,
90	HfC	12.200	*1.000	Hafnium Carbide
91	HfN	13.800	*1.000	Hafnium Nitride
92	HfO <sub>2</sub>	9.680	*1.000	Hafnium Oxide
93	HfSi <sub>2</sub>	7.200	*1.000	Hafnium Silicide
94	Hg	13.460	0.740	Mercury
95	Но	8.800	0.580	Holminum
96	$Ho_2O_3$	8.410	*1.000	Holminum Oxide
97	In	7.300	0.841	Indium
98	$ln_2O_3$	7.180	*1.000	Indiurn Sesquioxide,
99	In <sub>2</sub> Se <sub>3</sub>	5.700	*1.000	Indium Selenide
100	$In_2Te_3$	5.800	*1.000	Indium Telluride
101	InAs	5.700	*1.000	Indium Arsenide
102	InP	4.800	*1.000	Indium Phosphide
103	InSb	5.760	0.769	Indium Antimonide
104	Ir	22.400	0.129	Iridium
105	K	0.860	10.189	Potassium
106	KBr	2.750	1.893	Potassium Bromide
107	KCI	1.980	2.050	Potassium Chloride
108	KF	2.480	*1.000	Potassium Fluoride
109	KI	3.128	2.077	Potassium lodide
110	La	6.170	0.920	Lanthanum
111	La <sub>2</sub> O <sub>3</sub>	6.510	*1.000	Lanthanum Oxide
112	LaB <sub>6</sub>	2.610	*1.000	Lanthanurn Boride
113	LaF <sub>3</sub>	5.940	*1.000	Lanthanum Fluoride
114	Li	0.530	5.900	Lithium
115	LiBr	3.470	1.230	Lithium Bromide



Table A-1 Material Table (continued)

Code	Formula	Density	Z-Ratio	Material Name
116	LiF	2.638	0.778	Lithium Fluoride
117	$LiNbO_3$	4.700	0.463	Lithium Niobate
118	Lu	9.840	*1.000	Lutetium
119	Mg	1.740	1.610	Magnesium
120	$MgAl_2O_4$	3.600	*1.000	Magnesium Aluminate
121	$MgAl_2O_6$	8.000	*1.000	Spinel
122	$MgF_2$	3.180	0.637	Magnesium Fluoride
123	MgO	3.580	0.411	Magnesium Oxide
124	Mn	7.200	0.377	Manganese
125	MnO	5.390	0.467	Manganese Oxide
126	MnS	3.990	0.940	Manganese (II) Sulfide
127	Мо	10.200	0.257	Molybdenum
128	Mo <sub>2</sub> C	9.180	*1.000	Molybdenum Carbide
129	$MoB_2$	7.120	*1.000	Molybdenum Boride
130	$MoO_3$	4.700	*1.000	Molybdenum Trioxdide
131	$MoS_2$	4.800	*1.000	Molybdenum Disulfide
132	Na	0.970	4.800	Sodium
133	Na <sub>3</sub> AIF <sub>6</sub>	2.900	*1.000	Cryolite
134	Na <sub>5</sub> Al <sub>3</sub> F <sub>14</sub>	2.900	*1.000	Chiolite
135	NaBr	3.200	*1.000	Sodium Bromide
136	NaCl	2.170	1.570	Sodium Chloride
137	NaClO <sub>3</sub>	2.164	1.565	Sodium Chlorate
138	NaF	2.558	1.645	Sodium Fluoride
139	NaNO <sub>3</sub>	2.270	1.194	Sodium Nitrate
140	Nb	8.578	0.492	Niobium (Columbium)
141	$Nb_2O_3$	7.500	*1.000	Niobium Trioxide
142	$Nb_2O_5$	4.470	*1.000	Niobium (V) Oxide
143	$NbB_2$	6.970	*1.000	Niobium Boride
144	NbC	7.820	*1.000	Niobium Carbide
145	NbN	8.400	*1.000	Niobium Nitride
146	Nd	7.000	*1.000	Neodynium
147	$Nd_2O_3$	7.240	*1.000	Neodynium Oxide
148	$NdF_3$	6.506	*1.000	Neodynium Fluoride



Table A-1 Material Table (continued)

1001071	material rabie (	oonanaoa)		
Code	Formula	Density	Z-Ratio	Material Name
149	Ni	8.910	0.331	Nickel
150	NiCr	8.500	*1.000	Nichrome
151	NiCrFe	8.500	*1.000	Inconel
152	NiFe	8.700	*1.000	Permalloy
153	NiFeMo	8.900	*1.000	Supermalloy
154	NiO	7.450	*1.000	Nickel Oxide
155	$P_3N_5$	2.510	*1.000	Phosphorus Nitride
156	Pb	11.300	1.130	Lead
157	PbCl <sub>2</sub>	5.850	*1.000	Lead Chloride
158	PbF <sub>2</sub>	8.240	0.661	Lead Fluoride
159	PbO	9.530	*1.000	Lead Oxide
160	PbS	7.500	0.566	Lead Sulfide
161	PbSe	8.100	*1.000	Lead Selenide
162	PbSnO <sub>3</sub>	8.100	*1.000	Lead Stannate
163	PbTe	8.160	0.651	Lead Telluride
164	Pd	12.038	0.357	Palladium
165	PdO	8.310	*1.000	Palladium Oxide
166	Po	9.400	*1.000	Polonium
167	Pr	6.780	*1.000	Praseodymium
168	$Pr_2O_3$	6.880	*1.000	Praseodymium Oxide
169	Pt	21.400	0.245	Platinum
170	PtO <sub>2</sub>	10.200	*1.000	Platinum Oxide
171	Ra	5.000	*1.000	Radium
172	Rb	1.530	2.540	Rubidium
173	Rbl	3.550	*1.000	Rubidiurn Iodide
174	Re	21.040	0.150	Rhenium
175	Rh	12.410	0.210	Rhodium
176	Ru	12.362	0.182	Ruthenium
177	S <sub>8</sub>	2.070	2.290	Sulphur
178	Sb	6.620	0.768	Antimony
179	$Sb_2O_3$	5.200	*1.000	Antimony Trioxide
180	$Sb_2S_3$	4.640	*1.000	Antimony Trisulfide
181	Sc	3.000	0.910	Scandium



Table A-1 Material Table (continued)

Code	Formula	Density	Z-Ratio	Material Name
182	Sc <sub>2</sub> O <sub>3</sub>	3.860	*1.000	Scandium Oxide
183	Se	4.810	0.864	Selenium
184	Si	2.320	0.712	Silicon
185	Si <sub>3</sub> N <sub>4</sub>	3.440	*1.000	Silicon Nitride
186	SiC	3.220	*1.000	Silicon Carbide
187	SiO	2.130	0.870	Silicon (II) Oxide
188	SiO <sub>2</sub>	2.648	1.000	Silicon Dioxide
189	Sm	7.540	0.890	Samarium
190	$Sm_2O_3$	7.430	*1.000	Samarium Oxide
191	Sn	7.300	0.724	Tin
192	SnO <sub>2</sub>	6.950	*1.000	Tin Oxide
193	SnS	5.080	*1.000	Tin Sulfide
194	SnSe	6.180	*1.000	Tin Selenide
195	SnTe	6.440	*1.000	Tin Telluride
196	Sr	2.600	*1.000	Strontium
197	$SrF_2$	4.277	0.727	Strontium Fluroide
198	SrO	4.990	0.517	Strontium Oxide
199	Та	16.600	0.262	Tantalum
200	Ta <sub>2</sub> O <sub>5</sub>	8.200	0.300	Tantalum (V) Oxide
201	TaB <sub>2</sub>	11.150	*1.000	Tantalum Boride
202	TaC	13.900	*1.000	Tantalum Carbide
203	TaN	16.300	*1.000	Tantalum Nitride
204	Tb	8.270	0.660	Terbium
205	Tc	11.500	*1.000	Technetium
206	Te	6.250	0.900	Tellurium
207	TeO <sub>2</sub>	5.990	0.862	Tellurium Oxide
208	Th	11.694	0.484	Thorium
209	ThF <sub>4</sub>	6.320	*1.000	Thorium.(IV) Fluoride
210	ThO <sub>2</sub>	9.860	0.284	Thorium Dioxide
211	ThOF <sub>2</sub>	9.100	*1.000	Thorium Oxyfluoride
212	Ti	4.500	0.628	Titanium
213	$Ti_20_3$	4.600	*1.000	Titanium Sesquioxide
214	TiB <sub>2</sub>	4.500	*1.000	Titanium Boride



Table A-1 Material Table (continued)

Code	Formula	Density	Z-Ratio	Material Name
215	TiC	4.930	*1.000	Titanium Carbide
216	TiN	5.430	*1.000	Titanium Nitride
217	TiO	4.900	*1.000	Titanium Oxide
218	TiO <sub>2</sub>	4.260	0.400	Titanium (IV) Oxide
219	TI	11.850	1.550	Thallium
220	TIBr	7.560	*1.000	Thallium Bromide
221	TICI	7.000	*1.000	Thallium Chloride
222	TII	7.090	*1.000	Thalliurn lodide (B)
223	U	19.050	0.238	Uranium
224	$U_3O_8$	8.300	*1.000	Tri Uranium Octoxide
225	$U_4O_9$	10.969	0.348	Uranium Oxide
226	UO <sub>2</sub>	10.970	0.286	Uranium Dioxide
227	V	5.960	0.530	Vanadium
228	$V_2O_5$	3.360	*1.000	Vanadium Pentoxide
229	$VB_2$	5.100	*1.000	Vanadium Boride
230	VC	5.770	*1.000	Vanadium Carbide
231	VN	6.130	*1.000	Vanadium Nitride
232	VO <sub>2</sub>	4.340	*1.000	Vanadium Dioxide
233	W	19.300	0.163	Tungsten
234	$WB_2$	10.770	*1.000	Tungsten Boride
235	WC	15.600	0.151	Tungsten Carbide
236	$WO_3$	7.160	*1.000	Tungsten Trioxide
237	WS <sub>2</sub>	7.500	*1.000	Tungsten Disulphide
238	WSi <sub>2</sub>	9.400	*1.000	Tungsten Silicide
239	Υ	4.340	0.835	Yttrium
240	$Y_20_3$	5.010	*1.000	Yttrium Oxide
241	Yb	6.980	1.130	Ytterbium
242	$Yb_2O_3$	9.170	*1.000	Ytterbium Oxide
243	Zn	7.040	0.514	Zinc
244	$Zn_3Sb_2$	6.300	*1.000	Zinc Antimonide
245	$ZnF_2$	4.950	*1.000	Zinc Fluoride
246	ZnO	5.610	0.556	Zinc Oxide
247	ZnS	4.090	0.775	Zinc Sulfide



Table A-1 Material Table (continued)

Code	Formula	Density	Z-Ratio	Material Name
248	ZnSe	5.260	0.722	Zinc Selenide
249	ZnTe	6.340	0.770	Zinc Telluride
250	Zr	6.490	0.600	Zirconium
251	ZrB <sub>2</sub>	6.080	*1.000	Zirconium Boride
252	ZrC	6.730	0.264	Zirconium Carbide
253	ZrN	7.090	*1.000	Zirconium Nitride
254	ZrO <sub>2</sub>	5.600	*1.000	Zirconium Oxide



## Index

A	datalog 3-36
acoustic impedance 14-9	Declaration Of Contamination 1-5
active oscillator 14-6, 14-8	density 5-3
Activity 3-12	calibration 10-1
aerial mass density 14-10	value 10-1
aggregate	DTE 2-11
rate 5-14	_
anharmonic 3-29, 14-2, 14-7, 14-9	E
unable to detect 3-30	earth ground 1-3, 2-4
AT	electrode-to-quartz bond 14-3
crystal 14-8	electromagnetic interference 2-7
resonator 14-3	Error Code 9-9
Auto Z 3-29, 10-1	evaporation source. 14-11
unable to 3-29, 3-30	event condition 8-7
averaging time 5-15	
	F
C	feed ramp 5-13
cable noise 2-6	File Access Code 3-33, 6-9
calibration 10-3	film-induced stress 14-11
Checksum 9-8	fit, weighted least-square-exponential 14-12
CLEAR 3-1, 6-4, 6-8	Frequency Response Method 14-11
Communications	fundamental 3-29, 14-7, 14-8, 14-9
network protocol 9-2	
control	Н
system 14-13	Handheld Controller 3-31
controller	hardware handshaking 9-5
gain 14-12	
model 14-11, 14-12	I
crucible 3-28	I/O 7-1, 8-1
crystal	IAE 14-13
frequency spectrum 14-8	idle ramp 5-13
known, used 3-30	Input/Relay module 2-9
life 3-10	integral time 14-13
new 3-29	IP Address 9-2
replacement 13-20	ISE 14-13
resonance frequency 3-28	ITAE 14-14
resonance point 14-8	_
unknown, used 3-30	L
use history 3-35	Laplace transform 14-12
Crystal12 3-27	Lock Code 6-8
CrystalSix 3-27	logic statement 8-1, 8-17
CrystalTwo 3-26	
Customer Service 1-5	M
Customer Support	mass sensitivity 14-1
Return Material Authorization 1-5	material
	definition 3-20
D	dielectric 3-10
DAC 2-8, 4-7	measured deposition rate 14-13
data entry 3-1	measurement sensor 4-1



mode hopping 14-7 ModeLock oscillator 14-9	control 3-28, 4-4 spreadsheet program 3-39
multiple layer deposition 10-4	spurious shift 14-10
	status code 9-11
N	Subnet mask 9-2
net mask 6-4	Suspend 3-25
0	Т
Open Loop Method 14-11	TEST mode 6-7
Р	test mode 3-32
parameter	THICKNESS EQUATION 6-2 thickness shear mode 14-2
commands 9-10	thickness twist mode 14-2
request established 9-10	Time-Power 3-24
Parenthesis 8-5	tooling 10-2
period measurement technique 14-4	turret
PID 5-4, 14-11, 14-12	feedback 3-29
power 14-12	source 3-28
process error 14-13	U
Program Lock code 3-33	USB 12-1
pulse accumulator 14-4	
•	W
Q	windup 14-14
Quality 5-8	wire feed 5-13
quality rate control 14-5 quartz crystal 14-1, 14-14	wired remote 3-31
quasiharmonic 14-2, 14-9	Z
quaditariio ii 2, i i o	Z-match equation 14-5
R	Z-ratio 3-11, 5-3, 10-1, 10-3, 14-9
rate	
filter time 5-15	
rate deviation 5-8	
rate set point 14-13 RateWatcher 3-31, 5-17	
reference oscillator 14-4	
remote communication 9-1	
Repair Service 1-5	
resonance 14-6	
Retry 9-1	
RS-232 9-5 RS-232C 2-11, 9-1	
N3-2320 2-11, 9-1	
S	
Sales and Customer Service 1-5	
sensor	
diagnosing problems 13-15	
installation 2-1 type 3-25	
serial communication 2-11	
series resonance 14-8	
Service Center 1-5	
source	





www.inficon.com reachus@inficon.com

Due to our continuing program of product improvements, specifications are subject to change without notice. All trademarks are the property of their respective owners.

PN 074-545-P1H

©2017 INFICON