

Heated Capacitance Diaphragm Gauge

INFICON Edge Capacitance Diaphragm Gauge is a highly accurate vacuum measurement instrument designed for harsh manufacturing environments. The proven temperature controlled, corrosion resistant, ultrapure ceramic sensor provides superior span stability over many years paired with state-of-the-art zero stability. Edge comes with the INFICON patented unique sensor shield which protects the gauge from undesired process by-products. Advanced electronics offer a wide range of configurable signal conditioning for all applications and optional EtherCAT fieldbus interface. The innovative heating concept enables a cool to the touch surface and saves valuable tool space. INFICON Edge is the smallest vacuum measurement instrument of its kind.



PINFICON

ADVANTAGES

- Compact, saves valuable tool space
- Easy integration, EtherCAT, wide variety of full scales and flanges, standard with two set points
- Easy one push button or remote signal zero command, zero offset adjustable
- Diagnostic port for quick service and maintenance
- Two year warranty, longer life time with advanced heating concept and gauge protection
- No long term recalibration due to excellent signal stability and repeatability, even in harsh plasma applications
- Compliance and standards: CE, EN, UL, SEMI, RoHS

APPLICATIONS


 CVD, Etch, PVD and other semiconductor production processes

Edge[®] CDG100D2

NFICON



ORDERING INFORMATION



- 1) Optimized signal filter setting for pressure control
- 2) Not possible with fieldbus interfaces

bold = standard products

Other flange types on request.

Edge® CDG100D2

2



SPECIFICATIONS

Full scale (FS)	1000 Torr, 1100 mbar	500 1 Torr / mbar	0.5 0.05Torr / mbar	
Accuracy ¹⁾	0.15 % of reading			
Temperature effect				
On zero	0.0025 % FS/ °C			
On span	0.02 % of reading / °C			
Pressure, max.	400 kPa (absolute) 260 kPa (absolute)			
Resolution	0.003 % FS			
Lowest reading	0.01 % FS			
Lowest suggested reading	0.05 % FS			
Lowest suggested control pressure	0.5 % FS			
Temperature				
Operation (ambient) ²⁾		+10 +50 °C		
Bakeout at flange	≤110 °C			
Storage	−20 +65 °C			
Supply voltage	+14 +30 V (dc) or ±15 V (±5%)			
Power consumption				
During Heat up	≤20 W			
At operating temperature		≤14 W		
Output signal (analog)	0 +10 V (dc)			
Response time ³⁾	30 ms			
Degree of protection		IP 40		
Standards				
CE conformity	EN 61000-6-2, EN 61000-6-3, EN 61010-1 and RoHS			
ETL certification	UL 61010-1, CSA 22.2 No. 61010-1			
SEMI compliance	SEMI S2 ²⁾			
Electrical connection	D-sub, 15-pin, male			
Setpoint		· · ·		
Number of setpoints	2 (SP1, SP2)			
Relay contact	≤30 V (dc) / ≤0.5 A (dc)			
Hysteresis	1 % FS			
Diagnostic port				
Protocol	R\$232-C			
Read	pressure, status, ID			
Set	setpoints, filter, zero adjust, factory reset, DC offset			
Materials exposed to vacuum	ceramics (Al ₂ O ₃), stainless steel (AlSI 316L)			
Internal volume	See (AISTOL) See (AISTOL) 5.8 cm ³			
Weight	552 622 g			

¹⁾ Non-linearity, hysteresis, repeatability at 25°C ambient operating temperature without temperature effects after two hours operation

²⁾ Ambient temperatures >40°C may increase surface temperature above SEMI S2 compliance levels — mark "caution hot!"


³⁾ Increase 10 ... 90% FS



SPECIFICATION ETHERCAT

EtherCAT [®]			
Protocol	EtherCAT [®] , firmware generation 2.0		
Communication standards	Semiconductor Device Profile ETG.5003 Part 1 Common Device Profile ETG.5003 Part 2080 "Specific Device Profile - Vacuum Pressure Gauge"		
Process Data	Fixed PDO mapping and configurable PDO mapping		
EtherCAT connector	RJ45, 8-pin (socket), IN and OUT		
Cable	Shielded Ethernet CAT5e or higher		
Cable length	≤100 m (330 ft.)		
Data rate	100000 Kbps		

DIMENSIONS



Inspired by visions. Proven by success.

www.inficon.com reachus@inficon.com

FICU

Jŀ

Due to our continuing program of product improvements, specifications are subject to change without notice. The trademarks mentioned in this document are held by the companies that produce them.