

PPG550 ATM to Medium Vacuum Gauge

The new INFICON Pirani Piezo combination gauge (PPG550) is based on the most advanced MEMS (Microelctromechanical Systems) sensor technology available.

The Pirani/ Piezo combination technology miniaturized in the MEMS process enables the construction of a very small and thus space-saving sensor, which makes it possible to keep the overall height of the measuring device very small.

In addition to the advantage of the low height, a Pirani based on MEMS technology also offers the advantage of measuring deeper and more accurately in the HV range than a classic Pirani. In combination with a MEMS piezo sensor, mounted in the same flange, the Pirani gauge becomes a real vacuum wide range gauge, extending the measuring range far beyond the usual 1000 mbar, also towards the atmosphere. At the same time the MEMS piezo sensor provides gas type independent pressure measurement in the range of 2 ... 1333 mbar. Another advantage of the technologies mentioned is the increased resistance to acceleration forces and vibrations.

Last but not least the new INFICON PPG550 can be used to direct drop in replace the so called MKS910 "DualTrans™ MicroPirani™ -Absolute Piezo Vacuum Pressure Transducers" as well as MKS925 "Micro Pirani™ Vacuum Pressure Transducers". Inficon offes same connectors/ pin assignment, analog output and RS232/485 compatibility.



ADVANTAGES

- Gas type independent above 2 mbar allows safe venting with any gas mixture
- High accuracy and reproducibility at atmosphere for reliable, fast atmospheric pressure detection

1


- Versatile of mounting orientation provides engineering freedom in tool design
- Selectable analog output signal for easy system integration
- Digital interfaces RS232/ RS485

- Compliance & standards: CE, EN, UL, CSA, RoHS
 - Able to direct drop in replace MKS910 "DualTrans™ MicroPirani™ Absolute Piezo Vacuum Pressure Transducers" as well as MKS925 "Micro Pirani™ Vacuum Pressure Transducers".

DualTrans™ MicroPirani™ are registered trademarks of MKS Instruments, Andover, MA

Compliance & standards: CE, EN, UL, CSA, RoHS

ORDER INFORMATION



- 1) No RS interface on FCC 8-pin connector
- 2) Only for D-sub 9-pin or D-sub 15-pin HD connectors
- ³⁾ FCC 8-pin with 0 or 2 solid state relays; no RS interface on FCC 8-pin connector; solid state relays on FCC connector gauges have to be preset during production; they can't be set in the field due to missing RS interface
- 4) D-sub 9-pin with 0 or 1 solid state relay; customer choice of either RS232 or RS485 interface
- ⁵⁾ D-sub 15-pin HD with 0 or 3 solid state relays; customer choice of either RS232 or RS485 interface
- 6) All connectors are also available without solid state relays
- ⁷⁾ 2 solid state relays are only available on FCC 8-pin connector; solid state relays on FCC connector gauges have to be preset during production; they can't be set in the field due to missing RS interface
- 8) 1 solid state relay is only available on D-sub 9-pin connector; solid state relays can be set by customer via RS interface
- 9 3 solid state relays are only available on D-sub 15-pin HD connector; solid state relays can be set by customer in the field via the RS interface

Туре		PPG550 MEMS	
Measurement principle			
Pressure range	mbar		
		2 1333 MEMS Piezo resistive diaphragm	
		1.5 2 &nbs	
Measuring range			
Range (N2)	mbar	1x10⁻⁴ 1333	
Accuracy			
1100 1333 mbar	% of reading	0.5	
800 1099 mbar	% of reading	0.25	
100 800 mbar	% of reading	0.5	
2 99.9 mbar	% of reading	1	
1 x 10-4 1.99 mbar	% of reading	5	
1 x 10-5 9.99 x 10-5 mbar	% of reading	25	
Hysteresis			
10 1333 mbar	% of reading	0.1	
1 x 10-3 10 mbar	% of reading	1	
Responsetime (ISO 19685:2017)	ms	<20	
Temperature compensation	°C	+10 +50	
Temperature measurement absolute accuracy	°C	+/-1.5 (0 +80)	
Gas type dependence		look operating manual page 13	
Solid state relay			
Set point range	mbar	5 x 10 ⁻⁶ 1333	
Solid state relay			
Contact rating	V	50	
Solid state relay			
Contact rating	mA	100	
Solid state relay			
Contact on resistance	Ω	<35	
Solid state relay			
Contact endurance		Unlimited (no mechanical wear)	


SPECIFICATIONS

Туре		PPG550 MEMS	
Analog output			
3PPM-xxx-xxx0	V	0.61 10.2	
3PPM-xxx-xxx2	V	0.375 5.570	
3PPM-xxx-xxx3	V	1.0 9	
Error signal	V	Check operating Manual page 13	
Power Supply			
Supply voltage at the gauge	V (dc)	+12 30	
Power Supply			
Power consumption	W	<u><</u> 3.5	
Power Supply			
Internal fuse (thermal recoverable)	mA	100	
Power Supply			
Reverse polarity and overvoltage protection		yes	
Sensor cable connection			
3PPM-0xx-x0xx	IP40	FCC 68, 8-pin electrical connection	
3PPM-0xx-xExx	IP40	D-Sub HD, 15-pin, male electrical connector	
3PPM-0xx-xDxx	IP40	D-Sub, 9-pin, male electrical connection	
Sensor cable connection			
Sensor cable		shielded, 0.14 mm²/ conductor	
Sensor cable connection			
Cable lenght for analog operation	m	<u>≤</u> 100	
Cable lengt for RS232 operation	m	<u><</u> 15	
Cable lenght for RS482 operation	m	<u><</u> 1200	
RS232C/ RS485 interface			

SPECIFICATIONS		
Туре		PPG550 MEMS
Data format	bit	binary,
		8 data bits
		onestop bit
		no parity bit
		no handshake
		For further informaion on RS232/ RS485 interfaceplease look operating manua page 15
Materials exposed to vacuum		
Flange		SS 1.4307, AISI 304L
Housing		SS 1.4307, AISI 304L, AL 6061
Further parts		AISI 304L, Kovar, glass, Silicon, nickel, AL, SiO₂, Si₃N₄, gold, FPM, low outgassng epoxy resin, solder, RO4305
Pressure max.	bar	10 (absolute)
Admissible temperatures (ambiance)		
Operation	°C	-20 +50
Storage	°C	-40 +120
Bakeout	°C	+120 (non operating)
Relative humidity ambiance (IEC 68-2-38); year`s mean/ during 60 days	%	98 (non-condensing)
Use	m	Indoors only
		altitude up to 2000
Mounting orientation		any
Protection class	IP40	degree of protection

DIMENSIONS

Dimensions [mm]



	A	В
	[mm]	[mm]
DN 16 ISO-KF	12	39.4
DN 16 ISO-KF, long tube	29	56.4
DN 25 ISO-KF	12	39.4
4 VCR female	37.5	64.9
1/6" NPT	37.0	64.4

.

Weight

DN 16 ISO-KF	≈136 g
DN 16 ISO-KF, long tube	≈154 g
DN 25 ISO-KF	≈155 g
4 VCR female	≈158 g
1/2" NPT	≈139 g
4 VCR female	≈158 g



 www.inficon.com
 reachus@inficon.com

 Due to our continuing program of product improvements, specifications are subject to change without notice.

 RateWatcher is a trademark of INFICON. All other trademarks are the property of their respective owners.

 2022-07-13
 (2022-07)

 © 2022 INFICON