

QUICK START GUIDE

How to set the Lower Explosive Limit (LEL) at 5.0vol% on IRwin Methane Leak Detector

1

Press  followed by 

2

Use  to navigate to *General* and press 



3

Use  to navigate to *Custom* and press 



4

Use  to select *100% CH4 LEL Conc*



5

If prompted, enter the Supervisor (Advanced) password code and repeat step 4.
If not prompted, go ahead to the next step

6

Use  to select 5.0 vol% in the drop-down menu, press 



7

Press  followed by  and 