

# QS5

## VACUUM PUMP

### An affordable pump that lasts.

QS5 is a 2-stage, 5 CFM rotary vane pump with premium features without the premium price. Dual voltage operation, brass fittings, and an exhaust demister make QS5 a versatile and durable pump for everyday use. A two-year warranty ensures QS5 will stand up to daily punishment for years.

#### ADVANTAGES

- 142 l/min (5 CFM) displacement for vacuum down to 0,02 mbar
- Inlet check valve prevents oil from flowing back into the system
- Durable metal fittings and base
- Oil demister helps reduce oil in exhaust
- Versatile dual voltage operation

#### SPECIFICATIONS


Includes	QS5 Detachable power cord Vacuum pump oil
Free air displacement	142 l/min 8.52 m³/h (5 cfm)
Motor	1/2 HP AC
Pump stages	2
Oil capacity	370 ml (12.5 oz.)
Weight	10.89 kg (24 lb.)
Certifications	A2L Certified CE, UKCA
Power source	115/230 V (ac) dual voltage operation
Stages	2
Warranty	Two-year

#### ORDERING INFORMATION

QS5 pump, 115 V (ac)	700-100-P1
QS5 pump, 230 V (ac)	700-100-P10

#### Accessories and Replacement Parts

Power cord (115 V)	068-0684
Power cord (230 V Euro)	068-0685



Oil demister helps reduce oil in exhaust

Gas ballast (not shown)

Large sightglass to monitor oil level

Easy access oil drain with tethered cap

Rubber handle for no-slip grip

Durable metal fittings (3/8 and 1/4 in.) with check valve

Switch for 115 or 230V operation (requires appropriate power cord)

Rugged metal base with rubber feet keeps pump stable