

# Manifold Gauge Sets



## PRECISE, DEPENDABLE MEASUREMENT

The patented gauge movement in our manifold gauges delivers pulse/vibration free measuring and gauges that can withstand 2-1/2 times over pressure without damaging the gauges. Accuracy is 1% no matter where you are on the gauge. The large, 80mm, easy-to-read gauge face is available in several configurations for your most demanding HVAC/R and automotive applications. The manifolds have a unique insertion valve stem for finer adjustment. This design allows for less contamination and fewer seal failures.

Both manifold gauge sets come with a two year warranty, that's twice the warranty of any other manufacturer.

## MANIFOLD FEATURES

- ◆ insertion valve for easier metering
- ◆ large sightglass for visual contact of refrigerant flow
- ◆ rebuildable valves, replacement seals available
- ◆ durable metal knobs
- ◆ 1/4" SAE connections

## GAUGE FEATURES

- ◆ patented gauge movement for pulse/vibration free measuring
- ◆ withstands 2-1/2 times over pressure without damaging gauges
- ◆ 1% accuracy
- ◆ large, 80mm, easy-to-read gauge face
- ◆ high and low set gauges
- ◆ hanging hook
- ◆ universal gauge set for both automotive and HVAC&R

## Manifold Gauge Sets

The composite molded block manifold is half the weight of standard manifolds.

*Light manifold gauge set  
(weight 1 lb. 3 oz.)*



The durable aluminum manifold gauges come with protective rubber boots.

*Aluminum manifold gauge set  
(weight 2 lbs. 2.5 oz.)*

## Ordering Information

### Temperature Scale Ranges

R12, R134a Automotive  
R22, R134a, R404A  
R410A  
R12, R22, R502

### Light Manifold Gauge Sets 2-way w/gauge protectors

710-602-G11A  
710-602-G21  
710-602-G31  
710-602-G41

### Light Manifold Gauge Sets 2-way w/out gauge protectors

710-602-G10A  
710-602-G20  
710-602-G30  
710-602-G40

### Temperature Scale Ranges

R12, R134a Automotive  
R22, R134a, R404A  
R410A  
R12, R22, R502

### Aluminum Manifold Gauge Sets 2-way w/gauge protectors

710-612-G11A  
710-612-G21  
710-612-G31  
710-612-G41

### Aluminum Manifold Gauge Sets 4-way w/gauge protectors

710-614-G11A  
710-614-G21  
710-614-G31  
710-614-G41

CE

Call 1.800.344.3304 for your nearest distributor.



#### GLOBAL HEADQUARTERS:

Two Technology Place, East Syracuse, NY 13057 USA  
Tel: +315.434.1100 Fax: +315.437.3803 E-mail: reachus@inficon.com

Due to our continuing program of product improvements, specifications are subject to change without notice.  
Visit our website for contact information and other sales offices worldwide. [www.inficon.com](http://www.inficon.com)

eibb80a1-a ©2002 INFICON